EMERIO PO-115985

EMERIO PO-115985 Pizza Maker/Oven User Manual

Model: PO-115985 | Brand: EMERIO

1. Introduction

Thank you for purchasing the EMERIO PO-115985 Pizza Maker/Oven. This appliance is designed to allow you to prepare delicious mini pizzas quickly and conveniently. Its unique design, featuring a ceramic dome and non-stick cooking surface, ensures even cooking and easy cleanup. Please read this manual thoroughly before first use to ensure safe and optimal operation of your new pizza oven.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs. The ceramic dome and cooking surface become very hot during operation.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Ensure the appliance is placed on a stable, heat-resistant surface during operation.

3. Components and Parts

Your EMERIO PO-115985 Pizza Maker/Oven comes with the following components:

- Main Base Unit with Heating Element and Control Knob
- Ceramic Dome (Pizza Stone)
- Mini Pizza Peels (typically 4 or more)
- Dough Cutter (for perfectly sized mini pizzas)
- User Manual (this document)



Figure 3.1: The EMERIO PO-115985 Pizza Maker/Oven with its included accessories, including the ceramic dome, base unit, pizza peels, and dough cutter.



Figure 3.2: Close-up view of the main base unit, showing the non-stick cooking surface and the heating element.



Figure 3.3: The pizza maker in operation, demonstrating how mini pizzas are placed under the ceramic dome using the provided peels.



Figure 3.4: An internal view of the ceramic dome, showing its construction and the metal plate that helps distribute heat.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe the non-stick cooking surface with a damp cloth. The ceramic dome can be wiped with a dry cloth. Do not immerse the base unit in water.
3. **Placement:** Place the pizza maker on a stable, flat, and heat-resistant surface. Ensure there is adequate ventilation around the appliance and that it is not too close to walls or other heat-sensitive objects.
4. **Assembly:** Place the ceramic dome securely onto the base unit. Ensure it is properly seated.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet. The appliance is now ready for use.

5. Operating Instructions

1. **Preheating:** Turn the control knob to the desired temperature setting (usually maximum for preheating). Allow the pizza maker to preheat for approximately 10-15 minutes. The ceramic dome needs to reach a high temperature for optimal cooking.
2. **Prepare Dough:** Use the included dough cutter to create perfectly sized mini pizza bases.

3. **Add Toppings:** Place your mini pizza dough on one of the pizza peels. Add your desired sauce and toppings. Be mindful not to overload the pizzas, as this can affect cooking and cause spills.
4. **Cooking:** Carefully slide the prepared mini pizza from the peel onto the hot cooking surface under the ceramic dome. You can cook up to 4 pizzas simultaneously.
5. **Monitor Cooking:** Cooking time will vary depending on the thickness of the dough and the amount of toppings, typically 5-10 minutes. Monitor the pizzas through the openings. The cheese should be melted and bubbly, and the crust golden brown.
6. **Remove Pizzas:** Once cooked, use the pizza peels to carefully remove the hot pizzas from the oven.
7. **Serve:** Serve immediately and enjoy!
8. **Turn Off:** When finished, turn the control knob to the "OFF" position and unplug the appliance from the wall outlet.

Tip: For best results, ensure your dough is thin and your toppings are not too wet. Pre-baking certain toppings like mushrooms or onions can prevent excess moisture.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your EMERIO Pizza Maker.

- **Always Unplug:** Before cleaning, ensure the appliance is unplugged from the power outlet and has completely cooled down.
- **Ceramic Dome:** The ceramic dome can be cleaned with a dry brush or a slightly damp cloth once cooled. Do not use abrasive cleaners or immerse in water.
- **Cooking Surface:** The non-stick cooking surface can be wiped clean with a damp cloth and mild detergent. For stubborn residue, allow it to soak briefly with a damp cloth before wiping. Do not use metal scouring pads or abrasive cleaners that could damage the non-stick coating.
- **Pizza Peels & Dough Cutter:** These accessories can be washed with warm soapy water and dried thoroughly.
- **Base Unit:** Wipe the exterior of the base unit with a damp cloth. Never immerse the base unit in water or any other liquid.
- **Storage:** Store the clean and dry appliance in a cool, dry place, preferably in its original packaging.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working; control knob not turned on.	Ensure the power cord is securely plugged into a working outlet. Turn the control knob to an active setting.
Pizzas not cooking evenly or taking too long.	Insufficient preheating time; too many toppings; dough too thick; ceramic dome not properly seated.	Allow adequate preheating time (10-15 minutes). Use thinner dough and fewer toppings. Ensure the ceramic dome is correctly placed.
Smoke or unusual odor during first use.	Protective coating burning off; residue from manufacturing.	This is normal for first use. Ensure good ventilation. It should dissipate after a few minutes. If it persists, unplug and contact support.
Pizzas sticking to the cooking surface.	Surface not properly cleaned; dough too wet; not enough flour on peel.	Ensure the non-stick surface is clean. Lightly flour the pizza peels before placing dough. Avoid overly wet toppings.

8. Specifications

Brand	EMERIO
Model Name	PO-115985
Power Source	Electric
Wattage	900.0 watts
Control Type	Knob
Special Feature	Non-stick cooking surface
Door Style	Dropdown Door (access openings)
Included Components	Pizza Stone (Ceramic Dome), User Manual, Mini Pizza Peels, Dough Cutter
Product Dimensions	14.57 x 9.65 x 14.76 inches (approx.)
Item Weight	Approx. 9.77 lbs (4.43 kg)
Color	Black, Orange (Ceramic Dome)

9. Warranty and Support

Your EMERIO PO-115985 Pizza Maker/Oven is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or questions regarding your appliance, please contact EMERIO customer service. Contact information can typically be found on the EMERIO official website or on the product packaging.

Please have your model number (PO-115985) and purchase date available when contacting support.

© 2024 EMERIO. All rights reserved. | Model: PO-115985