

[Manuals.plus](#) /

› [Fricosmos](#) /

› Fricosmos Stainless Steel Wall-Mounted Knee-Operated Washbasin (Model 061202) Instruction Manual

Fricosmos 061202

Fricosmos Stainless Steel Wall-Mounted Knee-Operated Washbasin

Model: 061202 | Brand: Fricosmos

INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your Fricosmos Stainless Steel Wall-Mounted Knee-Operated Washbasin. Please read these instructions carefully before use and retain them for future reference.



Figure 1: Fricosmos Stainless Steel Wall-Mounted Knee-Operated Washbasin, 30 x 18 cm, Grey. This image shows the complete washbasin unit with its integrated knee-operated control and faucet.

SAFETY INFORMATION

Observe the following safety precautions to prevent injury and damage to the product:

- Ensure all water connections are properly sealed to prevent leaks.
- Installation should be performed by a qualified professional if you are unsure.
- Do not use abrasive cleaners or harsh chemicals on the stainless steel surface.
- Verify that the wall mounting is secure and capable of supporting the washbasin's weight when filled with water.
- Always turn off the main water supply before performing any maintenance or installation.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Wall-mounted knee-operated washbasin (hot and cold water)
- All necessary accessories for installation
- Mixing T-valve for temperature regulation

Setup and Installation

The Fricosmos washbasin is designed for wall-mounted installation. It requires both water inlet and drainage connections.

1. **Prepare the Installation Area:** Identify the desired mounting location on a sturdy wall. Ensure access to hot and cold water supply lines and a drainage point.
2. **Mount the Washbasin:** Securely attach the washbasin to the wall using appropriate fasteners (included). Ensure it is level and stable.
3. **Connect Water Supply:** Connect the hot and cold water supply lines to the washbasin's inlets. The included mixing T-valve allows for temperature regulation. Ensure all connections are tight to prevent leaks.
4. **Connect Drainage:** Connect the washbasin's drain outlet to your facility's drainage system. The basin features a large capacity with an overflow and drain valve.
5. **Test Connections:** Slowly turn on the main water supply and check for any leaks at all connection points.

Note: All necessary accessories for installation are included with the product.

Operating Instructions

This washbasin features a knee-operated, non-timed push-button mechanism for water activation.

1. **Water Activation:** Gently press the knee-operated push-button with your knee. Water will flow from the faucet as long as the button is depressed.
2. **Water Temperature Regulation:** The mixing T-valve allows you to adjust the water temperature. This adjustment is typically done during installation or maintenance and not during regular operation. Consult a professional if temperature adjustment is required.
3. **Water Flow:** The water flow stops when the knee-operated push-button is released.

Maintenance and Care

Proper care ensures the longevity and hygiene of your Fricosmos washbasin.

- **Regular Cleaning:** Clean the stainless steel surface regularly with a soft, damp cloth.
- **Avoid Harsh Cleaners:** Do not use abrasive sponges, steel wool, or harsh chemical cleaners, as these can scratch or damage the stainless steel finish.
- **Drying:** After cleaning, dry the surface with a clean, dry cloth to prevent water spots and maintain shine.
- **Drain Maintenance:** Periodically check the drain for blockages and clean as necessary to ensure proper water flow.

Troubleshooting

Problem	Possible Cause	Solution
No water flow	Water supply off; clogged inlet filter; faulty knee-operated mechanism.	Check main water supply; clean inlet filters; inspect knee-operated mechanism for obstruction or damage.

Problem	Possible Cause	Solution
Water leaks	Loose connections; damaged seals.	Tighten all water connections; replace any damaged seals.
Slow drainage	Drain blockage.	Clear any debris from the drain and overflow.
Incorrect water temperature	Mixing T-valve setting incorrect.	Adjust the mixing T-valve. This may require professional assistance.

SPECIFICATIONS

Brand	Fricosmos
Model Number	061202
Material	Stainless Steel
Color	Grey
Dimensions (Size)	30 x 18 cm
Style	Modern
Installation Type	Wall-mounted (Independent)
Drain Type	Grid
Included Items	1 x Wall-mounted knee-operated washbasin (hot and cold water), all necessary installation accessories

WARRANTY AND SUPPORT

Warranty Information: This product does not come with a manufacturer's warranty.
For any questions or assistance regarding your Fricosmos washbasin, please contact your retailer or the point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question