Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Speed Queen /
- SPEED QUEEN Home Style Mechanical Top Load Washer (LWN432SP115TW01) Instruction Manual

Speed Queen LWN432SP115TW01

Speed Queen LWN432SP115TW01 Home Style Mechanical Top Load Washer

User Instruction Manual

NTRODUCTION

The Speed Queen LWN432SP115TW01 is a robust home-style mechanical top load washer designed for durability and efficient cleaning. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your appliance. Please read this manual thoroughly before operating your washer.



This image displays the front view of the Speed Queen LWN432SP115TW01 top load washer, featuring its classic white finish and mechanical control panel.

SAFETY INFORMATION

Your safety and the safety of others are very important. Please read all safety messages in this manual and on your appliance. Always follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Do not wash articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, drycleaning solvents, or other flammable or explosive substances, as they give off vapors that could ignite or explode.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the

appliance is used near children.

- Before the appliance is removed from service or discarded, remove the door to the washing compartment.
- Do not reach into the appliance if the tub or agitator is moving.
- Do not install or store this appliance where it will be exposed to the weather.
- · Do not tamper with controls.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in this manual or in published user-repair instructions that you understand and have the skills to carry out.
- Proposition 65 Warning: This product can expose you to chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance and longevity of your Speed Queen washer. This appliance is designed for freestanding installation.

- 1. **Location:** Choose a location with a solid, level floor capable of supporting the washer's weight (196 pounds) when full of water and laundry. Ensure adequate space for ventilation and access.
- 2. **Leveling:** Use a level to ensure the washer is perfectly level. Adjust the leveling legs as needed to prevent vibration and noise during operation.
- 3. **Water Connections:** Connect the hot and cold water inlet hoses to the corresponding water supply valves. Ensure connections are tight to prevent leaks.
- 4. **Drain Hose:** Securely attach the drain hose to the washer and route it into a standpipe or laundry tub, ensuring it is properly secured to prevent dislodging during draining.
- 5. **Electrical Connection:** Plug the washer's power cord into a grounded 3-prong outlet. Do not use an extension cord. Ensure the electrical supply meets the requirements specified in the specifications section.

OPERATING INSTRUCTIONS

Your Speed Queen washer features mechanical controls for straightforward operation.

- 1. **Prepare Laundry:** Sort laundry by fabric type, color, and soil level. Close zippers, fasten hooks, and tie drawstrings to prevent damage.
- 2. **Load the Washer:** Open the lid and load items loosely around the curved 4-vane agitator. Do not overload the washer; ensure items can move freely for effective cleaning. The washer has a 16 lbs capacity.
- 3. **Add Detergent:** Add the recommended amount of detergent directly into the wash tub before adding clothes, or into the dispenser if available.
- 4. **Select Water Temperature:** Turn the temperature selector knob to choose the desired water temperature for your load (e.g., Hot, Warm, Cold).
- 5. **Select Wash Cycle:** Turn the mechanical control knob to select the appropriate wash cycle (e.g., Normal, Perm Press, Delicate, Heavy Duty).
- 6. **Start the Washer:** Pull out the cycle knob to start the wash cycle. The washer will begin to fill with water. The solid mount suspension system helps ensure stable operation throughout the cycle.
- 7. Lid Lock: For safety, the lid may lock during certain parts of the cycle. Do not attempt to force the lid open.

MAINTENANCE

Regular maintenance helps ensure your Speed Queen washer operates efficiently and extends its lifespan.

- Cleaning the Exterior: Wipe down the exterior surfaces with a soft, damp cloth and mild soap. Avoid abrasive cleaners.
- Cleaning the Tub: Periodically run a clean cycle with a washer cleaner or a cup of white vinegar to remove detergent residue and odors from the stainless steel tub.
- Water Inlet Hoses: Inspect water inlet hoses every 5 years (or sooner if signs of wear are present) and replace them if they show cracks, bulges, or leaks.
- Lint Filter (if applicable): Some models may have a removable lint filter. Refer to your specific model's diagram for location and clean it regularly.
- Winterizing: If the washer is located in an area subject to freezing temperatures, follow proper winterizing procedures to drain all water from the hoses and pump to prevent damage.

TROUBLESHOOTING

Before calling for service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Washer does not start	Power cord unplugged; Circuit breaker tripped; Lid not closed properly.	Ensure power cord is securely plugged in; Reset circuit breaker; Close lid firmly.
Washer not filling with water	Water supply turned off; Water inlet hoses kinked; Inlet screens clogged.	Turn on water supply; Straighten hoses; Clean inlet screens.
Washer not draining or spinning	Drain hose kinked or clogged; Load out of balance.	Check and clear drain hose; Redistribute laundry evenly in the tub.
Excessive vibration or noise	Washer not level; Load out of balance; Shipping bolts not removed (if applicable).	Level the washer; Redistribute laundry; Ensure all shipping bolts are removed.
Clothes are not clean	Overloading; Insufficient detergent; Incorrect cycle selection.	Reduce load size; Use correct amount of detergent; Select appropriate wash cycle.

SPECIFICATIONS

Key technical specifications for the Speed Queen LWN432SP115TW01 washer:

Feature	Detail
Manufacturer	Speed Queen
Part Number	LWN432SP115TW01
Item Weight	196 pounds
Package Dimensions	45 x 30 x 28 inches
Color	White
Style	Top Load
Finish	Stainless Steel

Feature	Detail
Material	Stainless steel
Installation Method	Freestanding
Item Package Quantity	1
Capacity Description	16 lbs
Certification	UL Listed
Special Features	Solid mount suspension system, Curved 4-vane agitator

WARRANTY AND SUPPORT

For detailed warranty information, service requests, or technical support, please refer to the warranty card included with your purchase or visit the official Speed Queen website. Keep your purchase receipt as proof of purchase for warranty claims.

For additional assistance, you may also contact the retailer where the product was purchased.

Related Documents - LWN432SP115TW01



Speed Queen LWN432SP115TW01 Commercial Top Load Washer - Specifications & Features

Detailed specifications and features for the Speed Queen Manual Homestyle Commercial Top Load Washer (Model LWN432SP115TW01), highlighting its durable construction, performance features, and technical data for commercial laundry applications.



Speed Queen Commercial Washers and Dryers Manual

This manual provides detailed information on Speed Queen's commercial rear control washers and dryers, including top load washers, single load dryers, stack dryers, and front load washers. It covers features, specifications, and operational details for reliable performance in commercial environments.

Installation Instructions
for Topload Washers

Speed Queen Topload Washer Installation Guide

Comprehensive installation instructions for Speed Queen topload washers from Alliance Laundry Systems. Covers setup, connections, leveling, electrical requirements, and safety. Ensure proper installation for optimal performance.

Notes Inspends Application



Speed Queen Frontload Washer Quick Start Guide

A concise guide for Speed Queen frontload washers, covering product registration, initial setup, laundry tips, cleaning procedures, and troubleshooting common issues.



Speed Queen Washer and Dryer Quick Start Manual

Concise quick start guide for installing and operating Speed Queen washers and dryers, including essential setup steps and usage tips for commercial-grade laundry appliances.



Speed Queen Dryer Quick Consumer Manual

A concise guide to installing, operating, and understanding the cycles of Speed Queen dryers, including electronic and mechanical control models.