

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [STEREN](#) /

› [STEREN 50ft 3-RCA Component Video Cable Instruction Manual](#)

## STEREN B07DFCR4Y4

# STEREN 50ft 3-RCA Component Video Cable Instruction Manual

## INTRODUCTION

---

This manual provides essential information for the proper setup, operation, and maintenance of your STEREN 50ft 3-RCA Component Video Cable. This cable is designed to transmit high-quality analog component video signals between compatible devices, such as DVD players, gaming consoles, and televisions or projectors, commonly found in home theater systems.

## SETUP

---

Follow these steps to correctly connect your component video cable:

- 1. Identify Ports:** Locate the component video output ports on your source device (e.g., DVD player) and the component video input ports on your display device (e.g., TV). These ports are typically labeled 'Y Pb Pr' or 'Y Cb Cr' and are color-coded Red, Green, and Blue.
- 2. Connect Source Device:** Take one end of the STEREN 3-RCA Component Video Cable. Connect the Red connector to the Red output port, the Green connector to the Green output port, and the Blue connector to the Blue output port on your source device. Ensure each connection is firm.
- 3. Connect Display Device:** Take the other end of the STEREN 3-RCA Component Video Cable. Connect the Red connector to the Red input port, the Green connector to the Green input port, and the Blue connector to the Blue input port on your display device. Again, ensure each connection is firm and matches the color coding.
- 4. Power On Devices:** Once all connections are secure, power on both your source device and your display device.
- 5. Select Input:** On your display device, use the remote control or menu options to select the correct component video input source (e.g., 'Component 1', 'YPbPr', 'Video Input').



Image: A coiled STEREN 50ft 3-RCA Component Video Cable, showcasing its length and the three color-coded connectors (Red, Green, Blue) at each end. This cable is used for transmitting analog video signals between compatible electronic devices.

## OPERATING

---

Once properly connected and the correct input is selected on your display device, the STEREN 3-RCA Component Video Cable will automatically transmit the video signal from your source device to your display. No further user interaction with the cable itself is required during operation. Ensure that both the source and display devices are configured to output and receive component video signals, respectively, for optimal performance.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your STEREN 3-RCA Component Video Cable, consider the following maintenance tips:

- **Keep Connectors Clean:** Periodically inspect the 24k gold-plated connectors for dust or debris. Use a soft, dry cloth to gently wipe them clean if necessary. Avoid using liquid cleaners directly on the connectors.
- **Avoid Kinks and Sharp Bends:** Do not bend the cable sharply or allow it to become kinked, as this can damage the internal wiring and affect signal quality. Store the cable in a loose coil when not in use.
- **Handle with Care:** Always grasp the connector housing when plugging or unplugging the cable, rather than pulling on the cable itself.
- **Environmental Conditions:** Keep the cable away from extreme temperatures, direct sunlight, and excessive moisture.

## TROUBLESHOOTING

---

If you encounter issues with your component video connection, try the following troubleshooting steps:

- **No Picture or Black Screen:**

- Verify that all three color-coded RCA connectors (Red, Green, Blue) are securely plugged into their corresponding ports on both the source and display devices.
- Ensure the correct input source is selected on your television or display.
- Check that both the source device and display device are powered on.
- If possible, test the cable with another set of compatible devices to rule out issues with the cable itself.

- **Poor Picture Quality (e.g., blurry, distorted, or incorrect colors):**

- Confirm that the Red, Green, and Blue connectors are matched correctly at both ends. Incorrect color matching will result in distorted or missing colors.
- Ensure all connections are tight and free from looseness.
- Inspect the cable for any visible damage, such as kinks or frayed insulation.
- Check the settings on your source device to ensure it is outputting a component video signal.

## SPECIFICATIONS

<b>Brand</b>	STEREN
<b>Model Number (ASIN)</b>	B07DFCR4Y4
<b>Cable Type</b>	Component Video
<b>Length</b>	50 feet
<b>Connector Type</b>	3-RCA Male-to-Male
<b>Connector Plating</b>	24k Gold-Plated
<b>Color Coding</b>	Red, Green, Blue
<b>Cable Color</b>	Ivory
<b>Compatible Devices</b>	Home Theater System, DVD Player
<b>UPC</b>	884645100345

## WARRANTY

This STEREN product is covered by a manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the documentation included with your purchase or visit the official STEREN website.

## SUPPORT

For technical assistance, product inquiries, or customer service, please contact STEREN customer support. You can find contact information, FAQs, and additional resources by visiting the official [STEREN Brand Store on Amazon](#) or the STEREN corporate website.

