

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [mecor](#) /

> [User Manual for L-Shaped Corner Computer Desk with Shelf](#)

mecor L-Shaped Corner Computer Desk

User Manual

L-Shaped Corner Computer Desk with Shelf

Model: L-Shaped Corner Computer Desk

Brand: mecor

1. INTRODUCTION

Thank you for purchasing the mecor L-Shaped Corner Computer Desk. This manual provides detailed instructions for assembly, operation, and maintenance to ensure safe and efficient use of your new furniture. Please read this manual thoroughly before beginning assembly and retain it for future reference.

2. SAFETY INFORMATION

- Always assemble the desk on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload the desk or shelves. Refer to specifications for weight limits.
- Keep small parts away from children during assembly.
- Handle glass components with care to avoid breakage and injury.
- Do not stand or sit on the desk.
- Avoid placing hot items directly on the glass surface without protection.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
A	Main Glass Desktop Panel (Left)	1
B	Main Glass Desktop Panel (Right)	1
C	Corner Glass Panel	1

Part	Description	Quantity
D	Upper Glass Shelf	1
E	Metal Frame Leg (Type 1)	2
F	Metal Frame Leg (Type 2)	2
G	Metal Crossbar	4
H	CPU Stand Frame	1 set
I	Keyboard Tray	1
J	Hardware Pack (Screws, Washers, Allen Wrench)	1

4. ASSEMBLY INSTRUCTIONS (SETUP)

Estimated Assembly Time: 45-60 minutes. Two people recommended for easier assembly.

- Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratches. Refer to the "Package Contents" section to identify each part.
- Assemble Leg Frames:** Attach the metal crossbars (G) to the metal frame legs (E and F) using the provided screws from the hardware pack (J). Do not fully tighten screws until all components are in place.
- Attach Desktop Panels:** Carefully place the main glass desktop panels (A and B) onto the assembled leg frames. Secure them using the appropriate screws and suction cups/pads as indicated in the detailed diagram (refer to included paper instructions for diagrams).
- Install Corner Panel:** Position the corner glass panel (C) to connect the two main desktop sections. Secure it to the frame.
- Assemble Upper Shelf:** Attach the supports for the upper glass shelf (D) to the main frame, then carefully place the upper glass shelf onto its supports.
- Install CPU Stand and Keyboard Tray:** Assemble the CPU stand frame (H) and position it as desired. Attach the keyboard tray (I) rails to the underside of one of the main desktop panels and slide the tray into place.
- Final Tightening:** Once all components are in place and aligned, systematically tighten all screws and fasteners. Ensure the desk is stable and level.



Figure 4.1: Fully assembled mecor L-Shaped Corner Computer Desk, showcasing its glass and metal construction, L-shape design, and integrated upper shelf and CPU stand. The desk is set up in a room with a computer monitor, keyboard, and other office accessories.

5. OPERATION AND USAGE

The mecor L-Shaped Corner Computer Desk is designed for versatile use in home and office environments. Its L-shaped configuration provides ample surface area for multiple monitors, laptops, and other peripherals, making it ideal for gaming, office work, or study.

- **Workstation Setup:** Utilize the spacious desktop for your computer, monitor(s), keyboard, and mouse. The L-shape allows for efficient corner placement, maximizing room space.
- **Storage:** The integrated upper shelf is suitable for holding books, small printers, or decorative items. The CPU stand provides a dedicated space for your computer tower, keeping it off the main desktop.
- **Cable Management:** While the desk does not have built-in cable management, its open design allows for easy routing of cables using external cable ties or clips (not included).

6. MAINTENANCE AND CARE

Proper care will extend the life and maintain the appearance of your mecor desk.

- **Glass Surfaces:** Clean glass surfaces with a soft, lint-free cloth and a glass cleaner. Avoid abrasive cleaners or scouring pads that can scratch the glass.
- **Metal Frame:** Wipe metal parts with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by drying thoroughly. Avoid harsh chemicals.
- **Spills:** Immediately wipe up any spills to prevent staining or damage, especially on metal components.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten as necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may affect the finish of the metal frame over time.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Screws are not fully tightened; uneven floor.	Ensure all assembly screws are tightened securely. Adjust leveling feet if present, or place shims under legs on uneven surfaces.
Parts do not align during assembly.	Incorrect part orientation; screws tightened too early.	Review assembly steps and diagrams. Loosen all screws, align parts correctly, then re-tighten.
Missing or damaged parts.	Packaging error or transit damage.	Do not proceed with assembly. Contact mecor customer support with your purchase details and a description of the issue.

8. SPECIFICATIONS

Brand: mecor

Product Dimensions: 57.5"D x 56"W x 36"H

Color: Clear Glass

Style: Modern

Base Material: Alloy Steel

Top Material Type: Glass

Finish Type: Steel

Special Feature: L-Shape Design

Room Type: Living Room, Home Office

Recommended Uses: Office, Gaming, Working

Included Components: Desk, Keyboard Tray

Item Weight: 74.9 Pounds

Number Of Shelves: 2 (Upper Shelf, CPU Stand)

Assembly Required: Yes

9. WARRANTY AND SUPPORT

mecor stands behind the quality of its products. For information regarding warranty coverage, product support, or to report missing/damaged parts, please contact mecor customer service directly. Please have your purchase receipt and product model information ready when contacting support.

Contact information for mecor customer service can typically be found on the product packaging or the retailer's website where the product was purchased.

© 2023 mecor. All rights reserved.
This manual is subject to change without notice.