

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Moen](#) /

› [Moen Brecklyn Single-Handle Pull-Out Sprayer Kitchen Faucet \(Model 87557\) Instruction Manual](#)

## Moen 87557

# Moen Brecklyn Single-Handle Pull-Out Sprayer Kitchen Faucet (Model 87557) Instruction Manual

Your guide to installation, operation, and maintenance.

## 1. INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your Moen Brecklyn Single-Handle Pull-Out Sprayer Kitchen Faucet, Model 87557. Please read this manual thoroughly before beginning installation or use to ensure proper function and longevity of your faucet.



**Figure 1:** Moen Brecklyn Single-Handle Pull-Out Sprayer Kitchen Faucet, Chrome finish. This image displays the faucet's overall design, including the single handle on the right and the pull-out sprayer head.

## 2. PRODUCT FEATURES

---

- **Single-Handle Design:** Allows for easy adjustment of water temperature and flow.
- **Pull-Out Sprayer:** Provides extended reach for cleaning and filling tasks, retracts smoothly.
- **Power Clean Spray Technology:** Delivers concentrated spray power for efficient cleaning.
- **Duralock Quick Connect System:** Facilitates a straightforward and secure installation process.
- **Chrome Finish:** A highly reflective, mirror-like finish that complements any decor.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation. The package typically includes:

- Faucet body with single handle
- Pull-out sprayer head
- Mounting hardware (nuts, washers, gasket)


- Deck plate (escutcheon) for 3-hole installations
- Hot and cold water supply lines
- Weight for pull-out hose
- Installation instructions

## 4. SAFETY INFORMATION

- Always turn off the main water supply before installing or servicing the faucet.
- Wear safety glasses during installation to protect your eyes.
- Ensure all connections are tight to prevent leaks, but do not overtighten.
- If you are unsure about any part of the installation, consult a qualified plumber.
- Keep small parts away from children.

## 5. INSTALLATION (SETUP)

This faucet is designed for single-hole or three-hole deck mount installations.



**Figure 2:** Sink hole compatibility. The diagram illustrates that the faucet can be installed on both one-hole and three-hole sinks. For three-hole sinks, the included deck plate (escutcheon) is used to cover the additional holes.

### 5.1 Tools Required

- Adjustable wrench
- Phillips screwdriver
- Plumber's putty or silicone sealant (optional, for deck plate)
- Flashlight
- Bucket and towels

### 5.2 Installation Steps

1. **Prepare the Sink:** Turn off water supply valves. Remove the old faucet if applicable. Clean the sink surface.
2. **Install Deck Plate (for 3-hole sinks):** If your sink has three holes, place the deck plate over the holes. Apply plumber's putty or silicone sealant around the base of the deck plate if desired for a watertight seal.
3. **Mount the Faucet:** Insert the faucet body through the center hole of the sink (and deck plate, if used). From underneath the sink, secure the faucet with the provided washer and mounting nut. Tighten firmly but do not overtighten.
4. **Connect Water Supply Lines:** Attach the hot and cold water supply lines from the faucet to your home's water supply valves. Ensure connections are secure.
5. **Connect Sprayer Hose:** Use the Duralock Quick Connect System to attach the pull-out sprayer hose to the designated port on the faucet's underside. Ensure it clicks securely into place.
6. **Install Hose Weight:** Attach the hose weight to the pull-out sprayer hose at the indicated location (usually 6-8 inches from the end of the hose loop) to ensure proper retraction.
7. **Test for Leaks:** Turn on the main water supply slowly. Check all connections for leaks. Operate the faucet to flush out any debris and ensure proper function.

## 6. OPERATION

- **Water Flow and Temperature:** Lift the single handle to turn on the water and control flow volume. Move the handle left for hot water and right for cold water.
- **Pull-Out Sprayer:** Grasp the sprayer head and pull it out from the spout. The hose will extend for increased reach.
- **Spray Modes:** The sprayer head features a button to switch between aerated stream and Power Clean spray modes. Press the button to toggle between these functions.
- **Retracting the Sprayer:** When finished, gently guide the sprayer head back into the spout. The hose weight will assist in smooth retraction.

## 7. MAINTENANCE AND CLEANING

- **Regular Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Rinse thoroughly with water and dry with a soft cloth to prevent water spots.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the chrome finish.
- **Aerator Maintenance:** Periodically unscrew the aerator from the sprayer head and clean any mineral deposits or debris. Rinse and reattach.
- **Hose Inspection:** Periodically inspect the pull-out hose for any signs of wear or damage.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	<ul style="list-style-type: none"> <li>◦ Partially closed water supply valves</li> <li>◦ Clogged aerator</li> <li>◦ Debris in supply lines</li> </ul>	<ul style="list-style-type: none"> <li>◦ Fully open hot and cold water supply valves.</li> <li>◦ Clean or replace the aerator.</li> <li>◦ Flush supply lines (turn off water, disconnect lines, flush into a bucket).</li> </ul>

Problem	Possible Cause	Solution
Leaks from Faucet Base	<ul style="list-style-type: none"> <li>Loose mounting nut</li> <li>Improperly seated gasket</li> </ul>	<ul style="list-style-type: none"> <li>Tighten the mounting nut underneath the sink.</li> <li>Ensure the gasket is correctly positioned between the faucet and sink surface.</li> </ul>
Leaks from Sprayer Hose	<ul style="list-style-type: none"> <li>Loose quick connect fitting</li> <li>Damaged hose or O-rings</li> </ul>	<ul style="list-style-type: none"> <li>Ensure the Duralock quick connect is fully engaged.</li> <li>Inspect the hose and O-rings for damage; replace if necessary.</li> </ul>
Sprayer Does Not Retract Properly	<ul style="list-style-type: none"> <li>Hose weight improperly positioned or missing</li> <li>Obstruction under the sink</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the position of the hose weight.</li> <li>Clear any items obstructing the hose's movement under the sink.</li> </ul>

## 9. SPECIFICATIONS

Specification	Detail
Brand	Moen
Model Number	87557
Series ID	Brecklyn
Finish Type	Chrome
Material	Metal (Chrome)
Mounting Type	Deck Mount
Number of Handles	1
Hole Count	1 or 3 (with included deck plate)
Special Feature	Pull Out Sprayer, Power Clean Technology
Spout Height	7.8 Inches
Spout Reach	8.25 Inches
Hose Length	59 Inches
Item Weight	3 Pounds
Product Dimensions	12"D x 8"W x 7"H (approximate)
UPC	026508279618

## 10. WARRANTY AND SUPPORT

The Moen Brecklyn Faucet (Model 87557) comes with a **limited warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Moen website.

For technical assistance, replacement parts, or warranty claims, please contact Moen Customer Support directly.

- **Moen Official Website:** [www.moen.com](http://www.moen.com)
- **Customer Service:** Refer to the Moen website or product packaging for current contact information.

