



[Manuals.plus](#) /

> [XSHOT](#) /

> XSHOT Excel Fury 4 Foam Dart Blaster Model 36185 Instruction Manual

## XSHOT 36185

# XSHOT Excel Fury 4 Foam Dart Blaster Instruction Manual

Model: 36185

## INTRODUCTION

The XSHOT Excel Fury 4 is a high-performance foam dart blaster designed for rapid firing. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.

The Fury 4 features a rotating barrel, allowing you to blast 4 darts in quick succession. It is capable of hitting targets up to 27 meters (90 feet) away with accuracy. The barrel automatically rotates when the blaster is primed, ensuring a smooth firing experience.



*Image: The XSHOT Excel Fury 4 Foam Dart Blaster, ready for use.*

## **IMPORTANT SAFETY INFORMATION**

**WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.**

- Do not aim at eyes or face.
- Use only official XSHOT darts. Other darts may not meet safety standards.
- Do not modify the blaster or darts.
- Adult supervision is recommended for young users.

## **PACKAGE CONTENTS**

Verify that all items are present in your package:

- 1 x X-Shot Excel Fury-4 Dart Blaster

- 8 x X-Shot Foam Darts



*Image: The XSHOT Excel Fury 4 Blaster shown with the included 8 foam darts.*

## SETUP

### Loading Darts

1. Ensure the blaster is not primed.
2. Insert one X-Shot foam dart into each of the four openings in the rotating barrel. Push the darts in firmly until they are fully seated.



*Image: A hand demonstrating how to load a foam dart into the barrel of the XSHOT Excel Fury 4 Blaster.*

## OPERATING INSTRUCTIONS

### Firing the Blaster

1. **Load Darts:** Follow the "Loading Darts" instructions in the Setup section.
2. **Prime the Blaster:** Pull the priming handle located at the back of the blaster firmly backward until it clicks into place. The barrel will automatically rotate to the next loaded dart.
3. **Aim:** Point the blaster at your intended target, ensuring it is a safe area and not at eyes or face.
4. **Fire:** Squeeze the trigger to launch the dart.
5. **Repeat:** To fire another dart, prime the blaster again. The barrel will rotate, and you can fire the next dart.



*Image: A person holding the XSHOT Excel Fury 4 Blaster, demonstrating how it is held during operation.*

## MAINTENANCE

### Cleaning and Storage

- **Cleaning:** Wipe the blaster with a clean, damp cloth. Do not submerge in water or use harsh chemicals.
- **Dart Care:** Keep darts clean and dry. Avoid bending or damaging darts, as this can affect performance.
- **Storage:** Store the blaster and darts in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Dart does not fire or fires weakly.	Blaster not fully primed. Damaged or incorrect dart. Dart not fully inserted.	Pull priming handle back until it clicks. Use only official XSHOT darts in good condition. Ensure darts are pushed in completely.
Barrel does not rotate.	Blaster not primed correctly. Obstruction in the barrel mechanism.	Ensure priming handle is pulled back fully. Check for any foreign objects and remove them carefully.

## SPECIFICATIONS

- **Model:** 36185
- **Brand:** XSHOT (by ZURU)
- **Product Dimensions:** 11.81 x 2.56 x 7.09 inches (30 x 6.5 x 18 cm)
- **Item Weight:** 5.3 ounces (150 grams)
- **Dart Capacity:** 4 darts (rotating barrel)
- **Included Darts:** 8 X-Shot Foam Darts
- **Firing Range:** Up to 27 meters (90 feet)
- **Manufacturer Recommended Age:** 8 years and up
- **Release Date:** January 1, 2018



Image: Diagram highlighting key features of the XSHOT Excel Fury 4 Blaster, including priming mechanism, dart storage, rotating barrel, and firing range.

## WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official ZURU website or contact their customer service department. Details are typically provided on the product packaging or ZURU's official channels.

You can visit the XSHOT store for more information: [XSHOT Official Store](#)