



[Manuals.plus](#) /

› [Skip Hop](#) /

› Skip Hop Farmstand Avocado Baby Stroller Toy Instruction Manual

Skip Hop 307252

Instruction Manual

SKIP HOP FARMSTAND AVOCADO BABY STROLLER TOY

1. Product Overview

The Skip Hop Farmstand Avocado Baby Stroller Toy is designed to engage infants with its unique features. This plush toy consists of two halves that can be easily opened and closed by small hands. Inside, a clear rattle 'pit' contains colorful beads, providing auditory stimulation.

Its textured exterior and soft felt details offer tactile exploration for babies. The toy includes a built-in loop and ring for convenient attachment to strollers, infant carriers, and other baby gear.



Image 1.1: The Skip Hop Farmstand Avocado Baby Stroller Toy in its closed state, showing the plush exterior and attachment ring.

2. Safety Information

- Always inspect the toy before each use for any signs of damage or wear.
- Discontinue use if any parts become loose or broken.
- Do not leave infants unattended with the toy.
- Ensure the toy is securely attached to prevent choking hazards.
- This toy is intended for infants aged 0-1 years.

3. Setup and Attachment

To attach the Skip Hop Farmstand Avocado Baby Stroller Toy, locate the integrated loop and ring at the top of the toy. Securely fasten this ring to the bar of your stroller, infant carrier, or other compatible baby equipment. Ensure the attachment is firm to prevent accidental detachment during use.



Image 3.1: A baby interacting with the avocado stroller toy, demonstrating its attachment to a stroller bar.

4. Operating Instructions

The avocado toy features two plush halves connected by hook-and-loop fasteners. Babies can practice fine motor skills by opening and closing these halves. The clear center 'pit' contains colorful beads that produce a rattling sound when shaken, providing auditory engagement.





Image 4.1: The avocado toy opened, showing the clear rattle 'pit' with colorful beads inside.

5. Care and Maintenance

For cleaning, surface wash the toy with a mild soap and damp cloth. Allow to air dry completely. Do not immerse in water or machine wash, as this may damage the internal rattle mechanism or plush materials.

6. Troubleshooting

- **Rattle not working:** Ensure the toy is shaken gently. If no sound is produced, check for any obstructions or damage to the clear 'pit'.
- **Toy detaches easily:** Verify that the attachment ring is securely fastened to the stroller bar or carrier. Re-secure if necessary.
- For persistent issues not covered here, please refer to the support section.

7. Specifications

Product Dimensions	3.75 x 9 x 4.7 inches
Item Weight	2.4 ounces
Model Number	307252
Recommended Age	0 - 1 years
Manufacturer	Skip Hop

8. Warranty and Support

For product support, warranty information, or any inquiries regarding your Skip Hop Farmstand Avocado Baby Stroller Toy, please contact Skip Hop customer service. Visit the official Skip Hop website for the most current contact details and support resources.

You can find more information and contact options at: [Skip Hop Official Store](#)

