

[Manuals.plus](#) /

› [NOMAI](#) /

› NOMAI 88MB 5.25" Removable Hard Disk Cartridge User Manual

NOMAI 88MB

NOMAI 88MB 5.25" Removable Hard Disk Cartridge User Manual

Model: 88MB

INTRODUCTION



This manual provides comprehensive instructions for the proper use, installation, and maintenance of your NOMAI 88MB 5.25" Removable Hard Disk Cartridge. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The NOMAI 88MB 5.25" Removable Hard Disk Cartridge is a high-capacity magnetic storage medium designed for use with compatible SyQuest removable hard disk drives. It offers 88 MB of formatted storage capacity and is 100% compatible with SyQuest SQ800 cartridges and SyQuest SQ5110, SQ5100C, SQ5200 drives.

Removable Hard Disk Cartridge
100% SyQuest™ 5.25" Compatible

88MB



100% TESTED - FORMATTED - READY TO USE

Image of the NOMAI 88MB 5.25" Removable Hard Disk Cartridge packaging. The packaging highlights its compatibility with SyQuest 5.25" systems, its 88MB capacity, and states that it is 100% tested, formatted, and ready to use. A 'Five Years Worldwide Warranty' seal is also visible.

SETUP

1. Unpacking

Carefully remove the NOMAI 88MB cartridge from its packaging. Inspect the cartridge for any visible damage. Do not use the cartridge if it appears damaged.

2. Compatibility Check

Ensure your removable hard disk drive is compatible with 5.25" SyQuest SQ800 cartridges. This NOMAI cartridge is designed to be 100% compatible with SyQuest SQ5110, SQ5100C, and SQ5200 drives.

3. Insertion

With the drive powered off, gently insert the NOMAI 88MB cartridge into the compatible removable hard disk drive slot. Ensure it slides in smoothly and clicks into place, indicating proper seating.

OPERATING INSTRUCTIONS

1. Powering On

After inserting the cartridge, power on your computer system and the removable hard disk drive. The drive should recognize the NOMAI cartridge automatically.

2. Accessing Data

Once recognized, the cartridge will appear as a removable drive in your operating system. You can now access, save, and transfer files to and from the 88 MB storage space.

3. Ejecting the Cartridge

Before removing the cartridge, ensure all read/write operations are complete and the drive activity light is off. Safely eject the cartridge through your operating system's 'Safely Remove Hardware' or 'Eject' function to prevent data corruption.

Once prompted, gently remove the cartridge from the drive.

MAINTENANCE

1. Storage

Store the NOMAI 88MB cartridge in its protective case or a clean, dry, dust-free environment when not in use. Avoid exposure to extreme temperatures, humidity, or strong magnetic fields.

2. Handling

Always handle the cartridge by its edges. Avoid touching the magnetic media surface or the read/write head opening to prevent contamination and damage.

3. Cleaning

If necessary, gently wipe the exterior of the cartridge with a soft, lint-free cloth. Do not use liquid cleaners or solvents.

TROUBLESHOOTING

Cartridge Not Recognized

- Ensure the cartridge is fully inserted into the drive.
- Verify the drive is powered on and properly connected to your computer.
- Check if your operating system has the necessary drivers for the removable hard disk drive.
- Test with another compatible cartridge if available to rule out drive issues.

Data Corruption or Read/Write Errors

- Ensure the cartridge was safely ejected before removal.
- Avoid sudden power loss during data transfer.
- Check the cartridge for physical damage or contamination.
- Run a disk utility or diagnostic tool on the cartridge if supported by your system.

SPECIFICATIONS

Feature	Detail
---------	--------

Brand	NOMAI
Model	88MB
Type	Removable Hard Disk Cartridge
Capacity	88 MB
Form Factor	5.25 inches
Compatibility	100% compatible with SyQuest SQ800 cartridges and SyQuest SQ5110, SQ5100C, SQ5200 drives
UPC	767524009000

WARRANTY AND SUPPORT

The NOMAI 88MB 5.25" Removable Hard Disk Cartridge comes with a **Five Years Worldwide Warranty**. For warranty claims or technical support, please refer to the contact information provided with your purchase or visit the official NOMAI website.

For additional assistance, please contact your retailer or the manufacturer directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question