Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Smartpro microtouch Solo

Smartpro microtouch Solo Rechargeable Electric Shaver User Manual

Model: microtouch Solo | Brand: Smartpro

1. Important Safety Information

Please read all safety instructions carefully before using the Smartpro microtouch Solo electric shaver. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Water Exposure:** Avoid using the electric shaver near water, bathtubs, showers, or other liquid-filled containers.
- **Charging:** Do not use the shaver while it is connected to the charging cable. Always ensure the shaver is dry before charging.
- **Cleaning:** Clean the shaver regularly to prevent the buildup of hair and debris, which can lead to skin irritation or infections.
- **Sensitive Areas:** Exercise caution when using the shaver on sensitive skin areas or the face to avoid nicks or irritation.
- **Children:** Keep the appliance out of reach of children. This device is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- **Damage:** Do not use the shaver if the blades are damaged or if the device shows any signs of malfunction. Contact customer support for assistance.

2. Product Overview

The Smartpro microtouch Solo is a rechargeable electric shaver designed for precise beard line trimming and detailing. It features German stainless steel blades and a pivoting head for optimal contouring.



Image: The Smartpro microtouch Solo electric shaver, showcasing its compact design, pivoting head, and integrated LED light for enhanced visibility during trimming.

Key Features:

- German stainless steel blades for durability and precision.
- Multifunction shaver with built-in LED light for improved visibility.
- Pivoting head for maximum precision and contouring on various surfaces.
- Rechargeable Lithium-ion battery providing up to 45 minutes of cordless operation.
- Designed specifically for trimming and defining clean, precise beard lines.

3. What's in the Box

Your Smartpro microtouch Solo package includes the following items:

- Smartpro microtouch Solo Electric Shaver
- Cleaning Brush
- Three Trimming Combs (1 mm, 3 mm, 5 mm)
- USB Charging Cable

4. Setup

1. **Initial Charge:** Before first use, fully charge the shaver. Connect the USB charging cable to the shaver's charging port and plug the other end into a compatible USB power adapter (not included) or a computer USB port. The charging indicator (if present) will show the charging status. A full charge provides up to 45 minutes of use.
2. **Attach Trimming Comb:** Select the desired trimming comb (1 mm, 3 mm, or 5 mm) based on your preferred beard length. Align the comb with the shaver head and gently push it until it clicks into place. Ensure it is securely attached before use.

5. Operating Instructions

1. **Power On/Off:** Press the power button to turn the shaver on. Press it again to turn it off.
2. **Trimming Beard Lines:**
    - For precise lines, use the shaver without a comb guide. Hold the shaver at a slight angle against your skin.
    - Gently glide the blade along the desired beard line, moving against the direction of hair growth for a cleaner cut.
    - The built-in LED light illuminates the area, helping you achieve accurate lines.
3. **Even Trimming:**
    - Attach one of the trimming combs (1mm, 3mm, or 5mm) for an even trim.
    - Move the shaver slowly and steadily against the direction of hair growth.
    - The pivoting head will adjust to the contours of your face for consistent results.
4. **Battery Life:** The shaver provides up to 45 minutes of cordless operation on a full charge. Recharge the device when the power indicator shows low battery.

6. Maintenance

1. **Cleaning the Blades:**
    - After each use, turn off the shaver and detach any comb guide.
    - Use the provided cleaning brush to remove hair clippings from the blades and the shaver head.
    - For a more thorough cleaning, the shaver head can be rinsed under running water. Ensure the shaver body remains dry. Allow the head to air dry completely before reattaching or storing.
2. **Storing the Shaver:** Store the shaver in a cool, dry place, away from direct sunlight and moisture. Ensure it is fully charged before long-term storage to maintain battery health.
3. **Blade Care:** The German stainless steel blades are designed for longevity. Avoid dropping the shaver or exposing the blades to hard surfaces, which can cause damage.

7. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully using the USB cable.
Poor trimming performance / Does not cut hair effectively.	Blades are clogged with hair or dull.	Clean the blades thoroughly with the cleaning brush. If blades are dull, consider replacement (contact support).
Trimming combs detach during use.	Comb not securely attached or damaged.	Ensure the comb clicks firmly into place. Inspect the comb for damage; replace if necessary.
Skin irritation after shaving.	Improper technique, dirty blades, or sensitive skin.	Ensure blades are clean. Use gentle strokes. If irritation persists, consult a dermatologist.

8. Specifications

- **Brand:** Smartpro
- **Model Name:** microtouch Solo
- **Power Source:** Battery Powered (Rechargeable Lithium-ion)
- **Battery Duration:** Up to 45 minutes
- **Blade Material:** Stainless Steel (German)
- **Head Type:** Pivoting Rotary Head

- **Special Features:** Built-in LED Light, Pivoting Head
- **Recommended Use:** Beard Trimming and Detailing
- **Included Components:** Shaver, Cleaning Brush, 3 Trimming Combs (1mm, 3mm, 5mm), USB Charging Cable
- **Color:** Blue, Black

9. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact Smartpro customer service. Refer to the product packaging or the retailer's website for specific contact details.
Always retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DGDSJJ4

More documents and user manuals: **https://manuals.plus/**