

[Manuals.plus](#) /

› [BAKAJI](#) /

› BAKAJI Gazebo Replacement Canopy 3x3m Beige - Instruction Manual

BAKAJI 3x3 meters

BAKAJI Gazebo Replacement Canopy 3x3m Beige - Instruction Manual

Model: 3x3 meters

INTRODUCTION

This manual provides essential information for the proper installation, use, and maintenance of your BAKAJI 3x3 meter beige gazebo replacement canopy. Designed for durability and protection, this canopy features a windproof chimney roof, waterproof double-layer construction with polyester and PVC, and UV protection. Please read these instructions carefully before proceeding with installation to ensure optimal performance and longevity of your product.



Image: The BAKAJI 3x3m beige gazebo replacement canopy, showcasing its overall design and color. This image highlights the main product with its windproof chimney and UV protection features.

SETUP INSTRUCTIONS

This product is a replacement canopy and does not require assembly of a frame. It is designed to be installed on an existing 3x3 meter gazebo frame. While adaptable to most similar 3x3 gazebos, it is not a universal model. Ensure your gazebo frame is compatible before installation.

- 1. Prepare the Gazebo Frame:** Ensure your existing 3x3 meter gazebo frame is clean, stable, and free from any sharp edges that could damage the new canopy. Remove any old canopy material.
- 2. Unfold the Canopy:** Carefully unfold the new BAKAJI replacement canopy. Identify the top (main roof) and the smaller upper roof (chimney/ventilation part).
- 3. Install the Upper Roof:** Begin by attaching the smaller upper roof section to the designated supports on your gazebo frame. This section typically sits above the main canopy to provide ventilation and wind resistance.
- 4. Install the Main Canopy:** Drape the main 3x3 meter canopy over the gazebo frame. Align the corners and edges with the frame structure.
- 5. Secure the Canopy:** Attach the canopy to the frame using the integrated fasteners, straps, or pockets

provided on the canopy. Ensure all attachment points are securely fastened to prevent wind uplift. Distribute tension evenly to avoid stress points and ensure a taut fit.

6. **Check for Proper Fit:** Once installed, inspect the canopy to ensure it is properly stretched and secured. There should be no excessive sagging, which could lead to water pooling.



Image: A close-up view of the gazebo canopy's chimney roof design. This feature is crucial for ventilation and enhancing wind resistance, preventing the canopy from acting like a sail in gusty conditions.

OPERATING INSTRUCTIONS

The BAKAJI replacement canopy is designed for outdoor use, providing shade and protection from rain and UV rays. To ensure its effectiveness and longevity:

- **Weather Conditions:** While the canopy is waterproof and wind-resistant, it is recommended to remove it during extreme weather conditions such as heavy storms, strong winds, or significant snowfall to prevent damage to both the canopy and the gazebo frame.
- **Water Drainage:** The design helps prevent water pooling, but regularly check for any accumulation of water, especially after heavy rain. If water pools, gently push up from underneath to release it.
- **UV Protection:** The canopy offers UV protection. However, prolonged exposure to direct sunlight can still cause some fading over time, which is normal for outdoor fabrics.

- **Ventilation:** The chimney roof design facilitates air circulation, reducing heat buildup under the canopy and improving stability in breezy conditions.

MAINTENANCE AND CARE

Proper maintenance will extend the life of your BAKAJI gazebo replacement canopy.

- **Cleaning:** Clean the canopy regularly with mild soap and water. Use a soft brush or cloth to remove dirt and debris. Rinse thoroughly with clean water and allow it to air dry completely before storage or re-installation. Do not use harsh chemicals or abrasive cleaners, as these can damage the fabric and coatings.
- **Inspection:** Periodically inspect the canopy for any signs of wear, tears, or damage, especially at attachment points. Address minor issues promptly to prevent them from worsening.
- **Storage:** When not in use for extended periods, or during off-season, remove the canopy from the frame. Clean it thoroughly, ensure it is completely dry, and store it in a cool, dry place away from direct sunlight and pests.
- **Repair:** Small punctures or tears can often be repaired with a suitable fabric repair kit designed for outdoor materials. For significant damage, consider replacing the canopy.

TROUBLESHOOTING

Water Pooling on Canopy:

Issue: Water collects on the canopy surface after rain.

Solution: Ensure the canopy is installed tautly and evenly across the frame. Check that the frame itself is level and not sagging. Gently push up from underneath the pooled water to release it. If pooling persists, re-adjust the canopy tension.

Canopy Appears Loose or Sags:

Issue: The canopy does not fit snugly or sags in areas.

Solution: Verify that all attachment points (straps, pockets, ties) are securely fastened to the gazebo frame. Re-tension the canopy by adjusting these fasteners. Ensure the canopy size matches your gazebo frame (3x3 meters).

Damage from Wind:

Issue: Canopy tears or detaches during windy conditions.

Solution: Always ensure the canopy is securely fastened to the frame. For very strong winds, it is advisable to remove the canopy to prevent damage. The chimney roof design helps with wind resistance, but extreme conditions can still pose a risk.

Fading Color:

Issue: The beige color of the canopy appears to fade over time.

Solution: While the canopy has UV protection, prolonged exposure to direct sunlight will naturally cause some degree of fading in any outdoor fabric. This is generally considered normal wear and tear. Storing the canopy when not in use can help slow this process.

SPECIFICATIONS

Brand:	BAKAJI
Model/Size:	3 x 3 meters

Color:	Beige
Material:	Polyester (350 gr/sqm), PVC coating, PU reinforced double layer
Water Resistance:	Waterproof
UV Protection:	Yes
Product Dimensions:	3L x 3W x 0.3H meters (canopy only)
Item Weight:	9 Kilograms
Assembly Required:	No (for the canopy itself)

3 x 3 Mt

Telo Impermeabile Antivento



***Doppio strato rinforzato in PU
Cover TOP in poliestere e Fondo in PVC***

Image: A detailed view of the canopy's double-layer reinforced material. This shows the polyester top and the PVC bottom, highlighting the robust construction for durability and waterproofing.




Image: A close-up demonstrating the waterproof PVC layer of the canopy. This illustrates the material's ability to repel water, ensuring protection from rain.

WARRANTY INFORMATION

Specific warranty details for the BAKAJI Gazebo Replacement Canopy may vary depending on the retailer and region of purchase. Please retain your proof of purchase. For information regarding warranty coverage, terms, and conditions, please refer to the documentation provided at the time of purchase or contact the retailer directly. General consumer rights apply.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or encounter issues not covered in this manual, please contact BAKAJI customer support or your retailer. You can often find contact information on the product packaging or the brand's official website.

For more information about BAKAJI products, visit the official store: [BAKAJI Store on Amazon.it](#)

