

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Sharper Image](#) /
- › [Sharper Image 13-in-1 Tactical LED Flashlight User Manual](#)

Sharper Image SI-13IN1-FL

Sharper Image 13-in-1 Tactical LED Flashlight User Manual

Model: SI-13IN1-FL

INTRODUCTION

The Sharper Image 13-in-1 Tactical LED Flashlight is a versatile multi-tool designed for various situations, from everyday tasks to emergency preparedness. It combines a powerful LED flashlight with a comprehensive set of integrated tools, making it an essential item for home, outdoor activities, and travel.

PRODUCT FEATURES

- **Powerful LED Flashlight:** 4 white LEDs with a beam range of up to 50 meters.
- **High Brightness:** LED brightness of 15,000 - 18,000 mcd.
- **Emergency Signal Light:** Features an intermittent signal light function.
- **Integrated 13-in-1 Multi-Tool:** Includes a variety of essential tools.
- **Compact and Portable:** Ideal size for carrying in a bag or glove compartment.
- **Durable Construction:** Made from metal for longevity.

PACKAGE CONTENTS

- 1 x Sharper Image 13-in-1 Tactical LED Flashlight
- *Note: 3 AAA batteries are required and not included.*

SETUP

Battery Installation

1. Unscrew the front cap of the flashlight counter-clockwise to access the battery compartment.
2. Insert 3 AAA batteries into the compartment, ensuring correct polarity (+/-) as indicated inside.
3. Carefully screw the front cap back on clockwise until secure.



Figure 1: Open battery compartment showing where to insert 3 AAA batteries.

OPERATING INSTRUCTIONS

Flashlight Operation

Locate the slide switch on the body of the flashlight. This switch controls the flashlight's functions:

- Slide the switch to "FLASH LIGHT" for continuous white LED illumination.
- Slide the switch to "OFF" to turn off the flashlight.
- Slide the switch to "FLASH" for the intermittent red signal light.



Figure 2: The Sharper Image 13-in-1 Tactical LED Flashlight in its compact, folded state.

Using the Integrated Tools

The multi-tool section of the flashlight houses 12 additional tools. To access a tool, gently pull it outwards from its housing until it locks into place. Always exercise caution when deploying and using sharp tools.

- **Tools Included:** Fish Scaler, Hook Remover, Scissors, Phillips Screwdriver, Blade, Saw, Knife, Can Opener, File, Flathead Screwdriver, 6mm Hexagonal Wrench, 7mm Hexagonal Wrench.



Figure 3: The flashlight with all 13 tools extended, showcasing its versatility.



Figure 4: Overhead view of the multi-tool flashlight with all components deployed.

MAINTENANCE

- **Cleaning:** Wipe the flashlight and tools with a dry or slightly damp cloth. Do not use abrasive cleaners or immerse in water.
- **Lubrication:** Periodically apply a small amount of light machine oil to the tool pivots to ensure smooth operation.
- **Battery Care:** Remove batteries if the flashlight will not be used for an extended period to prevent leakage.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.

Problem	Possible Cause	Solution
Light is dim.	Low battery power.	Replace batteries.
Tools are stiff or difficult to open.	Lack of lubrication or debris.	Clean tools and apply a small amount of light machine oil to the pivots.
Red signal light stays on in "OFF" mode.	Switch malfunction.	Contact customer support for assistance.

SPECIFICATIONS

Feature	Detail
Brand	Sharper Image
Model	SI-13IN1-FL
Light Source	4 x LED (White Light)
Light Brightness	15,000 - 18,000 mcd (Candela)
Beam Range	Up to 50 meters
Power Source	3 x AAA Batteries (not included)
Material	Metal
Dimensions (L x W x H)	14 cm x 4.5 cm x 4.5 cm (5.51 in x 1.77 in x 1.77 in)
Weight (without batteries)	Approx. 146 g (0.32 lbs)
Integrated Tools	Flashlight, Fish Scaler, Hook Remover, Scissors, Phillips Screwdriver, Blade, Saw, Knife, Can Opener, File, Flathead Screwdriver, 6mm Hexagonal Wrench, 7mm Hexagonal Wrench

WARRANTY AND SUPPORT

Sharper Image products are designed with quality and performance in mind. For warranty information or technical support, please refer to the official Sharper Image website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, please visit: [Sharper Image Support](#)