Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > ROCCAT /
- > ROCCAT Vulcan TKL Mechanical PC Gaming Keyboard User Manual (Model ROC-12-274)

ROCCAT ROC-12-274

ROCCAT Vulcan TKL Mechanical PC Gaming Keyboard User Manual

Model: ROC-12-274

INTRODUCTION

This manual provides instructions for the ROCCAT Vulcan TKL Mechanical PC Gaming Keyboard, Model ROC-12-274. This tenkeyless keyboard features Titan Switch Mechanical technology, per-key AIMO RGB lighting, an anodized aluminum top plate, and a detachable USB-C cable. It is designed for PC use.



Image: Top-down view of the ROCCAT Vulcan TKL keyboard, showcasing its compact layout and illuminated keys.

SETUP

- 1. Unpack the Keyboard: Carefully remove the keyboard and its detachable USB-C cable from the packaging.
- 2. **Connect to PC:** Insert the USB-C end of the cable into the port on the back of the keyboard. Connect the standard USB-A end of the cable to an available USB port on your PC.
- 3. **Driver Installation:** Your operating system should automatically detect and install the necessary drivers. For advanced customization and features, download and install the ROCCAT Swarm software from the official ROCCAT website.



Image: Side view of the ROCCAT Vulcan TKL keyboard, illustrating the detachable USB-C cable connection point.

OPERATING INSTRUCTIONS

Key Features

- Titan Switch Mechanical: Features linear actuation for responsive keystrokes.
- Tenkeyless Form Factor: Compact design without a numeric keypad, optimizing desk space.
- AIMO Intelligent Lighting Engine: Per-key RGB lighting with customizable effects and synchronization with compatible devices.
- Mixer-Style Volume Dial: Dedicated control for audio adjustments.
- Detachable USB-C Cable: Enhances portability and simplifies cable management.

Controls and Functions

The Vulcan TKL keyboard includes dedicated media controls and a volume dial for convenient access to audio functions. Function keys (F1-F12) can be combined with the **FN** key for secondary functions, which are typically indicated by icons on the keycaps.

- Volume Dial: Located on the top right, rotate to adjust system volume.
- Media Keys: Typically accessible via FN + F-keys for playback control (play/pause, skip track).
- **Game Mode:** Activates a mode that disables the Windows key and other potentially disruptive functions during gameplay. Refer to the ROCCAT Swarm software for configuration.



Image: Angled view of the ROCCAT Vulcan TKL keyboard, highlighting the per-key RGB illumination and the dedicated volume dial.

MAINTENANCE

• Cleaning the Keyboard:

- Disconnect the keyboard from your PC before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the keycaps and aluminum top plate.
- Avoid spraying liquids directly onto the keyboard.
- Use compressed air to remove dust and debris from between the keycaps.
- Cable Care: Handle the detachable USB-C cable carefully to prevent damage to the connectors.

TROUBLESHOOTING

Issue	Possible Solution
Keyboard not responding	 Ensure the USB-C cable is securely connected to both the keyboard and the PC. Try connecting the keyboard to a different USB port on your PC. Restart your computer. Check if the keyboard is recognized in your PC's Device Manager.
Keys are not registering or double- typing	 Ensure the keyboard is clean and free of debris under the keycaps. Update the keyboard firmware using the ROCCAT Swarm software. Reinstall the ROCCAT Swarm software.
RGB lighting not working or incorrect	 Ensure ROCCAT Swarm software is running and updated. Check lighting settings within the Swarm software. Perform a factory reset of the keyboard (refer to Swarm software or ROCCAT support for instructions).

SPECIFICATIONS

Feature	Detail
Brand	ROCCAT
Model Number	ROC-12-274
Hardware Platform	PC
Connectivity Technology	USB-C (Detachable)
Keyboard Type	Mechanical Gaming Keyboard (Tenkeyless)
Switch Type	Titan Switch Mechanical (Linear)
Lighting	Per-key AIMO RGB Lighting
Material	Anodized Aluminum Top Plate
Color	Black
Product Dimensions (LxWxH)	14.17 x 5.25 x 1.34 inches (36 x 13.3 x 3.4 cm)
Item Weight	2.2 pounds (1 kg)
Included Components	USB Cable

WARRANTY AND SUPPORT

For warranty information, technical support, or to download the latest ROCCAT Swarm software and firmware updates, please visit the official ROCCAT support website. You can also find additional resources and FAQs there.

Official ROCCAT Store: ROCCAT Store on Amazon





ROCCAT Vulcan AIMO Keyboard: Speed, Durability, and Illumination

Discover the ROCCAT Vulcan AIMO keyboard, featuring Titan Switches for enhanced speed and precision, durable construction with an aluminum plate, and AIMO intelligent lighting for a vivid gaming aesthetic. Includes quick installation guide and product information.



ROCCAT Vulcan AIMO Mechanical Gaming Keyboard Quick Installation Guide

A quick installation guide for the ROCCAT Vulcan AIMO mechanical gaming keyboard, detailing setup, features like Titan Switches and AIMO lighting, and software installation.



ROCCAT Kone Aimo Gaming Mouse Quick Installation Guide

A quick installation guide for the ROCCAT Kone Aimo gaming mouse, detailing its features like Easy-Shift[+]TM, Aimo Lighting System, and Owl-Eye optical sensor, along with button assignments and multilingual setup instructions.



ROCCAT Kain 120/122 AIMO Quick Installation Guide

A quick installation guide for the ROCCAT Kain 120/122 AIMO gaming mouse, detailing setup, technical specifications, and safety information.

