

[Manuals.plus](#) /

› [MIABOO](#) /

› MIABOO Mini Bluetooth Speaker Instruction Manual (Model: M23)

MIABOO M23

MIABOO Mini Bluetooth Speaker Instruction Manual

MODEL: M23

Your guide to setting up, operating, and maintaining your MIABOO Mini Bluetooth Speaker.

Introduction

The MIABOO Mini Bluetooth Speaker (Model M23) is a compact, portable wireless speaker designed for high-quality audio on the go. Featuring Bluetooth 4.1 technology, it offers easy pairing with various devices and supports dual speaker connection for stereo sound. Its durable metal body is designed to be shockproof and dustproof, making it suitable for both indoor and outdoor use.

This manual provides detailed instructions to help you get the most out of your speaker, from initial setup to advanced features and troubleshooting.



Image: The MIABOO Mini Bluetooth Speaker, demonstrating its compact and portable design when held in a hand.

Package Contents

Please check the package for the following items:

- MIABOO Mini Bluetooth Speaker (Model M23)
- USB Charging Cable
- User Manual

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and the other end to a USB power source (e.g., computer, USB wall adapter). The LED indicator will show charging status. A

full charge typically takes approximately 2 hours.

2. Powering On/Off

- **To Power On:** Press and hold the power button (usually marked with a power symbol) for a few seconds until you hear an audible prompt or see the LED indicator light up.
- **To Power Off:** Press and hold the power button again for a few seconds until you hear an audible prompt or the LED indicator turns off.

Operating Instructions

1. Bluetooth Pairing (Single Speaker)

1. Ensure the speaker is powered on and in pairing mode. The LED indicator will typically flash blue rapidly.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices. The speaker will appear as "MIABOO M23" or a similar name.
4. Select the speaker from the list to connect. Once connected, you will hear a confirmation sound, and the LED indicator will typically show a solid blue light or flash slowly.
5. If prompted for a password, enter "0000".

MINI SPEAKER

Sound Beyond Size





Image: The MIABOO Mini Bluetooth Speaker paired with a smartphone, illustrating its use with mobile devices.

2. Dual Speaker Connection (Stereo Sound)

For an enhanced audio experience, you can pair two MIABOO M23 speakers together to create a stereo sound system.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be your primary speaker), double-press the power button. You will hear a prompt indicating it is searching for another speaker.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation sound.
4. Now, on your device, search for Bluetooth devices and connect to the primary speaker (e.g., "MIABOO M23"). Both speakers will now play audio in stereo.



Model No.: M23

Bluetooth Version: 4.1

Bluetooth Range: 10M

Frequency Response: 100 Hz - 20 KHz

Output Power: 3 Watts

Signal To Noise Ratio: 75 dB

Playback Time (Approx): 5 Hours

Battery Charge Time (Approx): 2 Hours

Item Weight: 0.15 lb (68g)

Dimensions: 1.6 x 1.6 x 1.8 inches(41*41*46mm)

Image: Two MIABOO Mini Bluetooth Speakers configured for stereo sound, demonstrating the dual connection feature.

3. Playing Audio

Once connected via Bluetooth, simply start playing audio from your paired device. The sound will be transmitted to the MIABOO Mini Bluetooth Speaker(s).

4. Hands-Free Calling

When connected to a smartphone, the speaker can be used for hands-free calls. Incoming calls will be routed through the speaker. Press the power button once to answer a call, and press it again to end a call.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

- **Water Resistance:** While the speaker features a durable metal body designed to be shockproof and dustproof, it is not explicitly stated as waterproof. Avoid submerging it in water or exposing it to heavy rain.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the speaker is fully charged. Connect it to a power source using the USB cable.
Cannot pair with Bluetooth device.	◦ Ensure the speaker is in pairing mode (flashing blue LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device (within 10 meters). ◦ Turn off and on both the speaker and your device's Bluetooth. ◦ Forget the speaker from your device's Bluetooth list and try pairing again.
No sound or low volume.	◦ Increase the volume on both the speaker and your connected device. ◦ Ensure the speaker is properly paired and connected. ◦ Check if the audio source on your device is playing.
Dual connection not working.	◦ Ensure both speakers are powered on and not connected to any other device. ◦ Follow the dual speaker pairing instructions carefully. ◦ Try resetting both speakers by powering them off and on.

Specifications



Image: Detailed technical specifications and dimensions of the MIABOO Mini Bluetooth Speaker (Model M23).

Feature	Detail
Model No.	M23
Output Power	3W
Battery Capacity	1000mAh
Playing Time	Approx. 5 hours
Chatting Time	Approx. 2 hours
Working Range	10 meters (33 feet)
Weight	70g
Bluetooth Version	4.1

Feature	Detail
Bluetooth Profile	A2DP1.2, AVRCP1.0
Frequency Response	100Hz-20KHz
Signal-To-Noise Ratio	75dB
Distortion	1.0%
Dimensions (LxWxH)	41 x 41 x 46 mm (1.6 x 1.6 x 1.8 inches)
Material	Metal
Control Method	Touch
Power Source	Battery Powered

Warranty and Support

MIABOO provides a **2-Year warranty** for the Mini Bluetooth Speaker (Model M23) from the date of purchase. This warranty covers manufacturing defects and ensures reliable performance under normal use. Additionally, we offer **3-month worry-free technical support** to assist you with any questions or issues you may encounter during the initial period of use.

For warranty claims, technical assistance, or any other inquiries, please contact MIABOO customer support through the retailer where you purchased the product or refer to the contact information provided on the official MIABOO website (if available).

Please retain your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07DJ62ZVW>

More documents and user manuals: <https://manuals.plus/>