

ECG SM 3510 Mix&Go

ECG SM 3510 Mix&Go Mini Blender Smoothie User Manual

Model: SM 3510 Mix&Go | Brand: ECG

1. IMPORTANT SAFETY INFORMATION

Please read this instruction manual carefully before using the appliance and keep it for future reference. Improper use may result in injury or damage to the appliance.

- Always ensure the appliance is unplugged from the power outlet before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the blending jar while blending to prevent severe injury and/or damage to the blender.
- The blades are sharp. Handle the blade assembly with extreme care.
- Do not operate the blender if the cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Do not overload the blender. Refer to the 'Operating Instructions' section for proper filling.
- The appliance is equipped with overheating protection. If it stops working, unplug it and let it cool down for at least 15 minutes before resuming use.

2. PRODUCT OVERVIEW AND COMPONENTS

The ECG SM 3510 Mix&Go Mini Blender Smoothie consists of a motor base, a blade assembly, a 600 ml blending bottle, and a drinking lid.



Image: All components of the ECG SM 3510 Mix&Go Mini Blender Smoothie, including the motor base, blade assembly, 600ml bottle, and drinking lid.

1. **Motor Base:** Contains the 350W motor and control mechanism. Features non-slip feet for stability.
2. **Blade Assembly:** Flat stainless steel chopping knife for efficient blending.
3. **600 ml Blending Bottle:** Made from durable, BPA-free Tritan plastic. Doubles as a portable drinking bottle.
4. **Drinking Lid:** Secure lid for the blending bottle, allowing for easy transport and consumption of your blended drinks.

3. SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or disposal.
2. **Initial Cleaning:** Before first use, wash the blending bottle, blade assembly, and drinking lid in warm, soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.
3. **Placement:** Place the motor base on a clean, dry, and stable surface. Ensure it is away from the edge of the countertop and out of reach of children.
4. **Power Connection:** Ensure the blender is unplugged before proceeding with ingredient preparation.



Image: The ECG SM 3510 Mix&Go Mini Blender Smoothie with the empty 600ml bottle attached to the motor base, ready

4. OPERATING INSTRUCTIONS

The ECG SM 3510 Mix&Go Mini Blender is designed for simple and efficient blending of smoothies, cocktails, and other beverages.

1. **Prepare Ingredients:** Cut fruits and vegetables into small pieces (approximately 2-3 cm) to ensure optimal blending.
2. **Fill the Bottle:** Add your ingredients to the 600 ml blending bottle. Do not exceed the maximum fill line indicated on the bottle. For best results, add liquids first, then soft ingredients, and finally harder ingredients or ice.



Image: The 600ml blending bottle filled with various fruits, ready for the blade assembly to be attached.

3. **Attach Blade Assembly:** Screw the blade assembly firmly onto the open end of the blending bottle. Ensure it is securely tightened to prevent leaks.
4. **Place on Motor Base:** Invert the bottle (with the blade assembly facing down) and place it onto the motor base. Align the tabs on the bottle with the slots on the base.
5. **Blend:** Plug the blender into a power outlet. To start blending, press and hold the button on the motor base. For continuous blending, you may need to lock the button in place (refer to specific model instructions if applicable, otherwise hold). For pulse blending, press and release the button repeatedly. Blend until desired consistency is achieved. The blender operates at 22,000 RPM for

quick results.



Image: The ECG SM 3510 Mix&Go Mini Blender Smoothie with the contents fully blended into a smooth consistency.

- 6. Remove and Enjoy:** Once blending is complete, release the button and unplug the blender. Carefully lift the bottle from the motor base. Unscrew the blade assembly and replace it with the drinking lid.



Image: The 600ml blending bottle with the drinking lid attached, ready for transport or immediate consumption.

5. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your blender.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Clean Bottle and Lid:** The 600 ml blending bottle and drinking lid are dishwasher safe. Alternatively,

wash them by hand with warm, soapy water and rinse thoroughly.

- Clean Blade Assembly:** Carefully wash the blade assembly by hand using warm, soapy water. Use a brush to remove any food residue. Rinse thoroughly. *Exercise extreme caution as the blades are very sharp.*
- Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid. Do not use abrasive cleaners or scouring pads.
- Dry and Store:** Ensure all parts are completely dry before reassembling or storing the blender. Store in a cool, dry place.

6. TROUBLESHOOTING

If you encounter issues with your ECG SM 3510 Mix&Go Mini Blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Not plugged in; bottle not correctly assembled on base; overheating.	Check power connection; ensure bottle is securely twisted onto the base; unplug and let cool for 15 minutes if overheated.
Ingredients are not blending smoothly.	Too little liquid; too many ingredients; ingredients are too large.	Add more liquid; reduce the amount of ingredients; cut ingredients into smaller pieces. Use pulse function for tough ingredients.
Leakage from the bottle.	Blade assembly not tightened properly; bottle overfilled.	Ensure blade assembly is securely screwed onto the bottle; do not fill past the maximum fill line.
Burning smell during operation.	Overloading the motor; new motor smell.	Unplug immediately and allow to cool. Reduce load. A slight burning smell can be normal for new motors during initial uses. If it persists or is strong, discontinue use and contact support.

7. TECHNICAL SPECIFICATIONS

Detailed specifications for the ECG SM 3510 Mix&Go Mini Blender Smoothie:

Model Number	SM 3510 Mix&Go
Brand	ECG
Power	350 Watts
Voltage	220 Volts

Capacity	600 Milliliters
Number of Speeds	1
Blade Material	Stainless Steel
Bottle Material	BPA-free Tritan Plastic
Product Dimensions (L x W x H)	11.5 x 11.5 x 37 cm
Item Weight	1 Kilogram
Dishwasher Safe Parts	Bottle, Lid
Special Feature	Lightweight, Overheating Protection, Non-slip feet
Recommended Use	Smoothie, Cocktails, Drinks, Baby Food

8. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or contact ECG customer support.

For technical assistance, spare parts, or any other inquiries, please visit the official ECG website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.
