

Elica EPBI 1060 DMF

Elica EPBI 1060 DMF Built-in Oven User Manual

Model: EPBI 1060 DMF | Brand: Elica (Manufactured by Interio World)

1. INTRODUCTION

Welcome to the user manual for your new Elica EPBI 1060 DMF Built-in Oven. This guide provides essential information for the safe and efficient use of your appliance. Please read all instructions carefully before installation and operation, and retain this manual for future reference.

1.1 Safety Instructions

- **Electrical Safety:** Ensure the oven is correctly installed by a qualified technician and connected to a properly grounded electrical outlet. Do not use extension cords.
- **Hot Surfaces:** The oven and its accessories become very hot during operation. Always use oven mitts when handling hot items. Keep children and pets away from the appliance.
- **Ventilation:** Ensure adequate ventilation around the built-in oven as specified in the installation guidelines.
- **Cleaning:** Always disconnect the oven from the power supply before cleaning.
- **Supervision:** Do not leave the oven unattended during operation, especially when using high temperatures or the grill function.

2. PRODUCT OVERVIEW

The Elica EPBI 1060 DMF is a 70-liter electric multifunction built-in oven designed for modern kitchens. It features a sleek matte black finish and a user-friendly control panel.



Front view of the Elica EPBI 1060 DMF Built-in Oven, showing the control panel with two rotary knobs, a digital display, and the oven door with a large viewing window.

2.1 Key Features

- **Capacity:** 70 Liters, providing ample space for various cooking needs.
- **Control Panel:** Features two rotary knobs for function and temperature selection, along with a digital electronic clock timer for precise control.
- **Interior Light:** One interior light located at the top of the oven for clear visibility of cooking progress.
- **Cooling Fan:** Integral cooling fan to maintain external surface temperatures.
- **Convection Fan:** Ensures even heat distribution for consistent cooking results.
- **Cavity:** Internal cavity with enamelled coating for easy cleaning.
- **Grill:** Drop-down grill for better access and simplified cleaning.
- **Electronic Clock Timer:** Functions for 'On', 'Off', and 'Alarm'.
- **Thermostat:** Adjustable up to 250 degrees Celsius.

3. INSTALLATION

The Elica EPBI 1060 DMF is a built-in appliance. Professional installation is highly recommended to ensure proper fitting, electrical connection, and ventilation.

3.1 Dimensions and Requirements

- **Overall Dimensions (W*D*H):** 595 mm * 575 mm * 598 mm.
- **Installation Type:** Built-In. Refer to the separate installation template for precise cabinet cutout dimensions.
- **Material:** Steel.
- **Finish Type:** Matte Black.

- **Electrical Connection:** The oven requires a dedicated, grounded electrical circuit. Consult a qualified electrician for connection.

Ensure sufficient space for air circulation around the oven to prevent overheating and ensure efficient operation.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the control panel before operating the oven.

4.1 Control Panel Overview

The control panel typically consists of:

- **Function Selector Knob:** Used to select the desired cooking mode (e.g., Convection, Grill).
- **Temperature Selector Knob:** Used to set the desired cooking temperature, up to 250°C.
- **Digital Display:** Shows time, temperature, and timer settings.
- **Timer Buttons:** For setting the electronic clock timer functions (On, Off, Alarm).

4.2 Basic Operation

1. **Preheating:** Turn the Function Selector Knob to the desired cooking mode and the Temperature Selector Knob to the desired temperature. Allow the oven to preheat until the indicator light turns off or the display shows the set temperature has been reached.
2. **Setting Temperature:** Rotate the Temperature Selector Knob to select a temperature between 50°C and 250°C.
3. **Using the Timer:** Use the timer buttons to set the cooking duration (Off), a delayed start (On), or an audible alarm. Refer to the detailed timer section in the full manual for specific programming steps.
4. **Oven Light:** The oven interior light stays on while the oven is in use, providing visibility of your food.
5. **Convection Cooking:** Select the convection function for even heat distribution, ideal for baking and roasting multiple dishes simultaneously.
6. **Grill Function:** For grilling, select the grill function. The drop-down grill allows for easier placement and removal of food. Monitor food closely to prevent burning.
7. **Turning Off:** Once cooking is complete, turn both selector knobs to the 'Off' position.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your oven.

5.1 General Cleaning

- **Before Cleaning:** Always ensure the oven is cool and disconnected from the power supply.
- **Exterior:** Clean the exterior surfaces with a soft cloth and mild detergent. Avoid abrasive cleaners or scouring pads that can damage the matte black finish.
- **Interior Cavity:** The enamelled coating of the internal cavity makes cleaning easier. Use a damp cloth and a non-abrasive oven cleaner. For stubborn stains, follow the instructions of your chosen oven cleaner.
- **Drop-Down Grill:** The grill element can be dropped down for better access to the oven ceiling for cleaning. Ensure it is securely returned to its position before operating the oven.
- **Oven Door:** Clean the glass door with a glass cleaner. Do not immerse the door in water.

5.2 Care Tips

- Avoid spilling liquids directly onto the control panel.
- Do not use sharp objects to remove food residue, as this can scratch the enamel.

6. TROUBLESHOOTING

If you encounter issues with your oven, refer to the following common troubleshooting steps. For problems not listed here, contact customer support.

- **Oven Not Heating:** Check if the oven is properly plugged in and the circuit breaker has not tripped. Ensure the function and temperature knobs are correctly set.
- **Uneven Cooking:** Ensure food is placed centrally and not overcrowding the oven. Verify that the convection fan is operating.
- **Timer Not Working:** Check if the clock is set correctly. Ensure the timer function is activated as per the operating instructions.
- **Oven Light Not Working:** The bulb may need replacement. Ensure the oven is disconnected from power before attempting to replace the bulb.

7. SPECIFICATIONS

Feature	Specification
Model Number	EPBI 1060 DMF
Part Number	EPBI1060-14
Capacity	70 Liters
Dimensions (W*D*H)	595 mm * 575 mm * 598 mm
Installation Type	Built-In
Primary Material	Steel
Finish Type	Matte Black
Color	Black
Heating Method	Convection
Thermostat	Up to 250°C
Manufacturer	Interio World
ASIN	B07DKWLG5S
Date First Available	7 June 2018



8. WARRANTY AND SUPPORT

For warranty information, technical support, or service requests, please contact the manufacturer, Interio World, or your authorized dealer. Keep your purchase receipt and model details handy when contacting support.


Manufacturer: Interio World

© 2023 Elica / Interio World. All rights reserved.

Related Documents - EPBI 1060 DMF

	<p><u>Manuale Elica SKYDOME-PLUS-30: Installazione, Uso e Manutenzione</u></p> <p>Scopri come installare, utilizzare e mantenere la tua cappa da cucina Elica SKYDOME-PLUS-30 con questa guida completa. Include istruzioni di sicurezza, consigli per l'efficienza e informazioni sulla connettività.</p>
	<p><u>Elica 2022: 4D Living Experience - Konyhai Készülékek Katalógusa</u></p> <p>Fedezze fel az Elica 2022 kollekcióját, innovatív konyhai páraelszívókkal, integrált főzőlapokkal és szellőztető rendszerekkel. Ismerje meg a 4D Living Experience élményt az Elica technológia, dizájn és funkcionális ötvözetével a modern otthonok számára.</p>
	<p><u>Elica Range Hoods: Comprehensive Use, Care, and Installation Guide</u></p> <p>This guide provides essential information for the safe and effective use, care, and installation of Elica range hoods, including models EMZ630S3, EMZ636S3, ETB424SS, ETB430S2, and ETB436S2. It covers safety, installation, operation, maintenance, and warranty details.</p>
	<p><u>Elica Aria Nuova: Manuale di Installazione e Uso</u></p> <p>Manuale completo per la cappa da cucina Elica Aria Nuova. Fornisce istruzioni dettagliate per l'installazione, l'uso, la manutenzione e la sicurezza, oltre a informazioni sulle funzionalità WiFi e il sensore VOC. Disponibile in più lingue.</p>

Documents - Elica – EPBI 1060 DMF



[pdf] User Manual

user manual epbi 1060 dmf elica sites default files upload forni |||

■ ■ ■

lang: score:37 filesize: 1 M page_count: 0 document date: 0000-00-00



[\[pdf\]](#) User Manual

user manual EPBI 1060 DMF epbi dmf 0 elica com cdn immedia net sites default files upload forni |||

■ ■ ■

lang: score:32 filesize: 7.05 M page_count: 8 document date: 2017-05-11