

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Uten](#) /
- › [Uten Digital Kitchen Scale User Manual](#)

### Uten US-U-HKW014-X01

# Uten Digital Kitchen Scale Instruction Manual

MODEL: US-U-HKW014-X01

## 1. Introduction

Thank you for choosing the Uten Digital Kitchen Scale. This ultra-slim, multifunction scale is designed for precise food weighing in your kitchen. Featuring a durable stainless steel platform, a clear back-lit LCD display, and multiple measurement modes, it simplifies your cooking and baking tasks. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Figure 1: Uten Digital Kitchen Scale with a bowl of fresh vegetables, demonstrating its use for weighing ingredients.

## 2. What's in the Box

- 1 x Uten Electronic Kitchen Scale
- 2 x 1.5V AAA Batteries (Panasonic)
- 1 x User Instruction Manual

## 3. Product Features

- **High-Quality Construction:** SUS401 high-quality stainless steel platform and ABS plastic frame for durability and easy cleaning.
- **Slim Design with Hook:** Lightweight, compact, and features a hook for convenient hanging storage when not in use.
- **Back-Lit LCD Display:** Large 2.87 x 1.02 inch high-contrast display with blue back-light for easy readability.

- **High Precision Sensor:** Built with a high precision strain gauge sensor, weighing up to 11lb/5kg with a graduation of 1g/0.1oz.
- **Multiple Measurement Modes:** Supports 4 measurement modes including kilograms (kg), grams (g), ounces (oz), and pounds (lb:oz).
- **Volume Indication:** Measures water and milk volume in milliliters (ml) and fluid ounces (fl'oz).
- **Zero & Tare Function:** Allows for weighing different loads consecutively without removing the previous load.
- **Alarm Timer & Real-Time Clock:** Integrated timer and clock display for added kitchen convenience.
- **Temperature Sensor:** Displays ambient temperature.
- **Warning Indicators:** Includes low battery and overload indications.



Figure 2: The scale's large platform and slim design, ideal for various kitchen tasks and easy storage.

## 4. Setup

### 4.1. Battery Installation

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert the two 1.5V AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

#### 4.2. Placement

For accurate readings, always place the scale on a flat, hard, and stable surface. Avoid soft surfaces like carpets or uneven countertops.

## 5. Operating Instructions

### 5.1. Power On/Off

Press the **ON/OFF** button to turn the scale on. The back-lit LCD display will illuminate, and the scale will enter weighing mode, typically displaying "0.0". To turn off the scale, press and hold the **ON/OFF** button for a few seconds.

### 5.2. Unit Conversion

With the scale on, press the **UNIT** button to cycle through the available measurement units: grams (g), kilograms (kg), pounds (lb:oz), milliliters (ml), and fluid ounces (fl'oz). A long press on the **UNIT** button can switch between metric and imperial systems for temperature display.

# 4 UNITS CONVERSION: WEIGHT & VOLUME



Figure 3: Visual representation of the four unit conversion options available on the scale's display.

## 5.3. Zero/Tare Function

The **ZERO/TARE** button allows you to reset the display to zero, effectively subtracting the weight of a container or previous ingredients. This is useful for weighing multiple ingredients in the same bowl.

1. Place an empty container on the scale. The display will show its weight.
2. Press the **ZERO/TARE** button. The display will reset to "0.0".
3. Add your ingredient to the container. The display will show only the weight of the added ingredient.

## ZERO & TARE FUNCTION

To weigh different loads consecutively without removing loads from the scale.



### STEP 1

put the container/ bowl on the scale



### STEP 2

press the Z/T button to zero



### STEP 3

put the item on the container

Figure 4: Step-by-step guide illustrating how to use the Zero/Tare function for accurate ingredient measurement.

### 5.4. Alarm Timer and Clock

The **T-SET** button functions as both a timer and a clock. In idle standing mode, the scale displays time and temperature. To set the timer, simply click **T-SET**; the clock display in the upper right-hand corner will begin to flicker. Adjust the desired stop time using the **ZERO/TARE** (up) or **UNIT** (down) buttons. The timer will count down and sound an alarm when finished.



Figure 5: The scale's alarm timer feature, useful for cooking and other timed kitchen activities.

## 5.5. Video Demonstration: Key Features

Your browser does not support the video tag.

Video 1: An official demonstration of the Uten Digital Kitchen Scale, highlighting its features such as power on/off, unit conversion, and the zero/tare function. This video provides a visual guide to operating the scale's main controls.

## 6. Care and Maintenance

- **Cleaning:** The stainless steel platform is fingerprint resistant and easy to clean. Use a slightly damp cloth to remove residue or fingerprints. Do not use abrasive cleaners.
- **Avoid Immersion:** Do not immerse the scale in water or any other liquid.
- **Keep Dry:** Ensure the scale is dry after cleaning to prevent damage to electronic components.
- **Handle with Care:** Do not strike or drop the scale, as this can affect its accuracy and functionality.
- **Storage:** Utilize the integrated hook for convenient hanging storage, keeping the scale safe and accessible.



Figure 6: Demonstrating the ease of cleaning the scale's fingerprint-resistant stainless steel surface.

## 7. Troubleshooting

- **"Lo" or "Err" Display:** This indicates low battery. Replace the two 1.5V AAA batteries.
- **"O-Ld" Display:** This indicates an overload. The maximum weight capacity is 11lb (5kg). Remove items immediately to prevent damage.
- **Inaccurate Readings:** Ensure the scale is placed on a flat, stable surface. Avoid placing it near strong electromagnetic fields or extreme temperature changes. Recalibrate if necessary by turning it off and on.
- **Display Not Turning On:** Check battery installation and ensure batteries are not depleted.

## 8. Specifications

Specification	Detail
Product Dimensions	9.25 x 1.06 x 6.5 inches
Item Weight	1.29 Pounds
Item Model Number	US-U-HKW014-X01
Manufacturer	Uten
Color	Silver
Recommended Uses	Food Weighing
Special Features	Alarm Timer, Temperature Sensor, Water/Milk Volume Indicator, Auto Shut Off, Tare Function
Display Type	LCD (Back-Lit)
Max Capacity	11lb / 5kg
Graduation	1g / 0.1oz
Temperature Range	0-40°C or 0°F to 104°F

## 9. Warranty and Support

The Uten Digital Kitchen Scale comes with an extended 12-month warranty. For any product inquiries, technical support, or warranty claims, please contact Uten customer service through the retailer's platform or the official Uten website. Please retain your purchase receipt as proof of purchase for warranty purposes.