

[Manuals.plus](#) /

› [Sun Joe](#) /

› Sun Joe SPX2598 14.5-Amp Electric Pressure Washer User Manual

Sun Joe SPX2598

Sun Joe SPX2598 14.5-Amp Electric Pressure Washer User Manual

Model: SPX2598 | Brand: Sun Joe

INTRODUCTION

This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Sun Joe SPX2598 14.5-Amp Electric Pressure Washer. Please read this manual thoroughly before initial use and retain it for future reference.

IMPORTANT SAFETY INFORMATION


WARNING:

- Always wear appropriate personal protective equipment, including safety glasses, when operating the pressure washer.
- Ensure the power cord and plug are in good condition and connected to a properly grounded outlet.
- Do not direct the water stream at people, pets, electrical devices, or the unit itself.
- Keep children and bystanders away from the operating area.
- Always disconnect the power supply before performing any maintenance or cleaning.
- Do not operate the unit if any parts are damaged or missing.
- Use only clean water as the water supply.

PRODUCT OVERVIEW

The Sun Joe SPX2598 is a powerful 14.5-Amp electric pressure washer designed for light to medium-duty cleaning tasks around your home, auto, porch, and patio. It features a Total Stop System (TSS) for energy saving and prolonged pump life, and an adjustable spray wand for versatile cleaning.

Components







Front view of the Sun Joe SPX2598 Electric Pressure Washer, highlighting its compact design and main controls.





Side view of the Sun Joe SPX2598, showing the integrated hose reel and handle for easy transport.

Key components include the main unit with motor, high-pressure hose, spray wand with adjustable nozzle, and onboard detergent tank.

SETUP

Assembly

Your Sun Joe SPX2598 requires minimal assembly. Attach the handle, wheels, and any accessory holders using the provided screws and a Philips screwdriver. Ensure all connections are secure before proceeding.

Connecting Water Supply

1. Connect a standard garden hose (not included) to the water inlet on the pressure washer. Ensure the connection is tight to prevent leaks.
2. Connect the high-pressure hose to the outlet on the pressure washer and to the spray gun.
3. Turn on the water supply completely.
4. Squeeze the trigger on the spray gun to purge air from the system until a steady stream of water emerges.



The Sun Joe SPX2598 pressure washer fully assembled and ready for use on a paved surface.

OPERATING INSTRUCTIONS

Starting the Unit

1. Ensure the water supply is fully open and air has been purged from the system.
2. Plug the pressure washer into a grounded electrical outlet.
3. Turn the ON/OFF switch to the "ON" position. The motor will start briefly and then shut off due to the Total Stop System (TSS).
4. Squeeze the trigger on the spray gun to begin operation. The motor will run only when the trigger is engaged.

Adjusting Pressure and Spray Pattern

The SPX2598 features an adjustable spray wand. Simply twist the nozzle to change the spray pattern from a punishing pinpoint jet to a powerful fan spray, allowing you to tackle various cleaning tasks with ease.



A user demonstrating the pressure washer's effectiveness on outdoor furniture, showcasing the adjustable spray.

Using the Detergent Tank

For enhanced cleaning, fill the 33.8 fl oz (1 liter) onboard detergent tank with your preferred pressure washer-safe detergent. The detergent will be automatically mixed with the water stream when using a low-pressure spray setting.



A detailed view of the integrated detergent tank on the Sun Joe SPX2598, showing its capacity and fill cap.

Product Demonstration Video

Your browser does not support the video tag.

Official demonstration video showcasing the features and operation of the Sun Joe SPX2598 pressure washer.

MAINTENANCE

Cleaning

After each use, disconnect the water supply and power. Squeeze the trigger to release any remaining pressure. Wipe down the unit with a damp cloth. Do not use harsh chemicals or abrasive cleaners.

Storage

Store the pressure washer in a dry, frost-free area. Drain all water from the pump, hose, and spray gun to prevent

damage from freezing. Coil the high-pressure hose and power cord neatly. The unit's compact design allows for easy storage.



Size comparison of the Sun Joe SPX2598 pressure washer, illustrating its compact and portable nature for easy storage.

TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Motor does not start	Power cord not plugged in; GFCI tripped; No power at outlet.	Check power connection; Reset GFCI; Check circuit breaker.
Low pressure	Insufficient water supply; Air in pump; Clogged nozzle.	Ensure water tap is fully open; Purge air from system; Clean nozzle.
Water leaks	Loose connections; Damaged O-rings.	Tighten connections; Replace O-rings if damaged.
Detergent not dispensing	Detergent tank empty; Nozzle not on low-pressure setting.	Fill detergent tank; Adjust nozzle to low-pressure setting.

SPECIFICATIONS

Feature	Detail
Model	SPX2598
Motor	14.5-Amp
Maximum Pressure	2000 PSI
Maximum Flow Rate	1.6 GPM
Hose Length	20 Feet
Detergent Tank Volume	33.8 fl oz (1 Liter)
Item Weight	16.8 Pounds
Product Dimensions (L x W x H)	13.78" x 12.64" x 19.69"
Technology	Total Stop System (TSS)

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official user guide provided by Sun Joe. You can often find the most current version of the user guide on the manufacturer's website or via the link below:

[Download Official User Guide \(PDF\)](#)

For further assistance, contact Sun Joe customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07DLNWJBP>

More documents and user manuals: <https://manuals.plus/>