

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [allen + roth](#) /

› [allen + roth 20272-000 Sloan 6-Light Dimmable LED Flexible Track Light Instruction Manual](#)

allen + roth 20272-000 Sloan 6-Light

allen + roth 20272-000 Sloan 6-Light Dimmable LED Flexible Track Light

Instruction Manual

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup & Installation](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the allen + roth 20272-000 Sloan 6-Light Dimmable LED Flexible Track Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.

This flexible track lighting system features six integrated LED light heads, offering adjustable directional lighting and dimming capabilities. Its flexible design allows for customization to suit various room layouts.

2. IMPORTANT SAFETY INFORMATION

WARNING: Risk of electric shock. Disconnect power at the circuit breaker or fuse box before installation or servicing. Improper installation can result in electric shock or fire.

- Read and understand all instructions before proceeding.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Do not install this fixture in wet or damp locations. This product is intended for indoor use only.
- Ensure the mounting surface is structurally sound and can support the weight of the fixture.
- Do not attempt to modify the fixture or its components.
- Do not look directly into the LED light source when illuminated.
- Use only with compatible dimmers as specified by the manufacturer.

3. PACKAGE CONTENTS

Carefully unpack the fixture and check that all parts are present. If any parts are missing or damaged, do not attempt to assemble or install the product. Contact customer service for assistance.

- Flexible Track Rail (1)
- Integrated LED Light Heads (6)
- Mounting Hardware Kit (screws, anchors, wire connectors)
- Canopy/Junction Box Cover (1)
- Remote Control (1)
- Instruction Manual (1)



Image 1: Overview of the allen + roth Sloan 6-Light Flexible Track Light kit, showing the flexible rail and six integrated LED light heads.

4. SETUP & INSTALLATION

Tools Required (Not Included):

- Phillips Head Screwdriver
- Wire Strippers
- Drill with appropriate drill bits
- Pencil
- Safety Glasses

Installation Steps:

1. **Turn Off Power:** Before starting, ensure the power to the circuit at the circuit breaker or fuse box is completely OFF.
2. **Prepare Mounting Surface:** Determine the desired layout for your flexible track. Mark the mounting points on the ceiling or wall where the track will be secured. Ensure these points align with a junction box for electrical connection.
3. **Mount the Track:** Secure the flexible track rail to the marked mounting points using the provided screws and anchors. The track can be shaped to fit your design preferences. For longer rooms, multiple kits can be connected using a compatible flex joiner (sold separately, item 726497).
4. **Electrical Connection:** Connect the fixture's electrical wires to the corresponding wires from the junction box (black to black, white to white, ground to ground) using the provided wire connectors. Ensure all connections are secure.
5. **Attach Canopy:** Secure the canopy/junction box cover to conceal the electrical connections and provide a finished look.
6. **Position Light Heads:** The six integrated LED light heads are pre-attached to the track. Adjust each head to direct light as desired. The heads are fully adjustable for optimal directional lighting.
7. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit

breaker.

5. OPERATING INSTRUCTIONS

Power On/Off:

The track light can be turned on or off using a standard wall switch connected to the circuit or via the included remote control.

Dimming Function:

This fixture is dimmable. Use a compatible dimmer switch (sold separately) or the remote control to adjust the brightness of the LED lights. Refer to your dimmer's instructions for specific operation.

Adjusting Light Heads:

Each of the six light heads can be independently adjusted to direct light to specific areas. Gently pivot and rotate the light heads to achieve the desired illumination angle.

Remote Control Operation:

The included remote control allows for convenient operation of the track light, including power on/off and dimming functions. Ensure the remote has working batteries and is pointed towards the fixture for optimal response.

6. MAINTENANCE

Cleaning:

To clean the fixture, ensure the power is turned off. Wipe the surface with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or electrical components.

LED Replacement:

The allen + roth Sloan 6-Light Track Light features integrated LED modules. These LEDs are designed for long life and are **not user-replaceable**. If an LED module fails, the entire fixture may require replacement. Do not attempt to disassemble the light heads to replace individual LEDs.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse. Ensure wall switch is ON. Verify electrical connections.
Light flickers or dims improperly.	Incompatible dimmer switch. Loose wiring connection.	Ensure dimmer is LED compatible. Check all wire connections. Consult a qualified electrician.
Remote control not working.	Dead batteries. Obstruction.	Replace remote control batteries. Ensure clear line of sight to the fixture.
One or more LED heads are not working.	Integrated LED failure.	Integrated LEDs are not user-replaceable. If an LED fails, the entire fixture may need replacement. Contact customer support.

If you experience issues not listed above or if the suggested solutions do not resolve the problem, please contact customer support or a qualified electrician.

8. SPECIFICATIONS

- **Model Number:** 20272-000 Sloan 6-Light
- **Brand:** allen + roth
- **Light Type:** Integrated LED
- **Number of Lights:** 6
- **Brightness:** 3193 Lumens (per fixture), 532 Lumens (per head)
- **Light Color:** Warm White
- **Wattage:** 6 Watts (per head)
- **Incandescent Equivalent Wattage:** 50 Watts (per head)
- **Efficiency:** 108.33 lumens per watt
- **Voltage:** 120 Volts (AC)
- **Accepted Voltage Frequency:** 100 to 120 Volts and 60 Hertz
- **Special Feature:** Dimmable
- **Control Method:** Remote Control / Wall Switch
- **Power Source:** Corded Electric
- **Indoor/Outdoor Usage:** Indoor
- **Material Type:** Nickel
- **Item Weight:** 4.9 Pounds
- **UPC:** 022011652023

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact allen + roth customer service. Keep your purchase receipt as proof of purchase for any warranty claims. Do not return the product to the store without first contacting customer support.

Contact information for allen + roth can typically be found on their official website or on the product packaging.