

ALIGATOR T100

Aligator T100 GSM Mobile Phone User Manual

Model: T100

1. INTRODUCTION

The Aligator T100 is a GSM mobile phone designed in a classic desk phone style, offering convenient operation with large buttons and essential mobile phone functions. It serves as an excellent replacement for a fixed-line phone, providing the independence and flexibility of a mobile device. Its high-performance antenna ensures reliable reception even in areas with weak GSM signals.

2. SAFETY INFORMATION

- **Battery Warning:** Use only the original battery provided with the device. Using non-original batteries may cause damage to the phone or lead to battery explosion.
- Keep the device away from water and moisture.
- Do not attempt to disassemble or repair the phone yourself. Refer to qualified service personnel for any repairs.
- Avoid exposing the phone to extreme temperatures.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Aligator T100 GSM Mobile Phone unit
- Handset with coiled cord
- High-performance external antenna
- Mains charger
- Li-ion 800 mAh battery
- User manual (English, German, Czech, Slovak)



Figure 3.1: Contents of the Aligator T100 package.

4. PRODUCT OVERVIEW

The Aligator T100 features a robust design with a clear monochrome graphic display and a user-friendly keypad. Key components include the main unit, handset, and an external antenna for enhanced signal reception.



Figure 4.1: Front view of the Aligator T100.



Figure 4.2: Side view showing the antenna connection.



Figure 4.3: Back view of the Aligator T100.

4.1 Keypad and Display

The keypad features large, easy-to-read buttons. The monochrome graphic display (128 x 64 points, 53 x 25 mm) has a green background illumination for clear visibility.



Figure 4.4: Close-up of the display and keypad.

5. SETUP

5.1 Battery Installation

1. Remove the battery compartment cover on the back of the phone.
2. Insert the provided Li-ion 800 mAh battery, ensuring the contacts align correctly.
3. Replace the battery compartment cover.

5.2 SIM Card Installation

1. With the battery removed, locate the SIM card slot.
2. Insert your GSM SIM card into the designated slot, ensuring proper orientation as indicated by the

diagram near the slot.

3. Reinstall the battery and battery cover.

5.3 Antenna Attachment

1. Locate the TNC-Female connector on the side/back of the phone unit.
2. Screw the high-performance external antenna onto this connector until it is securely fastened.

5.4 Initial Charging and Power On

1. Connect the mains charger to the phone's charging port and plug it into a power outlet.
2. Allow the phone to charge fully before first use. The display will indicate charging status.
3. To power on, press and hold the power button (if available) or simply ensure the battery is inserted and the phone is connected to power.

6. OPERATING INSTRUCTIONS

6.1 Making and Receiving Calls

- **Making a Call:** Lift the handset. You will hear a classic dial tone. Dial the phone number using the keypad. The call will be initiated automatically after a short delay or upon pressing the call button.
- **Receiving a Call:** When the phone rings, simply lift the handset to answer the call.
- **Ending a Call:** Place the handset back onto the cradle to end the call.

6.2 Using the Keypad and Navigation

The keypad includes standard numeric keys (0-9, *, #) and dedicated function buttons. Use the navigation buttons (up, down, left, right) to navigate through menus on the display.







Figure 6.1: Display and navigation controls.



6.3 Speed Dial / Quick Dial

The Aligator T100 features four quick dial buttons (labeled 1-4) for frequently called numbers. You can program these buttons to dial a contact directly.

- **Programming Quick Dial:** Refer to the phone's menu for

Related Documents - T100

 <p>S6700 Senior Návod k použití</p>	<p>ALIGATOR S6700 Senior User Manual</p> <p>User manual for the ALIGATOR S6700 Senior mobile phone, covering setup, features like DUAL SIM and SOS Locator, Android OS, connectivity, safety, and ecological disposal.</p>
 <p>Aligator Watch Pro X</p>	<p>Aligator Watch Pro X User Manual and Guide</p> <p>Comprehensive user manual for the Aligator Watch Pro X smartwatch, covering setup, features, connectivity, notifications, watch faces, phone integration, and troubleshooting.</p>
 <p>A930 GPS Senior 4G Návod k použití Návod na použití Bedienungsanleitung Használati útmutató</p>	<p>ALIGATOR A930 GPS Senior 4G: Návod k použití</p> <p>Kompletní návod k použití pro mobilní telefon ALIGATOR A930 GPS Senior 4G, navržený pro seniory s funkcemi GPS a SOS pro snadné ovládání a bezpečnost.</p>
 <p>ALIGATOR WATCH LADY USER MANUAL</p>	<p>Aligator Watch Lady Smartwatch User Manual & Guide</p> <p>Comprehensive user manual for the Aligator Watch Lady smartwatch, covering setup, features, connectivity, troubleshooting, and safety information.</p>

 <p>Aligator Watch GPS Návod k použití</p>	<p>Aligator Watch GPS User Manual and Guide</p> <p>Comprehensive user manual for the Aligator Watch GPS smartwatch, covering setup, features, pairing, data tracking, settings, troubleshooting, and safety information.</p>
 <p>Aligator MiTag lokátor pro Android™ – s podporou Find Hub</p>	<p>Aligator MiTag Locator: User Manual, Setup, and Specifications</p> <p>Comprehensive user manual for the Aligator MiTag locator, detailing setup, operation, battery replacement, technical specifications, and safety guidelines. Compatible with Android devices and Find Hub.</p>