

Jura S8 (15210)

Jura S8 Automatic Coffee Machine User Manual

Model: S8 (15210) | Brand: Jura

INTRODUCTION

With its clear cut, sculptural design, the stylish S line exudes quality and precision in every way. It combines the best of the compact class with elements of the premium segment, including a hint of the GIGA. The impressive range of specialties and the stunning result in the cup satisfy even the most demanding coffee connoisseurs. The operating concept is based on simplicity and intelligence. The JURA S line creates a new segment in coffee machines: the premium mid-segment.

KEY FEATURES

- **One Touch Operation:** Prepare 15 barista quality specialties including espresso, coffee, cappuccino, flat white and latte macchiato at the touch of a button.
- **Perfect Espresso:** Ultimate coffee quality thanks to JURA's exclusive Pulse Extraction Process.
- **Conical Burr Grinder:** Fast and precise AromaG3 grinder grinds whole beans to the optimum fineness.
- **Freshly Ground:** JURA is always freshly ground, not capsuled - fresh taste with very limited waste - single serve machine.
- **Generous Capacity:** Features a 64 ounce water tank and a 10 ounce bean container.

SETUP GUIDE

Follow these steps to set up your Jura S8 Automatic Coffee Machine for the first time:

1. **Unpacking:** Carefully remove the machine and all accessories from the packaging. Retain packaging for future transport or storage.
2. **Placement:** Place the machine on a stable, level surface, away from heat sources and direct sunlight. Ensure adequate ventilation.
3. **Water Tank:** Remove the water tank, rinse it thoroughly, and fill it with fresh, cold water. Insert the CLARIS Smart filter cartridge into the water tank as instructed by the machine's display. Ensure the filter is properly recognized by the machine's RFID system.
4. **Bean Container:** Open the aroma preservation cover and fill the bean container with fresh coffee beans.
5. **Power Connection:** Plug the power cable into the machine and then into a suitable power outlet.

6. **Initial Rinse:** The machine will guide you through an initial rinse process. Follow the instructions on the touchscreen display.



Figure 1: Front view of the Jura S8 Automatic Coffee Machine with a prepared latte macchiato.

OPERATING INSTRUCTIONS

The Jura S8 features an intuitive touchscreen display for easy operation. Here are basic steps for preparing beverages:

1. **Power On:** Press the power button located on the top right of the machine.
2. **Select Beverage:** On the touchscreen display, select your desired coffee specialty (e.g., Espresso, Coffee, Cappuccino, Latte Macchiato).
3. **Customize (Optional):** For many beverages, you can adjust settings such as coffee strength, water volume, and milk foam quantity directly on the screen before brewing.
4. **Place Cup:** Position your cup(s) under the coffee spout and, if applicable, the milk spout.
5. **Start Brewing:** Press the start button or the selected beverage icon to begin preparation. The machine will automatically grind the beans, brew the coffee, and froth milk if required.
6. **Hot Water Function:** To dispense hot water, select the 'Hot Water' option on the display.




Figure 2: The Jura S8's intuitive touchscreen display for beverage selection.



Figure 3: Coffee being dispensed from the Jura S8.

Your browser does not support the video tag.

Video 1: Official Jura S8 Product Video demonstrating various features and beverage preparation. This video provides a visual guide to the machine's capabilities.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Jura S8. The machine will prompt you for necessary cleaning and maintenance tasks.

- **Daily Milk System Cleaning:** After preparing milk-based beverages, the machine will prompt you to clean the milk system. This is crucial to prevent blockages and maintain hygiene. Use Jura milk system cleaner for best results.
- **Coffee System Cleaning:** The machine will indicate when a coffee system cleaning is required. Use Jura cleaning tablets and follow the on-screen instructions. This typically occurs after approximately 180 preparations or 80 switch-on rinses.
- **Filter Replacement:** The CLARIS Smart filter cartridge needs to be replaced regularly, typically after 50 liters of water or 2 months, whichever comes first. The machine's RFID system will detect the filter and prompt for replacement. Using non-Jura filters or attempting to bypass the RFID system may lead to issues and void warranty.
- **Descaling:** If you operate the machine without a CLARIS Smart filter, descaling will be necessary. The machine will prompt you when descaling is due. Use Jura descaling tablets and follow the instructions carefully.
- **Drip Tray and Coffee Grounds Container:** Empty and clean the drip tray and coffee grounds container daily or when prompted by the machine.
- **Bean Container Cleaning:** Periodically clean the bean container to remove any oily residue from coffee beans.

Figure 4: Side view of the Jura S8, highlighting the water tank for refilling and filter access.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Jura S8. For more complex problems, refer to the official Jura support resources.

Problem	Possible Cause	Solution
Machine stuck on "Insert filter" screen.	The CLARIS Smart filter cartridge may not be correctly inserted or its RFID chip is not recognized.	Ensure the filter is fully seated and clicked into place. If the issue persists, try a new, genuine Jura CLARIS Smart filter. Contact Jura support if the problem continues with a new filter.
No coffee is dispensed.	Water tank empty, bean container empty, brewing unit clogged, or air in the system.	Refill water tank/bean container. Perform a cleaning cycle. Run hot water to prime the system.
Milk foam is not consistent or not produced.	Milk system is dirty or clogged, milk is too warm, or milk type is unsuitable.	Perform a thorough milk system cleaning. Use cold milk (preferably straight from the refrigerator). Ensure all milk system components are correctly assembled.

SPECIFICATIONS

Feature	Detail
Brand	Jura
Model Name	S8
Item Model Number	15210
Color	Moonlight Silver
Product Dimensions	21.4"D x 12.9"W x 17.4"H
Item Weight	4 pounds
Water Tank Capacity	64 ounces
Bean Container Capacity	10 ounces
Coffee Maker Type	Espresso Machine
Operation Mode	Fully Automatic
Human Interface Input	Touchscreen
Filter Type	Reusable (with CLARIS Smart filter system)
Special Feature	Programmable
Included Components	Coffee machine



Figure 5: Top view of the Jura S8, showing the bean hopper and water tank access.

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please contact Jura customer service directly. Ensure you have your machine's model number (S8) and serial number ready when contacting support.

You can find more information and contact details on the official Jura website: www.jura.com

© 2024 Jura Inc. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question