

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sauder](#) /

› [Sauder Craft Pro Series Storage Cabinet Model 421407 Instruction Manual](#)

Sauder 421407

Sauder Craft Pro Series Storage Cabinet Model 421407 Instruction Manual

Your guide to assembly, operation, and maintenance.

1. PRODUCT OVERVIEW

The Sauder Craft Pro Series Storage Cabinet, Model 421407, is designed to provide versatile storage for various items, particularly craft supplies. This unit features a durable melamine top surface, four drawers with full-extension slides, and open shelving for organized storage. Its white finish is designed to integrate with a range of interior styles.



Image 1.1: Front view of the Sauder Craft Pro Series Storage Cabinet.

This image displays the Sauder Craft Pro Series Storage Cabinet in a white finish, featuring four drawers with silver knobs and an open shelf above them. The cabinet is designed for functional storage and organization.

Key Features:

- Multi-purpose storage with four drawers and open shelving.
- White finish.
- Durable melamine top surface, resistant to heat, stains, and scratches.
- Suitable for craft rooms, studios, or home office areas.

2. ASSEMBLY INSTRUCTIONS

Assembly of the Sauder Craft Pro Series Storage Cabinet is required. The product includes all necessary materials, hardware, and a step-by-step assembly guide. Please follow the instructions carefully to ensure proper construction and stability.

Before You Begin:

- Review all instructions and diagrams before starting.

- Identify all parts and hardware. Ensure no pieces are missing.
- Clear a spacious, clean area for assembly.
- Gather necessary tools (e.g., screwdriver, hammer).

Assembly Tips:

- Pay special attention to aligning side rails and drawer components for smooth operation.
- Ensure all parts are securely fastened. Do not overtighten screws.
- If experiencing difficulty with drawer glides, ensure they are correctly oriented and lubricated as needed.
- For cam cover stickers, apply firmly to ensure adhesion.




Image 2.1: Dimensional diagram of the storage cabinet.

This diagram provides detailed measurements for the Sauder Craft Pro Series Storage Cabinet, including overall dimensions and internal drawer and shelf dimensions, crucial for assembly and placement.

3. OPERATING INSTRUCTIONS

The Sauder Craft Pro Series Storage Cabinet is designed for straightforward use, offering accessible storage solutions.

Using the Drawers:

- The cabinet features four drawers with full-extension slides for easy access to contents.
- To open a drawer, gently pull the knob. To close, push until it is fully seated.
- Organize items within the drawers. The top drawers are suitable for smaller items, while the bottom drawers offer more depth for larger supplies.



Image 3.1: Cabinet with drawers partially open, showcasing storage capacity.

This image shows the Sauder Craft Pro Series Storage Cabinet in a room setting with two drawers partially open, revealing stored items. This demonstrates the full-extension drawer slides and the cabinet's functional design.

Utilizing Open Shelving:

- The open shelf above the drawers provides quick access storage for frequently used items or decorative displays.
- Ensure items placed on the shelf do not obstruct drawer operation.



Image 3.2: Close-up of the open shelf area.

A detailed view of the open shelf section of the cabinet, showing craft paper rolls and a small box, illustrating its use for accessible storage.

4. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your Sauder Craft Pro Series Storage Cabinet.

Cleaning:

- Wipe surfaces with a damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Promptly clean spills to prevent staining, especially on the melamine top.

General Care:

- Periodically check all hardware connections and tighten if necessary to maintain stability.
- Avoid placing excessively heavy items on shelves or in drawers to prevent damage. Refer to specifications for weight limits.
- Protect the top surface from extreme heat or sharp objects.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your storage cabinet.

Drawers Not Operating Smoothly:

- **Check Alignment:** Ensure the drawer slides on both the cabinet and the drawer itself are correctly aligned and installed. Misalignment is a common cause of sticking drawers.
- **Verify Leveling:** Confirm that the cabinet is placed on a level surface. An uneven cabinet can cause drawers to bind.
- **Inspect for Obstructions:** Look for any foreign objects or debris in the drawer slides.
- **Lubrication:** If slides feel stiff, a small amount of silicone-based lubricant can improve movement. Avoid excessive grease.

Loose or Wobbly Cabinet:

- **Tighten Hardware:** Re-check all cam locks and screws throughout the cabinet structure. Gently tighten any that feel loose.
- **Ensure Proper Assembly:** Review the assembly instructions to confirm all components are correctly installed and secured.

Damaged or Missing Parts:

- If you received damaged parts or are missing components, please contact Sauder customer support immediately for assistance. Refer to the "Support and Warranty" section for contact information.

6. SPECIFICATIONS

Feature	Detail
Brand	Sauder
Model Number	421407
Color	White
Product Dimensions (D x W x H)	17.56" x 32.13" x 30.12"
Item Weight	88.6 pounds
Weight Limit	1456 Ounces (approx. 91 lbs)
Material	Engineered Wood (Top Material, Back Material, Frame Material)
Finish Type	White Finish
Special Feature	Scratch Resistant (Melamine top)
Assembly Required	Yes
Number of Drawers	4
Number of Shelves	1 (open shelf)

7. WARRANTY AND SUPPORT

Warranty Information:


This Sauder product comes with a 5-year parts warranty. Please retain your proof of purchase for warranty claims.

Customer Support:

For assembly assistance, replacement parts, or any other inquiries, please contact Sauder's Domestic Call Center. They are ready to assist you.

Website: sauder.com/service

Phone: 800-523-3987



DOMESTIC CALL CENTER

READY TO ASSIST.

sauder.com/service

800-523-3987

Image 7.1: Sauder customer support information.

This image displays contact information for Sauder's Domestic Call Center, including their website and phone number, emphasizing their readiness to provide assistance.

