Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Ingenuity /
- > Ingenuity SimpleComfort 2-in-1 Baby Swing & Rocker (Model 11791) Instruction Manual

Ingenuity 11791

Ingenuity SimpleComfort 2-in-1 Baby Swing & Rocker (Model 11791) - Instruction Manual

1. Introduction

The Ingenuity SimpleComfort 2-in-1 Baby Swing & Rocker is designed to provide soothing comfort and entertainment for your baby. This versatile product functions as both a multi-direction baby swing and a portable rocker, adapting to your child's needs from birth up to 9 months or 20 lbs. It features multiple swing speeds, soothing vibrations, a selection of melodies and nature sounds, and a compact, lightweight design for easy portability.



Figure 1: Ingenuity SimpleComfort 2-in-1 Baby Swing and Rocker in Raylan color.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- · Always use the restraint system.
- Never leave child unattended.
- Do not use this product once your child can sit up unaided or weighs more than 20 lbs (9 kg), whichever comes first.
- This product is intended for infants from 0 to 9 months.
- Do not move or lift the product with the child inside.
- Ensure the product is placed on a flat, level surface.
- Keep children away from the product during assembly and disassembly.
- Always ensure all locking mechanisms are engaged before use.

3. PACKAGE CONTENTS

Please check that all components are present before assembly:

- Swing Frame Assembly
- · Seat Pad and Headrest
- Toy Bar with 2 Plush Toys
- USB Power Cord (AC adapter not included)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly of the Ingenuity SimpleComfort 2-in-1 Baby Swing & Rocker is designed to be straightforward. Follow the detailed instructions provided in the manual. No special tools are required for most of the assembly, though a screwdriver may be needed for the battery compartment of the vibration unit.



Figure 2: Adult assembling the Ingenuity SimpleComfort baby swing.

Assembly Video

Your browser does not support the video tag.

Video 1: Detailed assembly guide for the Ingenuity SimpleComfort Baby Swing.

5. OPERATING INSTRUCTIONS

5.1 Powering the Unit

The swing motion and music are powered by the included USB cord. An AC adapter is not included and must be supplied by the user. The vibration unit requires 1 C battery (not included).



Figure 3: USB power cord.



Figure 4: USB power cord connected to the swing base.

5.2 Control Panel Functions

The intuitive control panel allows you to customize your baby's experience:



Figure 5: Control panel for the Ingenuity SimpleComfort swing.

- Power Button: Turns the swing on/off.
- Sound/Music Selection: Choose from 16 melodies, 3 nature sounds, or white noise. Music automatically shuts off after 20 minutes.
- Volume Control: Adjust the audio level to your preference.
- **Timer Settings:** Set the swing to operate for 30, 45, or 60 minutes. The swing has an auto shut-off feature after 2 hours.
- **Swing Speed:** Select from 6 different swing speeds. TrueSpeed technology maintains consistent speed as your baby grows.

5.3 Swing Motion and Seat Rotation

The seat can rotate 180 degrees, allowing for three different swinging directions (side-to-side or front-to-back). This feature helps you find the most comforting motion for your baby and keeps them in view.



Figure 6: Multi-directional swinging capability.

5.4 Soothing Vibration

Activate the gentle vibration feature to further soothe your baby. The vibration unit is battery-powered (1 C battery, not included) and automatically turns off after 30 minutes.



Figure 7: Vibration control button.

5.5 Toy Bar and Head Support

The removable toy bar features two adorable plush characters to engage your baby. A soft head support is included for newborns to ensure proper comfort and positioning.



Figure 8: Baby enjoying the toy bar.



Figure 9: Removable head support.

5.6 Portability

The swing is lightweight and compact, featuring wheels and a handle for easy movement between rooms or for storage.



Figure 10: Demonstrating the swing's portability.

5.7 Product Overview Video

Your browser does not support the video tag.

Video 2: Overview of the Ingenuity SimpleComfort Baby Swing features.

6. 2-IN-1 FUNCTIONALITY (SWING TO ROCKER)

The Ingenuity SimpleComfort is designed for seamless conversion from a full-feature baby swing to a portable rocker. This allows for flexibility in use, providing a soothing environment for your baby whether they prefer swinging or gentle rocking.




Figure 11: Swing and rocker modes.



Figure 12: Converting the swing to a rocker.



Figure 13: Baby in rocker mode.

7. MAINTENANCE AND CARE

To keep your Ingenuity SimpleComfort 2-in-1 Baby Swing & Rocker clean and hygienic:

- Seat Pad and Headrest: Remove from the frame. Fasten all buckles on the seat restraint and seat pad. Fasten all hook-and-loop patches to the corresponding patch. Machine wash with cold water on a gentle cycle. Do not use bleach. Tumble dry on low heat.
- Frame: Wipe clean with a soft, damp cloth and mild soap. Do not immerse the frame in water.



Figure 14: Washing the seat pad.

8. TROUBLESHOOTING

If you encounter any issues with your Ingenuity SimpleComfort 2-in-1 Baby Swing & Rocker, please consider the following:

- Swing not operating: Ensure the USB power cord is securely connected to both the swing and a working AC adapter/power source.
- **Vibration not working:** Check if the C battery is correctly installed and not depleted. Replace if necessary.
- **Unusual noises:** Verify that all parts are correctly assembled and securely fastened. Ensure no fabric or foreign objects are obstructing the moving parts.
- **Inconsistent swing speed:** The TrueSpeed technology is designed to maintain consistent speed. If you notice significant inconsistency, ensure the weight limit is not exceeded and check power connections.

For further assistance, please refer to the manufacturer's support resources.

9. Specifications

Feature	Detail		
Brand	Ingenuity		
Model Number	11791		
Product Dimensions	34.25"D x 31.53"W x 36.22"H		
Item Weight	22 pounds		
Material Composition	64% Metal, 29% Plastic, 7% Fabric		
Power Source (Swing/Music)	USB cord (AC adapter not included)		
Power Source (Vibration)	1 C battery (not included)		
Maximum Age	9 months		
Maximum Weight	20 lbs (9 kg)		
Swing Speeds	6		
Swing Directions	3 (with 180-degree seat rotation)		
Timer Options	30, 45, 60 minutes (auto shut-off after 2 hours)		
Sounds	16 melodies, 3 nature sounds, white noise		
Portability	Yes (lightweight, compact, wheels, handle)		



Figure 15: Product dimensions and weight limits.

10. WARRANTY AND SUPPORT

Specific warranty information for the Ingenuity SimpleComfort 2-in-1 Baby Swing & Rocker is not provided in the product details. For warranty claims, product registration, or further support, please visit the official Ingenuity website or contact their customer service directly. Keep your proof of purchase for any warranty-related inquiries.

ingenuity^{*}

Ingenuity SimpleComfort Compact Soothing Swing & Rocker - Raylan User Manual

This user manual provides essential safety information, assembly instructions, battery guidelines, and care tips for the Ingenuity SimpleComfort Compact Soothing Swing & Rocker™ in the Raylan™ design.

ingenuity

Ingenuity SimpleComfort Compact Soothing Swing - Everston User Manual

User manual and instructions for the Ingenuity SimpleComfort Compact Soothing Swing - Everston model (11149-MEES). Includes safety warnings, assembly, battery information, care, and usage details for this baby swing by Ingenuity (Kids2).

ingenuity



Ingenuity SimpleComfort Compact Soothing Swing - Parker User Manual

This user manual provides instructions for the Ingenuity SimpleComfort Compact Soothing Swing -Parker. It includes safety warnings, assembly instructions, care and cleaning guidelines, and information on the swing's features.



Ingenuity InLighten Soothing Swing - Van Elephant User Manual

User manual for the Ingenuity InLighten Soothing Swing in the Van Elephant design. Provides instructions on assembly, use, safety warnings, and care.



Ingenuity InLighten Soothing Swing - Kitt™ User Manual and Safety Guide

This comprehensive user manual provides detailed instructions for assembling, using, and caring for the Ingenuity InLighten Soothing Swing - Kitt™. It includes essential safety warnings, operational guidance for the control module, and maintenance tips, presented in English, Spanish, and French.



Ingenuity SimpleComfort Compact Soothing Swing - Chambray User Manual

This manual provides instructions for the Ingenuity SimpleComfort Compact Soothing Swing in Chambray. It includes safety warnings, assembly instructions, care and cleaning guidelines, and usage information for the swing's features.