

- Manuals.plus /
- › Project Source /
- › User Manual for Project Source 13-in W Brushed Nickel LED Flush Mount Light ENERGY STAR

Project Source 41058

User Manual

13-IN W BRUSHED NICKEL LED FLUSH MOUNT LIGHT

Brand: Project Source | Model: 41058

INTRODUCTION

Thank you for purchasing the Project Source 13-inch Brushed Nickel LED Flush Mount Light. This ENERGY STAR certified fixture is designed to provide efficient and long-lasting illumination for your indoor spaces. This manual will guide you through the installation, operation, and maintenance to ensure safe and proper use of your new light fixture.



An image showing the Project Source 13-inch Brushed Nickel LED Flush Mount Light. The fixture features a brushed nickel base and a frosted white dome-shaped diffuser, designed for ceiling installation.

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or other injuries that could be hazardous or fatal.

- Always turn off the power at the main circuit breaker or fuse box before beginning installation or performing any maintenance.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections are secure and comply with local codes and ordinances.
- Do not install this fixture in wet or damp locations. It is designed for indoor use only.
- Do not attempt to modify the fixture. Any modifications may void the warranty and create safety hazards.
- Handle the fixture with care to avoid damage to the LED components.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- LED Flush Mount Light Fixture (1)
- Mounting Hardware Kit (1)
- Remote Control (1)
- User Manual (1)

SETUP AND INSTALLATION

Follow these steps to properly install your light fixture:

1. **Turn Off Power:** Before starting, ensure the power to the junction box is turned off at the circuit breaker or fuse box.
2. **Prepare Mounting Surface:** Remove any existing fixture and mounting hardware. Ensure the junction box is securely mounted and capable of supporting the fixture's weight.
3. **Install Mounting Bracket:** Attach the mounting bracket (included in hardware kit) to the junction box using the provided screws. Ensure the bracket is firmly secured.
4. **Make Electrical Connections:** Carefully connect the electrical wires. Connect the fixture's black wire to the house's black (live) wire, the fixture's white wire to the house's white (neutral) wire, and the fixture's ground wire to the house's ground wire (or ground screw on the mounting bracket). Secure connections with wire nuts.
5. **Mount the Fixture:** Carefully align the fixture with the mounting bracket and secure it using the provided screws. Ensure the fixture is flush against the ceiling.
6. **Restore Power:** Once the fixture is securely installed and all connections are made, restore power at the circuit breaker.

OPERATING INSTRUCTIONS

This LED flush mount light is designed for simple operation:

- **Wall Switch:** The fixture can be controlled by a standard wall switch connected to the circuit.
- **Remote Control:** Use the included remote control to turn the light on/off. Refer to the remote control's specific instructions for any additional features like dimming or color temperature adjustments, if applicable.

MAINTENANCE

To maintain the appearance and performance of your light fixture:

- **Cleaning:** Always turn off the power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or electrical components.
- **LEDs:** The integrated LED light source is designed for long life and does not require replacement.

TROUBLESHOOTING

If you experience issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse. Ensure wall switch is ON.
Light does not turn on.	Loose wire connections.	Turn off power and check all wire connections.
Light flickers or dims.	Incorrect wiring or loose connection.	Turn off power and re-check all wire connections. Ensure proper voltage supply.
Remote control not working.	Dead batteries in remote.	Replace batteries in the remote control.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Project Source
Model Number	41058
Product Dimensions	13 x 13 x 3 inches

Feature	Detail
Item Weight	3 pounds
Color	Nickel
Material	Nickel
Style	Modern
Light Fixture Form	Ceiling
Indoor/Outdoor Usage	Indoor
Power Source	Corded Electric
Installation Type	Flush Mount
Control Method	Remote
Light Source Type	LED
Finish Type	Brushed
Shade Material	Nickel
Number of Light Sources	1
Voltage	120 Volts (DC)
Light Color	Warm White
Included Components	Remote Control, Mounting Hardware
Wattage	12 watts
Efficiency	ENERGY STAR Certified
Assembly Required	No
UPC	671961410582

WARRANTY INFORMATION

This Project Source product is backed by a manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, refer to the product packaging or contact customer support.

CUSTOMER SUPPORT

For technical assistance, replacement parts, or any questions regarding your Project Source 13-inch Brushed Nickel LED

Flush Mount Light, please contact our customer support team:

- **Website:** Visit the Project Source official website for FAQs and support resources.
- **Phone:** Refer to your product packaging for customer service contact numbers.

Please have your model number (41058) and date of purchase ready when contacting support.

© 2024 Project Source. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07DQP8QVV>

More documents and user manuals: <https://manuals.plus/>