

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PAXCESS](#) /

› [PAXCESS 9-Pad Electronic Drum Set User Manual](#)

PAXCESS PA-DS0001

PAXCESS 9-Pad Electronic Drum Set User Manual

Model: PA-DS0001

Brand: PAXCESS

1. INTRODUCTION

This manual provides comprehensive instructions for the PAXCESS 9-Pad Electronic Drum Set. Please read this guide thoroughly before operating the device to ensure proper setup, usage, and maintenance. This electronic drum set offers a realistic drumming experience with its nine sensitive pads, built-in speaker, headphone jack for quiet practice, and portable design.



Figure 1: PAXCESS 9-Pad Electronic Drum Set overview.

2. WHAT'S IN THE BOX

Upon unpacking, please ensure all the following components are present:

- PAXCESS 9-Pad Electronic Drum Set
- Drumsticks (2)
- Foot Pedals (2)
- USB Charging Cable
- User Manual (this document)

3. PRODUCT FEATURES

- **Realistic Sound Simulation:** Produces realistic sounds replicating 1 snare, 3 toms, 1 crash, 1 ride, 1 kick, 2 hi-hat, and 2 foot-pedal bass sounds.
- **Integrated Audio:** Features a built-in high-quality dual speaker system with super bass effect for sound output.
- **Quiet Practice Option:** Includes a headphone jack for private practice without disturbing others.
- **Connectivity:** Connects with computers via USB for use with games or MIDI applications. An MP3 input allows playing along to external audio.
- **Portability:** Lightweight and roll-up design for easy transport and storage. A long-lasting rechargeable battery provides up to 8 hours of playtime after 2 hours of charging.
- **Durable Material:** Made of top-quality, non-toxic, and waterproof silicone material.



Connect
the earphone



Double
loudspeaker



Easy to
carry



USB MIDI
interface



Pedal control



Figure 2: Key features and connectivity options.



Figure 3: Portability and battery life for on-the-go drumming.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Unroll the drum pad and place it on a flat, stable surface. A harder surface is recommended for better stick rebound.
3. **Charge Battery:** Connect the USB charging cable to the USB/DC 5V port on the drum set and to a power source. The battery takes approximately 2 hours to fully charge and provides up to 8 hours of playtime.
4. **Connect Foot Pedals:** Plug the two foot pedals into the 'PEDAL' ports on the control module. These control the kick drum and hi-hat sounds.
5. **Power On:** Slide the 'OFF/ON' switch to the 'ON' position to power on the drum set.
6. **Optional - Connect Headphones:** For quiet practice, plug your headphones into the 'PHONES' port.
7. **Optional - Connect External Audio:** To play along with music, connect an MP3 player or smartphone to the 'MP3' input port using an audio cable (not included).

8. **Optional - Connect to Computer:** For MIDI functionality or use with drumming software, connect the drum set to your computer via the USB port.



Figure 4: Labeled diagram of drum pads and control panel ports.

5. OPERATING INSTRUCTIONS

5.1. Basic Operation

- **Power On/Off:** Use the 'OFF/ON' switch to turn the device on or off.
- **Volume Adjustment:** Use the 'VOLUME+' and 'VOLUME-' buttons to adjust the output volume of the built-in speakers or connected headphones.
- **Playing the Pads:** Strike the silicone pads with the provided drumsticks or your hands to produce sounds. The pads are velocity-sensitive, meaning the sound intensity can vary with how hard you strike them.
- **Foot Pedals:** Use the foot pedals to trigger the kick drum and hi-hat sounds, providing a more authentic drumming experience.

5.2. Modes and Functions

- **KIT:** Press the 'KIT' button to cycle through different pre-set drum kits, each offering a unique set of drum sounds.
- **CLICK (Metronome):** Press the 'CLICK' button to activate the metronome. This provides a steady beat for practice. Press again to turn off.
- **PLAY/STOP:** This button is used to start or stop playback of demo songs or other functions.
- **DEMO:** Press the 'DEMO' button to play pre-recorded demonstration songs. This allows you to hear the drum set's capabilities and practice along.
- **SPECIAL:** The 'SPECIAL' button may cycle through different sound effects or modes, depending on the selected drum kit. Experiment to discover various sound variations.



Figure 5: Practicing quietly with headphones.

5.3. Video Demonstration

Your browser does not support the video tag.

Video 1: Official product overview video demonstrating the features and sound of the PAXCESS 9-Pad Electronic Drum Set.

6. MAINTENANCE

- **Cleaning:** Wipe the silicone pads and control module with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** When not in use, roll up the drum pad for compact storage. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Charge the device regularly, even if not in constant use.



Figure 6: Durable and waterproof silicone pad material.

Roll UP & Save Space



Figure 7: Roll-up design for easy storage and portability.

7. TROUBLESHOOTING

- **No Sound:**

- Ensure the device is powered on.
- Check the volume level using the 'VOLUME+' button.
- If headphones are connected, ensure they are fully plugged in and functioning correctly.
- If using external speakers, ensure they are connected to the headphone jack and powered on.

- **Pads Not Responding:**

- Ensure the drum pad is properly connected to the control module.
- Check for any visible damage to the pads or connections.

- **Sound Delay (when connected to computer via USB MIDI):**

- Latency can occur due to computer processing speed or audio interface drivers.
- Ensure your computer's audio drivers are up to date.
- Using a dedicated audio interface with ASIO drivers can significantly reduce latency for professional applications.

8. SPECIFICATIONS

| Feature | Detail |
|--------------------------------|---|
| Model Number | PA-DS0001 |
| Brand | PAXCESS |
| Drum Set Piece Quantity | 9 Pads |
| Material Type | Silicone |
| Body Material | Bass Wood |
| Finish Type | Glossy |
| Item Weight | 3.74 pounds |
| Product Dimensions (L x W x H) | 21.65 x 17.32 x 2.76 inches |
| Batteries | 1 Lithium Ion battery required (included) |
| Connector Type | Plug-in (USB, MP3, Phones, Pedal) |
| Color | 1-white |

9. WARRANTY AND SUPPORT

For detailed warranty information, product registration, or customer support, please visit the official PAXCESS website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.