



[Manuals.plus](#) /

› [PARLOS](#) /

› PARLOS Doris 14072 1.2GPM Brushed Nickel 2-Handle Bathroom Faucet Instruction Manual

PARLOS 14072

PARLOS Doris 14072 1.2GPM Brushed Nickel 2-Handle Bathroom Faucet Instruction Manual

Model: 14072

1. PRODUCT OVERVIEW

The PARLOS Doris 14072 is a 2-handle bathroom faucet designed for 4-inch centerset installations. It features a brushed nickel finish, a water-efficient aerator, and includes a metal pop-up drain assembly and cUPC certified supply lines for a complete installation.



Image 1.1: The PARLOS Doris 14072 faucet highlighting its mid-arc spout, NEOPERL aerator, and HENT cartridge.

Key Features:

- **4-inch Centerset Design:** Standard design for straightforward 3-hole deck mounted installations.
- **Water-Efficient Aerator:** Equipped with a no-splashing aerator, providing a clear and aerated stream with a maximum flow rate of 1.2 GPM (4.5 L/min) at 60 PSI.
- **Dual Handles:** Two handles allow for precise and effortless adjustment of water flow and temperature.
- **Durable Finish:** Tarnish, scratch, and corrosion-resistant brushed nickel metal construction.
- **Complete Package:** Includes a solid metal pop-up drain assembly and cUPC certified faucet supply lines.

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage, personal injury, or voiding of the warranty.

- Always turn off the main water supply before beginning any plumbing work.
- Wear appropriate personal protective equipment, such as safety glasses and gloves.

- Ensure all connections are secure and leak-free before restoring water supply.
- If you are unsure about any part of the installation, consult a qualified plumber.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

ALL NECESSARY HARDWARE IS INCLUDED

for quick & hassle-free Installation.




Image 3.1: All necessary hardware included for quick and hassle-free installation.

1. 4-Inch Bathroom Sink Faucet (1)
2. Plastic Escutcheon (1)
3. Mounting Nuts (2)
4. Installation Manual (1)
5. Metal Pop-up Drain (With Overflow) (1)
6. Allen Key (1)
7. Spare Hot and Cold Indicator Dots (2)
8. Faucet Supply Lines (2)

4. SPECIFICATIONS

Feature	Specification
Brand	PARLOS
Model Name	Doris 14072
Finish Type	Brushed Nickel
Material	Metal
Mounting Type	Deck Mount, 4-inch Centerset
Number of Handles	2
Hole Count	3
Maximum Flow Rate	1.2 Gallons Per Minute (4.5 L/min)
Special Feature	Lead Free
Item Weight	4.24 pounds (1.93 Kilograms)
Package Dimensions	10.4 x 8.5 x 5.3 inches

DIMENSION

Overall Height: 5.67 Inch (144mm)

Spout Height: 3.94 Inch (100.2mm)

Spout Reach: 5.11 Inch (129.8mm)



Will This Faucet Fit My Basin?



Image 4.1: Faucet dimensions and sink compatibility details.

5. INSTALLATION

This section provides step-by-step instructions for installing your PARLOS Doris 14072 bathroom faucet. Ensure you have all necessary tools and components before starting.

Required Tools (Not Included):

- Adjustable Wrench
- Phillips Head Screwdriver
- Plumber's Tape (Thread Seal Tape)
- Basin Wrench (Optional, for tight spaces)
- Safety Glasses

Installation Steps:

1. **Prepare the Sink:** Ensure the sink surface is clean and dry. The faucet is designed for 3-hole deck mounted installations with sink hole diameters between 1.02"-1.22" and a maximum deck thickness of 1.1".

2. **Place Plastic Escutcheon:** Position the plastic escutcheon on the sink deck, ensuring the side with the stick-out faces up towards the faucet.
3. **Install Faucet Body:** Insert the faucet body through the holes in the escutcheon and sink.
4. **Secure Faucet:** From underneath the sink, tighten the mounting nuts onto the faucet shanks to secure the faucet to the sink. Hand-tighten first, then use a wrench for a snug fit.
5. **Connect Supply Lines:** Connect the hot and cold faucet supply lines to the corresponding inlets on the faucet body. Use plumber's tape on the threads and tighten securely with a wrench. Connect the other ends to your hot and cold water supply valves.
6. **Install Pop-up Drain:**
 - a. Disassemble the pop-up drain, ensuring the sealing gasket, mounting gasket, and locking nut are ready.
 - b. Place the sealing gasket on the top of the drain hole.
 - c. Slide the drain body through the drain hole from the top.
 - d. From underneath the sink, place the mounting gasket and screw the locking nut onto the drain body. Hand-tighten to ensure a leak-free seal.
 - e. The pop-up drain is compatible only with sinks that have an overflow hole.
7. **Check for Leaks:** Once all connections are made, slowly turn on the main water supply. Check all connections for any signs of leaks. Tighten any leaking connections as needed.

Your browser does not support the video tag.

Video 5.1: Official PARLOS installation guide for a 4-inch centerset bathroom sink faucet. This video demonstrates the steps for installing the faucet and connecting the supply lines.

6. OPERATION

The PARLOS Doris 14072 faucet features two handles for controlling water flow and temperature.

- **Cold Water:** Turn the right handle counter-clockwise to open for cold water.
- **Hot Water:** Turn the left handle counter-clockwise to open for hot water.
- **Temperature Control:** Adjust the hot and cold handles simultaneously to achieve the desired water temperature.
- **Water Flow:** The handles control the volume of water flow. Turn them further counter-clockwise for increased flow.
- **Pop-up Drain:** Press the top of the drain stopper to close it and retain water in the sink. Press again to open and allow water to drain.

Your browser does not support the video tag.

Video 6.1: A demonstration of the PARLOS Centerset Lavatory Faucet, showcasing its design and water flow.

7. MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your PARLOS faucet.

Cleaning Instructions:

- Clean the faucet regularly with a soft, damp cloth.
- Use mild soap and water if necessary. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as

these can damage the brushed nickel finish.

- Wipe the faucet dry after each use to prevent water spots and mineral buildup.

Aerator Maintenance:

- If water flow decreases or becomes irregular, the aerator may be clogged with debris.
- Unscrew the aerator from the spout.
- Rinse the aerator screen under running water to remove any particles.
- Reinstall the aerator by screwing it back into the spout.

8. TROUBLESHOOTING

If you encounter any issues with your faucet, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator or partially closed supply valves.	Clean the aerator (see Maintenance section). Ensure hot and cold water supply valves are fully open.
Leaks at Faucet Base	Loose mounting nuts or improper escutcheon placement.	Tighten mounting nuts from underneath the sink. Ensure the escutcheon is correctly seated.
Leaks at Supply Line Connections	Loose connections or insufficient plumber's tape.	Turn off water supply. Tighten connections. If leaking persists, reapply plumber's tape and re-tighten.
Pop-up Drain Not Sealing/Draining	Improper gasket placement or debris.	Ensure the sealing gasket is correctly positioned. Check for debris obstructing the drain mechanism.

9. WARRANTY AND SUPPORT

PARLOS products are manufactured to high-quality standards and are backed by a manufacturer's warranty. For specific warranty details, product support, or to order replacement parts, please refer to the warranty card included with your purchase or visit the official PARLOS website.

Contact Information:

- **Website:** [Visit the PARLOS Store on Amazon](#)
- **Manufacturer:** PARLOS HOME FURNISHING CO.,LTD