

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tiny Love](#) /

› [Tiny Love 4-in-1 Here I Grow Mobile Activity Center Instruction Manual](#)

### Tiny Love WA077ETT

# Tiny Love 4-in-1 Here I Grow Mobile Activity Center

Brand: **Tiny Love** | Model: **WA077ETT**

## INTRODUCTION

---

The Tiny Love 4-in-1 Here I Grow Mobile Activity Center is designed to support your child's development through various stages. It offers four versatile modes: a stationary activity center, a push-along walker, a jumper, and a baby walker with wheels. This product is suitable for children who can sit up and hold their head upright unassisted, and are not yet able to walk or climb out of the product. It supports babies up to 30 lbs or 32 inches.



*Image: The Tiny Love 4-in-1 Here I Grow Mobile Activity Center in its assembled form, showcasing its vibrant green and teal colors and various attached developmental toys.*

## KEY FEATURES

---

- **4 Modes of Use:** Easily transforms between stationary activity center, push-along walker, jumper, and baby walker with wheels.
- **360° Swivel Seat:** Allows your baby to rotate and interact with all surrounding toys when in stationary activity center mode.
- **Developmental Activities:** Features 6 developmental toys and over 28 different activities designed to foster cognition, language, fine and gross motor skills, senses, creativity, and emotional intelligence.
- **Adjustable Height:** Offers 3 adjustable height positions to grow with your child.
- **Easy to Clean:** The seat pad is removable and machine washable for convenient cleaning.
- **Compact Storage:** Designed to nest inside its outer frame for hassle-free storage when not in use.

## SETUP

---

Follow these steps to assemble your Tiny Love 4-in-1 Here I Grow Mobile Activity Center:

- 1. Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the packing list (not provided here, refer to physical manual) are present.
- 2. Assemble Base and Legs:** The main frame and legs are largely pre-assembled. Ensure the legs are securely clicked into place.
- 3. Attach Seat:** Insert the seat into the designated opening in the activity center's top tray. Ensure it is securely fastened.
- 4. Attach Developmental Toys:** The activity center comes with various toys. These toys can be easily popped into and out of the designated slots on the top tray, allowing for customization and easy cleaning.
- 5. Adjust Height:** The activity center features three adjustable height levels. Locate the red buttons on the legs. Press these buttons to adjust the height of the activity center to suit your child's height, ensuring their feet can comfortably touch the floor or footrest.



*Image: The activity center shown in its compact, nested storage configuration, demonstrating how the frame collapses for space-saving.*

## OPERATING MODES

The Tiny Love 4-in-1 Here I Grow Mobile Activity Center adapts to your child's growth and developmental needs with four distinct modes:



*Image: A visual representation of the four modes: Swivel (stationary), Push, Bounce, and Walk.*

## 1. Stationary Activity Center (Swivel/Bounce Mode)

In this mode, the activity center remains stationary, providing a safe and engaging space for your child. The seat can swivel 360° to allow your baby to interact with all the toys around the tray. To enable bouncing, ensure the red lock/unlock mechanisms on the legs are in the 'unlocked' position. To prevent bouncing and keep the unit stable, engage the 'locked' position.



*Image: A baby seated in the activity center, demonstrating the 360-degree swivel seat feature, allowing access to all toys.*



*Image: A baby happily engaged with the toys while sitting in the stationary activity center mode.*

## 2. Push-Along Walker Mode

As your child begins to stand and take their first steps, the activity center can be converted into a push-along walker. This mode provides support and encourages independent movement. Ensure the wheels are unlocked for smooth movement.



*Image: A toddler standing behind the activity center, using it as a push-along walker, indicating the transition to mobile play.*

### **3. Baby Walker with Wheels Mode**

For more advanced mobility, the activity center can function as a traditional baby walker with wheels. This allows your child to move freely around a safe environment. Always ensure the wheels are unlocked for this mode.



*Image: A baby inside the activity center, utilizing it in walker mode, with visible wheels for movement.*

## **Developmental Toys**

The activity center includes 6 unique developmental toys and over 28 activities designed to stimulate your child's senses and encourage learning. These toys can be rearranged or removed as desired.

Nests compactly for easy storage



*Image: A detailed view of the activity center's top tray, highlighting the various interactive toys such as a spinning bee, a rattling hedgehog, and a bird with a bobblehead.*

## MAINTENANCE

- **Seat Pad Cleaning:** The seat pad is machine washable. Remove it from the activity center and follow the care instructions on the label.



*Image: The activity center with its seat pad detached, illustrating the ease of removal for cleaning purposes.*

- **Frame and Toy Cleaning:** Wipe down the plastic frame and toys with a damp cloth and mild soap. Rinse thoroughly and air dry. Avoid harsh chemicals or abrasive cleaners.
- **Regular Inspection:** Periodically check all parts for wear, damage, or loose components. Discontinue use if any part is broken or missing.

## TROUBLESHOOTING

- **Difficulty Adjusting Height:** Ensure the red buttons on the legs are fully depressed when attempting to adjust the height. Apply gentle pressure while moving the frame up or down.
- **Unit Not Bouncing/Swiveling:** Check that the lock/unlock mechanisms for bouncing and the swivel seat are in the correct 'unlocked' position for the desired function.
- **Wheels Not Moving Smoothly:** Ensure the wheel locks are disengaged. Clean any debris from the wheels. On carpeted surfaces, movement may be more restricted compared to hard floors.
- **Toys Not Staying in Place:** Ensure toys are firmly pressed into their designated slots until they click securely.
- **Child Not Comfortable:** Verify the height adjustment is appropriate for your child's height and that they meet the minimum age/strength requirements to sit upright unassisted.

## SPECIFICATIONS

---

Attribute	Value
Product Dimensions	7.63 x 28.5 x 24.5 inches
Item Model Number	WA077ETT
Item Weight	13.14 pounds
Material Type	Plastic
Minimum Weight Recommendation	6 Kilograms
Maximum Weight Recommendation	30 lbs (approx. 13.6 kg)
Maximum Height Recommendation	32 inches
Batteries Required	No
Color	Meadow Days

## SAFETY INFORMATION

---

### WARNING: Never leave child unattended. Always keep child in view while in product.

- This activity center is intended for children who can sit up unassisted and are not yet able to walk or climb out of the product.
- Discontinue use of the product if the child reaches 30 lbs (13.6 kg) or 32 inches (81 cm) in height, or can walk or climb out.
- Always place the activity center on a flat, level surface. Never use on elevated surfaces.
- Keep the product away from stairs, steps, heat sources, and electrical cords.
- Regularly inspect the product for any loose parts, damage, or signs of wear. Do not use if any part is broken or missing.
- Ensure all locking mechanisms are properly engaged before placing your child in the activity center.

## WARRANTY & SUPPORT

---

For detailed warranty information and customer support, please refer to the official Tiny Love website or contact their customer service department. A comprehensive user manual in PDF format is also available for download:

[Download User Manual \(PDF\)](#)

Please retain your proof of purchase for any warranty claims.

## Related Documents - WA077ETT

	<p><a href="#"><u>Tiny Love 5-in-1 Here I Grow Stationary Activity Center - Instruction Manual</u></a></p> <p>Comprehensive instruction manual for the Tiny Love 5-in-1 Here I Grow Stationary Activity Center, detailing assembly, safety guidelines, parts list, and care instructions.</p>
	<p><a href="#"><u>Tiny Love 4-in-1 Here I Grow Mobile Activity Center User Guide</u></a></p> <p>User guide for the Tiny Love 4-in-1 Here I Grow Mobile Activity Center (Model WA077). Includes assembly instructions, safety warnings, usage modes, care and maintenance, and warranty information.</p>
	<p><a href="#"><u>Tiny Love 5-in-1 Here I Grow Stationary Activity Center</u></a></p> <p>Instruction guide for the Tiny Love 5-in-1 Here I Grow Stationary Activity Center, featuring 5 modes of use: Tummy time piano, Baby balance board, Stationary activity center, Toddler activity table, and Child table and chair. Includes important safety warnings and battery information.</p>
	<p><a href="#"><u>Tiny Love Gymini Sunny Day Baby Gym - Instruction Manual &amp; Safety Guide</u></a></p> <p>Comprehensive instruction guide for the Tiny Love Gymini Sunny Day baby gym (Model Number: 120650E001), covering assembly, safety warnings, battery information, cleaning, and storage. Provides essential information for safe and proper use.</p>
	<p><a href="#"><u>Tiny Love GYMINI Move &amp; Play &amp; Tiny Princess Activity Gym: Assembly and Usage Guide</u></a></p> <p>Comprehensive instruction manual for the Tiny Love GYMINI Move &amp; Play and Tiny Princess Move &amp; Play activity gyms. Learn how to assemble, use, clean, and safely operate this developmental baby gym.</p>
	<p><a href="#"><u>Tiny Love Boho Chic Luxe Developmental Gymini - Instruction Guide</u></a></p> <p>Comprehensive instruction manual for the Tiny Love Boho Chic Luxe Developmental Gymini, covering assembly, battery safety, cleaning, storage, and usage guidelines. Features multiple languages.</p>