

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WALPLUS](#) /

› [WALPLUS Chiming Cuckoo Clock \(Model WC2049\) Instruction Manual](#)

WALPLUS WC2049

WALPLUS Chiming Cuckoo Clock Instruction Manual

MODEL: WC2049

1. Introduction

Thank you for choosing the WALPLUS Chiming Cuckoo Clock. This classic, battery-operated cuckoo clock is designed to add a touch of elegance to any room while providing accurate timekeeping and a delightful hourly chime. It features adjustable volume control and a light sensor for automatic night silencing.

Please read this manual carefully to ensure proper setup, operation, and maintenance of your new cuckoo clock.

2. Package Contents

- 1 x WALPLUS Chiming Cuckoo Clock Unit
- 1 x Pendulum
- 2 x Decorative Pine Cone Weights

3. Setup Instructions

3.1 Battery Installation

Your cuckoo clock requires three (3) C-type 1.5V batteries (not included) for full functionality. Two batteries power the cuckoo sound mechanism, and one battery powers the timekeeping. Ensure correct polarity when inserting batteries.



Figure 1: Rear view of the clock with the battery compartment open. Insert three C-type batteries as indicated.

Steps:

1. Locate the battery compartment cover on the back of the clock.

2. Remove the cover.
3. Insert three (3) C-type 1.5V batteries, matching the (+) and (-) terminals correctly.
4. Replace the battery compartment cover.

3.2 Attaching Pendulum and Weights

The pendulum and decorative weights are for aesthetic purposes and do not require winding. They should be attached to the chains at the bottom of the clock.





Figure 2: The fully assembled cuckoo clock, showing the pendulum and decorative weights hanging below.

Steps:

1. Gently hook the pendulum onto the small metal loop located at the bottom center of the clock.
2. Attach the two decorative pine cone weights to the chains on either side of the pendulum.

3.3 Mounting the Clock

The clock is lightweight and can be easily mounted on a wall using a single nail or screw.



Figure 3: The cuckoo clock displayed on a wall, illustrating its size and appearance in a room setting.

Steps:

1. Choose a suitable location on your wall.
2. Insert a nail or screw into the wall, ensuring it is secure.
3. Hang the clock using the hanging notch located on the back of the unit.

3.4 Setting the Time

To set the correct time, gently rotate the minute hand (the longer hand) clockwise until the desired time is displayed. Avoid moving the hour hand directly.

Video 1: A demonstration of how to set up the cuckoo clock, including battery insertion and time adjustment.

4. Operating Instructions

4.1 Cuckoo Chime

The cuckoo bird will emerge and chime once every hour between 7 AM and 9 PM. The chime automatically silences during nighttime hours (9 PM to 7 AM) thanks to its integrated light sensor.



Figure 4: A detailed view of the cuckoo bird appearing from its small door, ready to chime.

Video 2: A short preview demonstrating the cuckoo bird emerging and chiming from the clock.

4.2 Volume Adjustment

A volume adjustment button is located on the back of the clock, allowing you to control the loudness of the cuckoo sound.



Figure 5: The back panel of the clock, highlighting the volume adjustment button and reset button.

Steps:

1. Locate the volume button on the back of the clock.
2. Rotate the button to increase or decrease the volume to your preference.

4.3 Night Sensor

The clock is equipped with a light sensor that automatically silences the cuckoo chime when the room is dark, ensuring undisturbed sleep. The chime will resume automatically when the room is illuminated again.

5. Maintenance

To keep your cuckoo clock in optimal condition, follow these simple maintenance guidelines:

- **Cleaning:** Dust the clock regularly with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Battery Replacement:** Replace all three C-type batteries when the clock's timekeeping becomes inaccurate or the cuckoo sound weakens or stops.
- **Placement:** Avoid placing the clock in direct sunlight or near extreme temperature changes, as this may affect its performance and appearance.

6. Troubleshooting

If you encounter any issues with your cuckoo clock, please refer to the following common solutions:

- **Clock not keeping accurate time:**
 - Check if the batteries are fresh and correctly installed.
 - Ensure the minute hand is not obstructed.
- **Cuckoo sound is not working:**
 - Verify that the batteries are fresh and correctly installed.
 - Check the volume adjustment button on the back of the clock to ensure it is not set to minimum or off.
 - Confirm the room is adequately lit; the night sensor will silence the cuckoo in darkness.
 - The cuckoo only chimes between 7 AM and 9 PM.
- **Cuckoo bird not emerging:**
 - This is usually related to the cuckoo sound not working. Follow the steps above.

7. Specifications

Brand	WALPLUS
Model	WC2049
Color	Yellow
Material	Plastic
Product Dimensions	7.95"W x 14.57"H
Power Source	Battery Powered (3 C batteries required, not included)
Special Features	Hourly Chime, Adjustable Volume, Night Sensor

Display Type	Analog
--------------	--------

8. Warranty & Support

This WALPLUS Cuckoo Clock comes with a **2-year manufacturer's warranty**. Please retain your receipt or e-receipt as proof of purchase to validate your warranty.

For further assistance or warranty claims, please contact WALPLUS customer support through your retailer or the official WALPLUS website.

Related Documents - WC2049

<p>Quick Start Guide</p>  <p>V1.2</p>	<p><u>Walplus Cuckoo Clock Quick Start Guide and History</u></p> <p>A quick start guide for the Walplus Cuckoo Clock, including its history, specifications, setup instructions, and warranty information.</p>
<p>Walplus Cuckoo Clock</p> <p>Quick Start Guide</p>  <p>V1.2</p>	<p><u>Walplus Cuckoo Clock Quick Start Guide and Warranty Information</u></p> <p>A comprehensive guide to setting up and using the Walplus Cuckoo Clock, including historical context, product specifications, detailed setup instructions, and information on the 2-year warranty registration process.</p>
<p>Quick Start Guide</p>  <p>V1.2</p>	<p><u>Walplus Cuckoo Clock Quick Start Guide and History</u></p> <p>A quick start guide for the Walplus Cuckoo Clock, including its history, specifications, setup instructions, and warranty information.</p>
<p>Walplus Cuckoo Clock</p> <p>Quick Start Guide</p>  <p>V1.2</p>	<p><u>Walplus Cuckoo Clock Quick Start Guide and Warranty Information</u></p> <p>A comprehensive guide to setting up and using the Walplus Cuckoo Clock, including historical context, product specifications, detailed setup instructions, and information on the 2-year warranty registration process.</p>