

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Men's Minimalist Ultra Thin Analog Quartz Date Watch Instruction Manual

OLEVS YPFS-G5869PSZ-MB-1

OLEVS Men's Minimalist Ultra Thin Analog Quartz Date Watch Instruction Manual

Model: YPFS-G5869PSZ-MB-1

1. INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your OLEVS Men's Minimalist Ultra Thin Analog Quartz Date Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Figure 1: OLEVS Men's Minimalist Ultra Thin Analog Quartz Date Watch.

2. PRODUCT OVERVIEW

The OLEVS Minimalist Ultra Thin Watch features a classic dress design with a large face and a date display. It is equipped with a reliable Japanese Quartz movement and a durable Hardlex crystal glass. The watch is designed for comfort with a genuine leather strap.

Key Features:

- **Minimalist Design:** Ultra-thin profile (6.5mm) for a sleek appearance.

- **Analog Quartz Movement:** Reliable timekeeping powered by a Japanese Quartz movement.
- **Date Display:** Convenient date function.
- **Water Resistance:** Rated for 30 meters (3 ATM) for daily use.
- **Durable Materials:** Hardlex crystal glass and genuine leather strap.




Figure 2: Key features of the OLEVS watch, including water resistance and material quality.



Figure 3: The ultra-thin profile of the OLEVS watch, measuring 6.5mm.

3. SETUP

3.1 Setting the Time

1. Gently pull the crown (the small knob on the side of the watch) out to the furthest position.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Once the time is set, push the crown back into its original position to start the watch movement.

3.2 Setting the Date

1. Gently pull the crown out to the first position (halfway).
2. Rotate the crown clockwise or counter-clockwise to adjust the date.
3. Once the date is set, push the crown back into its original position.

Note: Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism and potentially damage the movement.

4. OPERATING INSTRUCTIONS

4.1 Water Resistance Guidelines

Your OLEVS watch is water resistant up to 30 meters (3 ATM), which means it is suitable for:

- Hand washing
- Light rain exposure
- Brief immersion in water (e.g., accidental splashes)

Important Precautions:

- **DO NOT** press any buttons or pull the crown while the watch is wet or submerged in water. This can compromise the water-resistant seals.
- **DO NOT** expose the watch to steam or hot water (e.g., hot showers, saunas, hot tubs), as extreme temperature changes can damage the seals.
- This watch is **NOT** suitable for diving, snorkeling, or any prolonged underwater activities.

5. MAINTENANCE

5.1 Battery Replacement

The watch uses a S-ONY 364 SR621SW button battery, which typically lasts for 2-3 years. When the watch stops or begins to lose time frequently, it is likely that the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and prevent damage to the movement.

5.2 Cleaning and Care

- Wipe the watch case and crystal with a soft, dry cloth regularly to remove dust and fingerprints.
- For the genuine leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals, which can cause drying, cracking, or discoloration.
- If the leather strap gets wet, gently pat it dry with a soft cloth and allow it to air dry completely away from direct heat.

6. TROUBLESHOOTING

6.1 Watch Not Running

- Ensure the crown is fully pushed in. If it is pulled out, the watch will not run.
- If the watch still does not run, the battery may be depleted and require replacement.

6.2 Incorrect Time or Date

- Refer to Section 3, "Setup," to correctly set the time and date.

- If the watch consistently loses or gains time, the battery may be weak, or the movement may require servicing. Contact customer support or a professional watch repair service.

7. SPECIFICATIONS

Feature	Detail
Brand	OLEVS
Model Number	YPFS-G5869PSZ-MB-1
Movement	Japanese Quartz
Battery Type	1 x LR44 (SR621SW) (included)
Case Material	Alloy
Case Thickness	6.5mm
Dial Diameter	40mm (1.6 inches)
Crystal Material	Hardlex Mineral Glass
Strap Material	Genuine Leather
Water Resistance	30 Meters (3 ATM)
Item Weight	1.23 ounces
First Available Date	June 23, 2018

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact OLEVS customer service directly. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question