

[Manuals.plus](#) /

› [AQUA CREST](#) /

› AQUA CREST EDR1RXD1 Refrigerator Water Filter Instruction Manual

AQUA CREST AQF-FF38

AQUA CREST EDR1RXD1 Refrigerator Water Filter Instruction Manual

Model: AQF-FF38

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your AQUA CREST EDR1RXD1 refrigerator water filter (Model: AQF-FF38). This filter is designed to provide clean, fresh-tasting water by reducing various impurities. It is certified by NSF 42 and 372 for performance and material safety.

The AQUA CREST AQF-FF38 filter is a replacement for models such as W10295370A, Everydrop® Filter 1, EDR1RXD1, EDR1RXD1B, WHR1RXD1, KAD1RXD1, P4RFWB, 46-9081, and 46-9930.

NSF/ANSI 42&372



REPLACEMENT ELEMENT

Tested and Certified by NSF International against **NSF/ANSI 42** in Model **EFF-6038S1** for the reduction of the claims specified on the Performance Data Sheet, and NSF/ANSI 372 ($\leq 0.25\%$ lead).

Authoritative NSF Certification In Water Purification Industry

Avoid chlorine in drinking water,
protect the respiratory system and prevent other diseases

Image: NSF/ANSI 42 & 372 Certification details for the AQUA CREST water filter, indicating testing and certification for reduction of claims and lead-free materials.

Replacement Models



W10295370A

Everydrop® Filter 1

EDR1RXD1

9081

P8RFWB2L

Image: Visual representation of the AQUA CREST filter and a list of compatible replacement models including W10295370A, Everydrop® Filter 1, EDR1RXD1, 9081, and P8RFWB2L.

SETUP AND INSTALLATION

Before installation, ensure you have the correct filter model for your refrigerator. The AQUA CREST AQF-FF38 is designed for a precise fit.

Confirm The Right Fit Model

INCOMPATIBILITY:



AQF-FF38

**EDR1RXD1
Filter 1**



EDR2RXD1

Filter 2



EDR3RXD1

Filter 3



EDR4RXD1

**Filter 4
UKF8001**




EDR5RXD1

**Filter 5
4396508**

Image: A chart showing the AQUA CREST AQF-FF38 (EDR1RXD1 Filter 1) and other incompatible filter models (EDR2RXD1, EDR3RXD1, EDR4RXD1, EDR5RXD1) to help confirm the correct fit.

Different shape, but still perfectly compatible with your refrigerator



New Water Drinking Experience

Premium materials and precise filtration ensures high water quality.

Image: A comparison showing the shape and connection points of an original cartridge versus the AQUA CREST cartridge, highlighting their compatibility.

Installation Steps:


1. **Locate the Filter Compartment:** The water filter compartment is typically found in the top-right or bottom-left corner of your refrigerator's fresh food compartment.
2. **Prepare the Filter:** Remove the new AQUA CREST filter from its packaging.
3. **Install the Filter:**
 - Observe the correct direction for installation, often indicated by a blue label arrow on the filter.
 - Insert the filter into the compartment. You may need to press down firmly to ensure proper seating. This will not harm the connector or the refrigerator.
 - Close the filter lid. If the lid cannot be closed, press the filter down hard to ensure proper installation.
4. **Flush the System:** After installation, dispense approximately 2-3 gallons of water through the dispenser to flush out air and any carbon fines. This ensures optimal filter performance and clear water.
5. **Reset Filter Indicator:** Refer to your refrigerator's owner's manual for instructions on how to reset the "Change Filter" indicator light, if applicable.

Install the water filter

You can find in the top-right corner of the refrigerator compartment.



You can find in the bottom-left corner of the refrigerator compartment.



Step 1: Notice the correct direction, when you install the filter.

Step2: Install the filter according to the blue label arrow direction and close the lid.

Note: You can press down firmly, it won't harm the connector or the fridge.

Note: If you are unable to close the filter housing cover with the filter installed, press in the direction of the pink arrow to remove the filter and then proceed to install it again by following Step2

Image: Step-by-step visual guide for installing the water filter, showing its location in the refrigerator and the correct insertion direction with arrows.

Note: If you are unable to close the filter housing cover with the filter installed, press in the direction of the pink arrow (as shown in the image) to remove the filter and then proceed to install it again by following Step 2.

OPERATING INSTRUCTIONS

Once installed, your AQUA CREST water filter will begin filtering water immediately. The filter utilizes a coconut shell carbon block to effectively reduce chlorine, taste and odor, sediment, and suspended solids from your drinking water. It does not reduce Total Dissolved Solids (TDS).

Advanced Filtration for Cleaner, Safer Water



* Tested by a third-party laboratory.

Image: A visual comparison of water quality before and after filtration, demonstrating the filter's effectiveness in providing cleaner water.

Effectively Absorb Impurities

Improve Water Taste



Chlorine



Taste and odor



Sediment



Suspended solids

Note: Do not reduce TDS!



High-grade coconut shell activated carbon block

Image: Diagram illustrating how the AQUA CREST filter effectively absorbs impurities like chlorine, taste and odor, sediment, and suspended solids using a high-grade coconut shell activated carbon block. A note indicates it does not reduce TDS.

For optimal performance, ensure the refrigerator's water dispenser is used regularly. If the dispenser has

not been used for an extended period, dispense a few cups of water before consumption.




Image: A refrigerator water dispenser in use, demonstrating smooth and stable water flow, indicating proper filter function.

MAINTENANCE AND FILTER REPLACEMENT

To maintain water quality and filter performance, it is recommended to replace your AQUA CREST water filter every **6 months** or after filtering **200 gallons** of water, whichever comes first. Overusing the filter can lead to reduced filtration effectiveness and potential secondary contamination.

Extended Lifecycle

Replace the filter in time to prevent secondary pollution



6 months

200 gallons

Image: Visual reminder to replace the filter every 6 months or 200 gallons to prevent secondary pollution and maintain an extended lifecycle.

The filter comes with month install stickers to help you track the installation date and remind you when a replacement is due.

Replacement Procedure:

1. Turn off the water supply to the refrigerator, if possible.
2. Locate the filter compartment and open the lid.
3. Remove the old filter by following the reverse of the installation steps (e.g., pressing in the direction of the pink arrow if it's stuck, then pulling out).
4. Insert the new AQUA CREST filter as described in the "Setup and Installation" section.
5. Flush the system and reset the filter indicator.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|---|--|---|
| Filter lid cannot be closed after installation. | Filter not fully seated. | Press down firmly on the filter to ensure proper installation. If still unable to close, remove the filter and re-insert, ensuring correct alignment. |
| Water flow is slow or reduced. | Air in the system; filter nearing end of life; clogged filter. | Flush 2-3 gallons of water through the dispenser to remove air. If flow remains slow, replace the filter. |
| Water has an unusual taste or odor. | New filter needs flushing; filter is expired or contaminated. | Flush 2-3 gallons of water after new installation. If taste/odor persists or filter is old, replace the filter. |
| Filter is difficult to remove. | Filter may be stuck due to prolonged use or improper initial installation. | Apply firm, steady pressure to remove. Refer to your refrigerator's manual for specific removal instructions if needed. |

SPECIFICATIONS

Model Number: AQF-FF38

Material: Lead-Free Material, Food-Grade Material, Advanced Activated Coconut Carbon Block

Product Dimensions: 6.48"D x 2.16"W x 7.28"H

External Testing Certification: NSF/ANSI 42 & 372

Filter Lifespan: 6 months or 200 gallons (whichever comes first)

Compatible Refrigerator Models: Whirlpool GSC25C4EYB00, GSC25C4EYB01, GSC25C4EYY02, GSC25C5EYW00, GSC25C5EYW01, GSC25C5EYW02, GSC25C6EYB00, GSC25C6EYW01, GSC25C6EYY00, GSC25C6EYY01, GSC25C6EYY03, GSF26C4EXB00, GSF26C4EXB02, GSF26C4EXT02, WSF26D3EXA00 (and others compatible with Everydrop® Filter 1, EDR1RXD1)

WARRANTY INFORMATION

AQUA CREST provides a Product Lifetime Warranty. This includes a 6-Month Return Policy on any filter confirmed with defects in material, workmanship, or any filter caused malfunction.

For warranty claims or further details, please contact AQUA CREST customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to troubleshoot an issue, please contact AQUA CREST customer support. Refer to the product packaging or the official AQUA CREST website for the most current contact information.

We are committed to providing quality water and support for your hydrated home.