

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Enbrighten](#) /

› [Enbrighten Vintage LED Cafe Lights Model 43375 Instruction Manual](#)

Enbrighten 43375

Enbrighten Vintage LED Cafe Lights Instruction Manual

Model: 43375

INTRODUCTION

Thank you for choosing Enbrighten Vintage LED Cafe Lights, Model 43375. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new string lights. These lights are designed for both indoor and outdoor use, featuring durable, impact-resistant bulbs and a weatherproof design for year-round enjoyment.

SAFETY INFORMATION

Please read and understand all safety instructions before installation and use. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- Ensure the power source voltage matches the product specifications (120V).
- Do not immerse the string lights or any electrical components in water.
- Always unplug the lights from the power outlet before performing any installation, maintenance, or troubleshooting.
- Do not connect more than the maximum recommended length of string lights (up to 750 feet total).
- Avoid installing lights near flammable materials or surfaces.
- Use appropriate mounting hardware (not included) to secure the lights safely.
- Do not modify the product in any way.

PACKAGE CONTENTS

Verify that all components are present in your package:

- 1 set of Enbrighten Vintage LED Cafe String Lights (24 feet, 12 bulbs)
- 12 Oil-Rubbed Bronze Lens Shades (packaged separately)

SETUP AND INSTALLATION

Follow these steps for proper installation of your Enbrighten Cafe Lights.

1. Shade Assembly

The oil-rubbed bronze shades are packaged separately and require simple assembly onto each bulb socket.



Image: Hands demonstrating the assembly of the oil-rubbed bronze shades onto the light sockets. The shades are provided separately from the main light string.

SOME ASSEMBLY REQUIRED





Image: A three-step diagram illustrating how to attach the decorative shade. Step 1: Unscrew the socket ring. Step 2: Place the shade over the bulb and onto the socket. Step 3: Screw the socket ring back on to secure the shade.


2. Mounting the Lights

These lights offer flexible mounting options. You can mount them on a flat surface or hang them from above. Mounting hardware (such as hooks, screws, nails, or guide wires) is not included and must be purchased separately.



EASY INSTALLATION AND FLEXIBLE MOUNTING OPTIONS

Mounting on a flat surface
or hang from above.
(Mounting hardware not included)



CONNECT MULTIPLE STRINGS

Heavy-duty, grounded cord
plugs into any standard outlet. Link
multiple Café Lights™ up to 750 feet.

Image: Illustration demonstrating easy installation and flexible mounting options. The diagram shows a mounting tab on the light string, suitable for securing with a screw or hook, or for hanging from a guide wire.

3. Connecting Multiple Strings

Each strand of Enbrighten Café Lights is linkable. You can connect multiple strings together, up to a maximum total length of 750 feet, from a single power outlet. Ensure the connection points are secure and protected from moisture.



Image: Close-up of hands connecting two heavy-duty, grounded power cords of the string lights. The image highlights the secure, weatherproof connection point.

OPERATING INSTRUCTIONS

To operate your Enbrighten Vintage LED Cafe Lights:

1. Ensure the lights are securely installed and all connections are tight.
2. Plug the heavy-duty, grounded cord into any standard 120V electrical outlet.
3. The lights will illuminate with a warm white glow (2700 Kelvin).
4. To turn off the lights, unplug them from the power outlet.

This model does not feature app control or color-changing capabilities; it provides a consistent warm white light.

MAINTENANCE

Your Enbrighten Cafe Lights are designed for durability and minimal maintenance.

Cleaning

To clean the lights, ensure they are unplugged from the power source. Wipe the bulbs and cords with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

Bulb Information

These lights feature lifetime LED bulbs that are impact-resistant and shatterproof. They are designed not to break if dropped, stepped on, or exposed to severe weather. Due to the lifetime LED design, bulb replacement is generally not required.



enbrighten
GUARANTEE
Lighting
for Life

NEVER REPLACE A BULB AGAIN

 **WEATHER PROOF**
Commercial grade and UL-rated
for permanent outdoor installation

 **IMPACT RESISTANT**
Durable acrylic bulbs won't
break if dropped, stepped on,
or in severe weather.

120V | **LED** | **1WATT** | **2700K**
PER LIGHT | WARM WHITE

Image: A detailed view of an Enbrighten LED bulb, highlighting its weatherproof and impact-resistant acrylic construction.
Text indicates it is 120V, LED, 1 Watt per light, and emits 2700K Warm White light.

TROUBLESHOOTING

If you encounter issues with your Enbrighten Cafe Lights, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lights do not turn on.	No power to the outlet. Loose connection. Faulty outlet.	Check the power outlet with another device. Ensure the plug is fully inserted. Verify all string connections are secure.

Problem	Possible Cause	Solution
Some bulbs are not lit.	Loose bulb in socket. Damaged bulb.	Gently twist the bulb to ensure it is seated correctly. While bulbs are designed for lifetime use, if a bulb is damaged, contact support.
Lights flicker.	Unstable power supply. Loose connection.	Ensure the power source is stable. Check all connections for tightness.

SPECIFICATIONS

Detailed specifications for your Enbrighten Vintage LED Cafe Lights, Model 43375:

Feature	Specification
Model Number	43375
Brand	Enbrighten
Item Length	24 Feet
Number of Light Sources	12
Light Source Type	LED
Light Color	Warm White
Color Temperature	2700 Kelvin
Wattage	12 watts (1 watt per bulb)
Voltage	120 Volts
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor, Outdoor
Special Features	Shatterproof, Weatherproof
Bulb Shape Size	ED28
Material	Rubber (cord), Acrylic (bulbs)
Linkable Length	Up to 750 feet



Image: Dimensional diagram of the string lights, indicating a 24-inch spacing between bulbs, a 7.8-inch drop from the main cord, and bulb dimensions of 4.125 inches in height and 1.625 inches in width.

WARRANTY

Enbrighten Vintage LED Cafe Lights are backed by a Lifetime LED Warranty. This product is designed for lasting performance and year-round installation.

SUPPORT

For further assistance, technical support, or warranty claims, please contact Jasco Products Company, LLC, the manufacturer of Enbrighten products.

Manufacturer: Jasco Products Company, LLC

You may also visit the official Enbrighten store on Amazon for more information and products: [Enbrighten Store](#)