

Winsome 94543

Winsome Marissa Kitchen Cart Model 94543 Instruction Manual

Model: 94543 | Brand: Winsome

[Setup](#)

[Operation](#)

[Maintenance](#)

[Specifications](#)

[Troubleshooting](#)

[Warranty & Support](#)

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Winsome Marissa Kitchen Cart, Model 94543. Please read these instructions carefully before use to ensure proper setup and longevity of your product.

The Marissa Kitchen Cart is designed to offer a stylish and functional workstation for your kitchen. It features a solid Beechwood top, multiple storage options, and mobile casters for convenience.

SETUP AND ASSEMBLY

Assembly is required for the Winsome Marissa Kitchen Cart. Detailed instructions are included in the product packaging. Ensure all parts are present before beginning assembly.

Key Assembly Steps:

- Unpack all components and verify against the parts list provided in the assembly guide.
- Assemble the main frame of the cart.
- Install the drawer slides and assemble the drawer.
- Attach the cabinet door and internal shelves.
- Secure the top surface.
- Install the casters, ensuring the two locking wheels are placed as indicated for stability.
- Attach the paper towel holder.

For a visual overview of the cart's features and components, please refer to the product video below.

Your browser does not support the video tag.

Video: A 360-degree view of the Winsome Marissa Kitchen Cart, demonstrating its locking drawer, adjustable shelves, and locking wheels.



Image: Front view of the assembled Winsome Marissa Kitchen Cart in Walnut finish with a natural wood top.



Image: Diagram showing the dimensions of the Winsome Marissa Kitchen Cart: 36.18 inches wide, 18.5 inches deep, and 34.61 inches high.

OPERATION AND FEATURES

The Marissa Kitchen Cart is designed for versatile use in your kitchen or dining area.

- **Work Surface:** The solid Beechwood top provides a durable surface for food preparation or serving.
- **Storage Drawer:** A wide drawer offers convenient storage for utensils and small kitchen tools.
- **Open Shelves:** Three removable open shelves provide accessible storage for dishes, glassware, or other items.
- **Cabinet Storage:** A cabinet with an adjustable shelf offers enclosed storage for larger items.
- **Mobility:** The cart is equipped with professional-grade casters for easy movement. Two of these casters are lockable to secure the cart in place when needed.
- **Paper Towel Holder:** A wooden handle on the side doubles as a paper towel holder for quick access.



Image: The Winsome Marissa Kitchen Cart with its top drawer pulled out and the cabinet door open, revealing internal storage.



Image: Close-up view of one of the locking caster wheels on the Winsome Marissa Kitchen Cart, showing the locking mechanism.





Image: Side view of the Winsome Marissa Kitchen Cart, highlighting the integrated paper towel holder.

CARE AND MAINTENANCE

To maintain the appearance and longevity of your Winsome Marissa Kitchen Cart, follow these care instructions:

- **Cleaning:** Wipe the cart clean with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the wood finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the wood.
- **Heat and Moisture:** Avoid placing hot items directly on the wood surface. Use coasters or protective pads. Protect the cart from excessive moisture.
- **Regular Inspection:** Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary.

PRODUCT SPECIFICATIONS

Model Number	94543
Brand	Winsome
Product Dimensions (D x W x H)	18.5" x 36.18" x 34.61"
Item Weight	48.4 pounds
Maximum Weight Recommendation	50 Pounds
Frame Material	Wood (Solid / Composite wood)
Furniture Finish	Walnut
Color	Walnut
Shelf Type	Tiered Shelf
Number of Shelves	4 (comprising three open shelves and one adjustable shelf within the cabinet)
Assembly Required	Yes

TROUBLESHOOTING

If you encounter any issues with your Winsome Marissa Kitchen Cart, please consider the following:

- **Stability Issues:** Ensure all screws and fasteners are securely tightened. Verify that the locking casters are engaged when the cart needs to remain stationary.
- **Drawer Operation:** Check that the drawer slides are correctly installed and free from obstructions.
- **Missing Parts or Damage:** If any parts are missing or damaged upon arrival, please contact customer support immediately.

WARRANTY AND CUSTOMER SUPPORT

Winsome Trading Inc. stands behind its products. If you receive a damaged or defective item, please

contact the retailer where you purchased the product or Winsome's support team for assistance. Customer service is available to assist with any questions or concerns regarding your product. For further information, you may visit the official Winsome Store:[Winsome Store on Amazon](#)