

Tribesigns HOGA-YS0071-X

Tribesigns Computer Desk User Manual

Model: HOGA-YS0071-X | Brand: Tribesigns

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your Tribesigns Computer Desk. Designed for home and office use, this desk offers a spacious and sturdy workspace. Please read this manual thoroughly before assembly and use to ensure proper setup and longevity of your product.

SAFETY INFORMATION

For safe use, always adhere to the following guidelines:

- Ensure the load on the desk does not exceed 900 lbs (total weight capacity).
- Properly fit the adjustable leg pads to ensure stability, especially on uneven floor surfaces.
- Refer to the assembly instructions carefully to ensure correct and secure setup.
- Keep small parts away from children during assembly.

PARTS LIST

Before beginning assembly, verify that all components are present and undamaged. The package should contain:

- 1 x Desktop (Laminated MDF)
- 4 x Metal Legs (Heavy duty powder coated steel)
- 2 x Leg Bars
- Adjustable Leg Pads (pre-installed or separate)
- Assembly Hardware (screws, hex key)

EASY ASSEMBLE

Only 2 Steps




Figure 1: Exploded view of desk components for assembly.

ASSEMBLY INSTRUCTIONS

The Tribesigns Computer Desk is designed for quick and easy assembly, typically taking less than 15 minutes. Follow these steps:

1. **Step 1: Attach Legs to Desktop.** Carefully place the desktop upside down on a soft, clean surface to prevent scratches.
2. **Step 2: Secure Leg Bars.** Attach the four metal legs to the designated points on the underside of the desktop using the provided screws and hex key. Ensure the leg bars are properly aligned and facing each other for correct orientation.
3. **Step 3: Tighten Screws.** Securely tighten all screws. Avoid over-tightening to prevent damage to the paint or material.
4. **Step 4: Adjust Leg Pads.** Once assembled, carefully flip the desk upright. Adjust the leg pads at the bottom of each leg to ensure the desk is stable and level on your floor.

EASY ASSEMBLE

Only 2 Steps




Figure 2: Simplified assembly steps.

OPERATION AND USAGE

Your Tribesigns Computer Desk is designed for versatile use in various settings:

- **Spacious Desktop:** The 63" (L) x 23.6" (W) desktop provides ample space for your computer, monitor, printer, and other office essentials.
- **Generous Leg Room:** With an underneath leg distance of 58.26", the desk offers comfortable leg room, suitable for various users, including taller individuals.
- **Versatile Application:** Ideal for use as a computer desk, office desk, study table, or writing desk in home offices, dorm rooms, or other personal workspaces.
- **Stability:** The heavy-duty powder-coated steel frame and adjustable leg pads ensure the desk remains stable even on uneven surfaces.



Figure 3: Tribesigns Computer Desk in a typical office setup.



Figure 4: Detailed view of the desk surface and leg design.

MAINTENANCE

To ensure the longevity and appearance of your Tribesigns Computer Desk, follow these simple maintenance tips:

- **Cleaning:** Wipe the desk surface with a damp cloth and dry immediately. Avoid using harsh chemicals or abrasive cleaners, which can damage the laminated MDF.
- **Spills:** Promptly clean up any spills to prevent staining or damage to the desktop.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Avoid Excessive Weight:** Do not place items exceeding the maximum weight capacity of 900 lbs on the desk.
- **Protect Surface:** Use coasters for drinks and mouse pads for computer mice to protect the desktop from scratches and moisture.




Figure 5: Close-up of the desktop material, highlighting its easy-to-clean surface.

TROUBLESHOOTING

If you encounter any issues with your Tribesigns Computer Desk, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Desk wobbles	Uneven floor surface; loose screws; leg pads not adjusted.	Adjust the leg pads until the desk is stable. Check and tighten all assembly screws. Ensure legs are installed correctly.
Difficulty assembling legs	Legs or leg bars are not oriented correctly.	Ensure the leg bars are facing each other as indicated in the assembly diagram. Do not force parts.
Scratches on desktop	Sharp objects or abrasive cleaning.	Use protective mats or coasters. Avoid dragging objects across the surface. Clean with soft cloth.

SPECIFICATIONS

Feature	Detail
Model Number	HOGA-YS0071-X
Color	Walnut + Black Leg
Product Dimensions (L x W x H)	160.02 cm x 59.94 cm x 72.9 cm (63" x 23.6" x 28.7")
Item Weight	21.95 kg (48.4 lbs)
Weight Capacity	Up to 900 lbs
Primary Material	E1 Particle Board & Metal
Top Material Type	Engineered Wood (Laminated MDF)
Base Material	Metal (Powder Coated Steel)
Assembly Required	Yes
Style	Modern
Special Features	Scratch Resistant, Adjustable Leg Pads



Figure 6: Desk dimensions overview.

Reason to Choose Tribesigns Furniture

Modern simple sturdy computer desk with lots of leg room
Frame and legs made from heavy square tube steel




Triangular Junction Design
ensure the stable of desk



Extra Steel Support Bar
enhance the load bearing



Superior Adjustable Leg Pads
keep desk stable even on uneven floor



1.97" thicker steel leg
more solid and sturdy

Figure 7: Key structural features of the desk.

WARRANTY AND SUPPORT

Tribesigns provides an **18-month warranty** for this product, covering manufacturing defects and material flaws under normal use. For any questions, concerns, or assistance with your product, please contact Tribesigns customer service. Our friendly customer service team is ready to assist you.

Please visit the official Tribesigns website or refer to your purchase documentation for specific contact details and warranty claim procedures.

© 2024 Tribesigns. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question