Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Marvel /
- Marvel Spiderman Kids Digital Wristwatch SMH4000 Instruction Manual

Marvel SMH4000

Marvel Spiderman Kids Digital Wristwatch SMH4000 Instruction Manual

Model: SPD4564

Introduction

This manual provides comprehensive instructions for the Marvel Spiderman Kids Digital Wristwatch, model SPD4564. This timepiece is designed for children and features a vibrant Spiderman-themed digital display, a light-up function, and a comfortable, adjustable strap. Please read this manual carefully to ensure proper use and maintenance of your watch.






Image 1: Front view of the Marvel Spiderman Kids Digital Wristwatch, showing the digital time display and Spiderman character on the dial.

PACKAGE CONTENTS

- Marvel Spiderman Kids Digital Wristwatch (Model SPD4564)
- Instruction Manual (this document)
- Warranty Card (if applicable)





Image 2: The Marvel Spiderman Kids Digital Wristwatch shown in its original retail packaging.

SETUP AND INITIAL USE

1. Battery Activation

The watch comes with a pre-installed battery. If the display is not active, gently pull out any plastic tab from the side of the watch crown or button area. This tab prevents battery drain during storage.

2. Setting the Time

- 1. Locate the button(s) on the side of the watch case. Typically, there is one main button for setting.
- 2. Press the button once to display the time.
- 3. To enter setting mode, press and hold the button for approximately 3-5 seconds until the hour digit starts flashing.
- 4. While the hour digit is flashing, press the button repeatedly to advance the hour.
- 5. Once the correct hour is set, press and hold the button again for 3-5 seconds until the minute digits start flashing.
- 6. Press the button repeatedly to advance the minutes.
- 7. After setting the minutes, press and hold the button one last time for 3-5 seconds to exit setting mode. The time will now be set.

Note: The exact button functions may vary slightly. Refer to the watch's physical buttons for specific indicators if available.

OPERATING INSTRUCTIONS

1. Displaying Time

Press the main button once to illuminate the digital display and show the current time. The display will typically remain active for a few seconds before turning off to conserve battery life.

2. Light-Up Function

This watch features a flashing light-up function. To activate it, press the designated light button (often a separate button or a secondary press of the main button). The watch will illuminate with flashing lights, adding a fun visual effect. The lights will automatically turn off after a short period.





Image 3: The Marvel Spiderman Kids Digital Wristwatch worn on a wrist, demonstrating its size and fit.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the watch with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but avoid excessive moisture.
- Water Resistance: This watch is generally splash-resistant but not waterproof. Avoid submerging it in water, showering, or swimming while wearing it.
- **Temperature:** Avoid exposing the watch to extreme temperatures, both hot and cold, as this can affect battery life and display performance.
- **Impact:** While designed for children, avoid dropping the watch or subjecting it to strong impacts, which can damage internal components.

• Battery Replacement: When the display dims or stops working, the battery may need replacement. This typically requires a small screwdriver and a compatible watch battery (e.g., SR626SW or similar button cell). It is recommended to have battery replacement performed by a qualified technician to ensure proper sealing and function.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch display is blank.	Battery tab not removed, or battery is depleted.	Ensure battery tab is removed. If still blank, replace the battery.
Time is incorrect.	Time was not set correctly or reset.	Follow the "Setting the Time" instructions in the Setup section.
Light-up function not working.	Low battery or button malfunction.	Replace the battery. If the issue persists, contact support.

SPECIFICATIONS

• Brand: Marvel

• Model Number: SPD4564 (also referred to as SMH4000)

• Display Type: Digital

• Case Material: Transparent Plastic

• Dial Size: 40 mm (approximate)

• Strap Material: Transparent Rubber

• Closure Type: Traditional Buckle

• Special Features: Spiderman-themed dial, Flashing Light-Up Function

• Product Dimensions: 3 x 8 x 18 cm (approx. 1.18 x 3.15 x 7.09 inches)

• Item Weight: 26 g (approx. 0.92 ounces)

• Battery: 1 x Product-specific battery (included)

• First Available Date: June 29, 2018

WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. Please refer to the included warranty card for specific terms and conditions, including warranty period and coverage details. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact your retailer or the manufacturer directly. Keep your proof of purchase for warranty validation.

Manufacturer: Spiderman (as per product specifications)

Related Documents - SMH4000



Marvel Universe RPG: Spider-Man's Guide to New York - Rules, Characters, and Adventures

Explore the Marvel Universe Roleplaying Game with Spider-Man's Guide to New York. This supplement offers detailed character profiles, new game actions and modifiers, rules for creating adventures, and lore about Marvel's New York City. Perfect for GMs and players.



Marvel United: Multiverse - Livret de Règles Officiel

Apprenez à jouer à Marvel United: Multiverse avec ce livret de règles complet. Découvrez les héros, le vilain, la mise en place, le déroulement du jeu, les modes spéciaux et plus encore.



Splendor: Marvel Board Game Rules and Gameplay Guide

Comprehensive guide to Splendor: Marvel, the board game combining Marvel Super Heroes with strategic token collection and card recruitment. Learn setup, gameplay, and how to win the Infinity Gauntlet.



Marvel Undercounter Refrigeration Owner's Guide & Service Manual MLWD224-SS01A

Comprehensive owner's guide and service manual for the Marvel MLWD224-SS01A undercounter refrigeration unit. Includes installation, maintenance, troubleshooting, and warranty information.



Marvel Villainous Board Game Rules and Instructions

Official rules and instructions for the Marvel Villainous board game. Learn how to play as iconic Marvel villains like Thanos, Hela, Killmonger, Ultron, and Taskmaster to dominate the Marvel universe.



Marvel MRRE215-SS31A Undercounter Refrigerator: Owner's Guide & Service Manual

Comprehensive owner's guide and service manual for the Marvel MRRE215-SS31A undercounter refrigerator, covering installation, operation, maintenance, troubleshooting, and warranty information.