

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Lumisky](#) /

> [Lumisky SO PLAY Bluetooth Speaker with LED Light \(21x21xH30\) Instruction Manual](#)

Lumisky SO PLAY

Lumisky SO PLAY Bluetooth Speaker with LED Light Instruction Manual

Model: SO PLAY (21x21xH30)

INTRODUCTION

Thank you for choosing the Lumisky SO PLAY Bluetooth Speaker with LED Light. This versatile device combines a portable wireless speaker with an adjustable LED light, perfect for enhancing any indoor or outdoor environment. This manual provides essential information for safe and efficient use, including setup, operation, maintenance, and troubleshooting.

PRODUCT OVERVIEW

Package Contents

- 1 Lumisky SO PLAY Speaker Lamp
- 1 Remote Control
- 1 Power Cord (USB charging cable)

Key Features

- Modern and portable design with a convenient handle.
- Wireless Bluetooth connectivity for audio streaming from smartphones and tablets.
- Adjustable LED lighting: white and multicolor options.
- Remote control for easy management of light and audio functions.
- Waterproof construction for outdoor use.
- Integrated speaker with 10W maximum output.



Image: Lumisky SO PLAY Bluetooth Speaker with LED Light. This image shows the speaker in its white, unlit state, highlighting its modern design and clear handle for portability.



Image: Lumisky SO PLAY speaker glowing white. The speaker is depicted in an outdoor setting, demonstrating its illumination capability and suitability for various environments.



Image: Lumisky SO PLAY speaker glowing green. This image illustrates the speaker's ability to display different LED colors, shown here with a vibrant green light on an indoor table.

SETUP

Charging the Device

1. Connect the provided USB charging cable to the charging port on the speaker.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light (if present) will typically illuminate red during charging and turn green when fully charged.
4. Allow approximately 4-6 hours for a full charge before first use.



Image: USB Charging Cable. This cable is used to recharge the Lumisky SO PLAY speaker's internal battery.

Powering On/Off

- To power on the speaker, press and hold the power button located on the side of the unit or use the 'ON' button on the remote control.
- To power off, press and hold the power button again or use the 'OFF' button on the remote control.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is powered on.
2. Activate Bluetooth on your smartphone, tablet, or other compatible device.
3. Search for available Bluetooth devices. The speaker will appear as 'SO PLAY' or similar.
4. Select 'SO PLAY' from the list to initiate pairing. A confirmation sound may indicate successful pairing.
5. Once paired, you can stream audio from your device to the speaker.

LED Light Control

Use the provided remote control to manage the LED lighting:

- **ON/OFF:** Turn the light on or off.
- **R, G, B, W:** Select Red, Green, Blue, or White light.
- **Color Buttons:** Additional buttons for various preset colors.
- **Brightness Control:** Use the up/down arrows to adjust the light intensity.
- **Mode Buttons (M I, M II, M III):** Cycle through different light modes (e.g., fade, flash, strobe).



Image: Lumisky SO PLAY Remote Control. This remote allows users to control both the speaker's LED lighting and audio playback functions.

Audio Playback

Once paired via Bluetooth, you can control audio playback directly from your connected device or using the remote control:

- **Play/Pause:** Use the Play/Pause button on the remote.
- **Next/Previous Track:** Use the skip buttons on the remote.
- **Volume Control:** Adjust volume using the volume up/down buttons on the remote or directly from your connected device.

CARE AND MAINTENANCE

Cleaning

- Ensure the speaker is powered off and disconnected from the charging cable before cleaning.
- Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- Avoid getting water into the charging port when cleaning, despite its waterproof rating.

Water Resistance

The Lumisky SO PLAY speaker is designed to be waterproof, making it suitable for outdoor use and exposure to splashes. However, it is not intended for prolonged submersion in water. Ensure the charging port cover (if present) is securely closed when exposed to moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker fully. Press and hold the power button for a few seconds.

Problem	Possible Cause	Solution
Bluetooth not connecting.	Speaker not in pairing mode; Device Bluetooth off; Speaker too far from device.	Ensure speaker is on and in pairing mode. Turn Bluetooth off/on on your device. Move device closer to speaker (within 10 meters).
No sound or poor sound quality.	Volume too low; Device not properly paired; Interference.	Increase volume on both speaker and connected device. Repair the device. Move away from other electronic devices.
LED light not working.	Light turned off; Remote battery low; Speaker battery low.	Press the 'ON' button on the remote. Replace remote battery if necessary. Charge the speaker.

TECHNICAL SPECIFICATIONS

- **Model Name:** SO PLAY
- **Brand:** Lumisky
- **Dimensions:** 21 x 21 x 30 cm
- **Weight:** 980 g
- **Material:** Plastic, Rotomolded Polyethylene
- **Connectivity Technology:** Bluetooth, USB (for charging)
- **Speaker Output Power:** 10 Watts (Max)
- **Surround Sound Channel Configuration:** 2.0
- **Light Type:** LED
- **Luminous Flux:** 100 lm
- **Power Consumption (Light):** 5 Watts (Max)
- **Power Source:** Battery Powered
- **Control Method:** Remote Control
- **Waterproof:** Yes
- **Compatible Devices:** Smartphone, Tablet

For detailed energy efficiency information, please refer to the EU Energy Label: [EU Energy Label \(EPREL Database\)](#)

WARRANTY AND CUSTOMER SUPPORT

The Lumisky SO PLAY speaker comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the documentation provided at the time of purchase or contact Lumisky customer support directly.

If you encounter any issues not covered in the troubleshooting section or require further assistance, please visit the official Lumisky website or contact their customer service department for expert support.