

[manuals.plus](#) /› [POLTI](#) /› [POLTI Easy Plus Steam Cleaner User Manual](#)

POLTI PGNA0002

POLTI Easy Plus Steam Cleaner User Manual

Model: PGNA0002

Brand: POLTI

1. INTRODUCTION AND PRODUCT OVERVIEW

The POLTI Easy Plus Steam Cleaner is a portable, handheld device designed for chemical-free cleaning and sanitization across various surfaces in your home and vehicle. Utilizing high-pressure steam, it effectively removes dirt, grime, and stains while reducing allergens.

This versatile unit is equipped with multiple attachments to tackle diverse cleaning tasks, from kitchen countertops and grout to car interiors and upholstery. Its compact and lightweight design ensures ease of use and portability.



Image: The POLTI Easy Plus Steam Cleaner, a compact white and green handheld unit with a nozzle, ready for use.

2. SAFETY INFORMATION

Always prioritize safety when operating the steam cleaner. Read all instructions before use.

- **Chemical-Free Cleaning:** The unit operates solely with water, eliminating the need for harsh chemical cleaners.
- **Patented Safety Cap:** The safety cap is designed not to unscrew if there is residual pressure inside the boiler, preventing accidental steam release.
- **High Temperature Steam:** The steam reaches temperatures up to 275°F (135°C). Exercise extreme caution to avoid burns. Do not direct steam at people, pets, or electrical appliances.
- **Child Lock:** The unit features a special child lock to prevent involuntary steam delivery.
- **Cool Down Period:** Allow the unit to cool down completely after each session before refilling or storing.

SAFETY CAP

The Polti Vaporetto safety cap does not unscrew if there is still a minimal residual pressure inside the boiler.



Image: A close-up view of the POLTI Vaporetto's safety cap, highlighting its design to prevent opening under pressure.

3. PRODUCT COMPONENTS AND ACCESSORIES

The POLTI Easy Plus Steam Cleaner comes with a variety of attachments to enhance its cleaning capabilities:

- **Main Unit:** The handheld steam generator.
- **Flexible Hose:** Extends reach for cleaning hard-to-access areas.
- **Window Washer:** For streak-free cleaning of glass surfaces.
- **Accessory for Grouting:** Specialized tool for cleaning grout lines.
- **Curved Nozzle:** For precise steam application in tight spaces.
- **Spatula:** For scraping off stubborn grime loosened by steam.
- **Round Nylon Brush:** General-purpose scrubbing brush.
- **Round Brass Brush:** For more abrasive scrubbing on durable surfaces.
- **Jug:** For accurate water measurement when filling the tank.
- **Cloth for Small Brush:** To be used with certain attachments for wiping and absorbing.



Includes 9 Multi-Surface Accessories

Image: An overhead view displaying the POLTI Easy Plus Steam Cleaner alongside its various accessories, including flexible hose, brushes, nozzles, and cloths.

4. SETUP

- 1. Unpack:** Carefully remove all components from the packaging.
- 2. Fill Water Tank:** Unscrew the safety cap on top of the unit. Use the provided measuring jug to pour up to 6.7 ounces (200 ml) of clean water into the tank. Do not overfill.
- 3. Secure Cap:** Screw the safety cap back on firmly until it is hand-tight.
- 4. Attach Accessories:** Select the appropriate attachment for your cleaning task. Slide the desired accessory onto the nozzle until it clicks securely into place. For the flexible hose, connect it to the main unit's steam outlet, then attach other accessories to the hose.
- 5. Power On:** Plug the 35-foot power cord into a standard 120V electrical outlet. The indicator light on the unit will illuminate, signaling that it is heating up.

6. **Heat-Up Time:** Allow approximately 3 minutes for the unit to heat up. The indicator light will turn off once the steam cleaner is ready for use.

Your browser does not support the video tag.

Video: "Polti Vaporetto - Easy Plus" - This official product video demonstrates the setup and various uses of the Polti Vaporetto Easy Plus steam cleaner, including filling the water tank, attaching accessories, and cleaning different surfaces.

5. OPERATING INSTRUCTIONS

Once the unit is heated and the indicator light is off, you can begin cleaning:

- **Steam Activation:** Press and hold the steam activation button on the handle to release continuous steam. For pulse steam, press and release the button as needed.
- **Cleaning Surfaces:**
 - **Kitchen & Bathroom Countertops:** Use the curved nozzle or a brush attachment to direct steam onto surfaces. Wipe away loosened dirt with a clean cloth.
 - **Grout:** Attach the grouting accessory or a brass brush. Apply steam directly to grout lines and scrub as necessary.
 - **Windows & Glass:** Use the window washer attachment. Apply steam to the glass, then use the squeegee to remove moisture and dirt.
 - **Upholstery & Fabrics:** For delicate fabrics, test on an inconspicuous area first. Use the small brush with a cloth cover to gently steam and refresh upholstery, drapes, and mattresses. Steam helps to clean and remove odors.
 - **Car Detailing:** The flexible hose and various brushes are ideal for cleaning car interiors, including seats, dashboards, and floor mats.
- **Runtime:** The 6.7-ounce tank provides up to 15 minutes of continuous steam. If the steam output decreases, the water tank may be low.
- **Refilling:** If refilling is needed during a cleaning session, unplug the unit and allow it to cool down completely before unscrewing the safety cap and adding more water.



Image: A collage showing the steam cleaner being used to clean a glass door, a stovetop, an oven interior, a mattress, a chair, and a bathroom sink, demonstrating its multi-surface capabilities.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your steam cleaner:

- **Empty Water Tank:** After each use, unplug the unit and allow it to cool. Carefully unscrew the safety cap and empty any remaining water from the tank.
- **Clean Accessories:** Wash all removable accessories with warm, soapy water and rinse thoroughly. Allow them to air dry completely before storing.
- **Wipe Down Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the unit in water.
- **Descaling:** Depending on your water hardness, periodic descaling may be necessary to prevent mineral buildup. Refer to the full user guide for detailed descaling instructions.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and

extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your POLTI Easy Plus Steam Cleaner, refer to the official Troubleshooting Guide for comprehensive solutions:

Common Issues:

- **No Steam Output:** Check if the unit is plugged in, if the indicator light has turned off (indicating it's heated), and if the water tank is sufficiently filled. Ensure the safety cap is securely tightened.
- **Weak Steam:** This may indicate low water level or mineral buildup. Refill the tank or consider descaling.
- **Water Leaking:** Ensure all attachments are securely fastened and the safety cap is tightly closed.

For more detailed troubleshooting steps and solutions, please download the official [Troubleshooting Guide \(PDF\)](#).

8. SPECIFICATIONS

Feature	Specification
Brand	POLTI
Model Name	Polti Vaporetto Easy Plus Handheld Steamer
Model Number	PGNA0002
Special Feature	Portable, Lightweight
Power Source	Corded Electric
Voltage	120 Volts
Wattage	1200 Watts
Tank Volume	200 Milliliters (6.7 ounces)
Maximum Temperature	275 Degrees Fahrenheit (135°C)
Product Dimensions	7.2 x 3.6 x 11.1 inches
Item Weight	5.77 pounds
Cord Length	35 feet (approx.)
Country of Origin	China

9. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the official POLTI website or contact their customer service directly.

Extended protection plans may be available for purchase to provide additional coverage beyond the standard manufacturer's warranty. Please check with your retailer for details on available protection plans.

For the complete user guide, you can download the PDF version here:[POLTI Easy Plus User Guide \(PDF\)](#).

© 2024 POLTI. All rights reserved.

For further assistance, please visit the official [POLTI Store on Amazon](#).