Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool W10490330

Whirlpool W10490330 Recirculation Kit Instruction Manual

Genuine OEM Part for Range Wall Hoods

1. Product Overview

The Whirlpool W10490330 Recirculation Kit is designed for use with range wall hoods when external venting is not feasible or desired. This kit effectively freshens and recirculates air back into your kitchen, providing an alternative to traditional outdoor ventilation.

This genuine OEM kit includes two charcoal filters, one black vent cover, and two mounting screws. It is engineered to meet Whirlpool's rigorous standards for quality and durability, ensuring reliable performance and compatibility with specified range hood models.



Image 1: Components of the Whirlpool W10490330 Recirculation Kit. This kit includes two circular charcoal filters and a black rectangular vent cover.

2. Installation and Setup

Installation of the Whirlpool W10490330 Recirculation Kit requires basic hand tools and novice repair experience. Prior to beginning any installation, ensure the appropriate circuit breaker is turned off to prevent electrical hazards. This kit is compatible with range model UXL5430BSS. Always verify compatibility with your specific range hood model number before installation.

For detailed, step-by-step installation instructions, please refer to the official Installation Manual provided by Whirlpool. A digital version of the manual can be accessed here.



Image 2: Example of a range hood, similar to those compatible with this recirculation kit, installed in a kitchen setting.

3. Operating Principles

Once installed, the recirculation kit works by drawing cooking fumes and odors through the charcoal filters. These filters absorb grease and odors, and the cleaned air is then recirculated back into the kitchen environment. This process helps maintain air quality without the need for external ducting.

4. Maintenance

For optimum performance of your range hood and the recirculation kit, it is crucial to regularly change the charcoal filters. It is recommended to change the filters at least once every 6 months, or more frequently if you notice a loss of airflow or persistent odors.

Replacing the filters is a simple process. Refer to your range hood's user manual or the kit's installation manual for specific instructions on how to access and replace the charcoal filters.




Image 3: Close-up view of the charcoal filters and vent cover, highlighting their design for easy identification during maintenance.

5. Troubleshooting

If you experience reduced airflow or persistent odors after installing the recirculation kit, consider the following:

- **Filter Condition:** Check if the charcoal filters are dirty or clogged. Replace them if necessary, especially if it has been more than 6 months since the last replacement.
- **Proper Installation:** Ensure all components of the recirculation kit are correctly installed and securely fastened according to the manual. Loose connections can affect performance.
- **Power Supply:** Verify that the range hood is receiving adequate power and that no circuit breakers have tripped.

For issues beyond basic troubleshooting, it is recommended to consult a qualified service technician or contact Whirlpool customer support. Always use genuine OEM parts for replacements to ensure proper fit, performance, and to maintain your appliance's warranty.

6. Specifications

Attribute	Detail
Brand Name	Whirlpool
Model Number	W10490330
Item Weight	1.61 pounds
Product Dimensions	8 x 11 x 7.75 inches
Part Number	W10490330
Special Features	Re-Circulation
Replaces Part Numbers	2684430, PS4704698
Kit Includes	(2) charcoal filters, (1) black vent cover, (2) mounting screws

7. Warranty and Support

Whirlpool Genuine OEM Parts are specifically designed and tested to meet Whirlpool engineering standards, ensuring the quality and longevity of your appliance. Using genuine parts helps maintain your appliance's performance and may be required to uphold warranty terms.
For over 100 years, Whirlpool has been committed to providing durable and innovative solutions for your home. For further support, warranty information, or to purchase additional genuine parts, please visit the official Whirlpool website or contact their customer service department.

© 2024 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07F314WSK

More documents and user manuals: **https://manuals.plus/**