

[Manuals.plus](#) /

› [Bedazzlinbeads](#) /

› Instruction Manual for 20 Wavy 13mm Round Silver 2 Hole Buttons Or Textured Linking Charms

Bedazzlinbeads 0658448946154

Instruction Manual: 20 Wavy 13mm Round Silver 2 Hole Buttons Or Textured Linking Charms

Model: 0658448946154

1. PRODUCT OVERVIEW

These buttons are crafted from silver with a light antique finish, providing a unique aesthetic. Their wavy shape introduces a distinctive texture, making them suitable for various design applications. Each button measures 13mm (just over 1/2 inch) in diameter and is 1.5mm thick. The two holes in each button have an inner diameter of 2.7mm, designed for easy threading. This package contains 20 buttons, ideal for both sewing projects and jewelry designs.



Figure 1: A collection of 13mm wavy silver buttons, highlighting their two-hole design and antique finish. Some buttons are visible inside their original packaging, while others are spread out, demonstrating their texture and size.

2. SETUP AND PREPARATION

Before integrating the buttons into your project, it is recommended to inspect each piece for any manufacturing inconsistencies. While these buttons are ready for immediate use, a gentle wipe with a soft, dry cloth can remove any dust or residue from packaging. No complex assembly or preparation is required.

- **Inspection:** Visually check each button for any deformities or damage.
- **Cleaning:** If desired, lightly clean with a dry, lint-free cloth. Avoid abrasive materials or harsh chemicals.
- **Hole Verification:** Ensure the two holes are clear and ready for threading.

3. USAGE INSTRUCTIONS

These versatile buttons can be utilized in various crafting and design applications. Their two-hole design makes them suitable for traditional sewing, while their aesthetic qualities also lend themselves to jewelry making as linking charms or decorative elements.

3.1. For Sewing Applications

1. **Placement:** Mark the desired button placement on your fabric.
2. **Threading:** Use a needle and thread appropriate for your fabric. Pass the needle through one hole from the back of the fabric, then through the corresponding hole on the button, and back down through the second hole on the button and into the fabric.
3. **Securing:** Repeat threading several times to secure the button firmly. Finish with a knot on the back of the fabric.

3.2. For Jewelry Making

1. **Material Selection:** Choose appropriate jewelry wire, cord, or jump rings that fit through the 2.7mm holes.
2. **Attachment:** Thread the wire or cord through the holes to integrate the button as a charm, connector, or decorative bead.
3. **Linking:** Use jump rings to connect multiple buttons or other jewelry components.

4. MAINTENANCE AND CARE

To preserve the appearance and longevity of your silver buttons, follow these care guidelines:

- **Cleaning:** Gently wipe with a soft, dry, non-abrasive cloth. Avoid using chemical cleaners, polishes, or abrasive materials, as these can damage the antique finish or the silver itself.
- **Storage:** Store buttons in a dry environment, away from direct sunlight and excessive humidity. An airtight bag or container can help prevent tarnishing.
- **Chemical Exposure:** Minimize contact with perfumes, lotions, hairsprays, and household cleaning products, which can accelerate tarnishing or cause discoloration.

5. TROUBLESHOOTING AND COMMON CONCERNS

While these buttons are designed for durability, certain environmental factors can affect their appearance over time. The most common concern with silver items is tarnishing.

5.1. Tarnishing

Silver naturally tarnishes when exposed to air and moisture, forming a dark layer. This is a normal chemical reaction and not a defect.

- **Prevention:** Follow the storage recommendations in Section 4. Storing buttons in a sealed bag with an anti-tarnish strip can significantly slow down the tarnishing process.
- **Removal:** For light tarnish, gently rub with a silver polishing cloth. For heavier tarnish, a mild silver cleaning solution designed for antique finishes may be used, but always test on an inconspicuous area first and follow product instructions carefully to avoid damaging the antique finish.

5.2. Discoloration (Beyond Tarnish)

If buttons exhibit discoloration that is not typical tarnish (e.g., green or blue spots), it may be due to prolonged exposure to harsh chemicals or extreme environmental conditions. In such cases, professional cleaning or assessment may be required.

6. PRODUCT SPECIFICATIONS

Attribute	Detail
Brand	Bedazzlinbeads
Model Number	0658448946154

Attribute	Detail
Color	Silver
Material	Silver
Shape	Round (Wavy Texture)
Number of Pieces	20
Diameter	13mm (approx. 1/2 inch)
Thickness	1.5mm
Hole Inner Diameter	2.7mm
Item Weight	0.81 ounces (total package)
Package Dimensions	3.5 x 2 x 0.25 inches
UPC	658448946154
ASIN	B07F3NF8VQ
Date First Available	December 29, 2016

7. WARRANTY AND SUPPORT

For specific warranty information or product support, please refer to the seller's policies or contact Bedazzlinbeads directly through their official channels. General product inquiries can often be resolved by reviewing the product description and specifications provided at the point of purchase.

© 2024 Bedazzlinbeads. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question