Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Seatcraft Loveseat with Center Storage Console

Seatcraft Vienna Home Theater Loveseat with Center Storage Console Instruction Manual

Model: Loveseat with Center Storage Console



Figure 0: Seatcraft Vienna Home Theater Loveseat. This image displays the complete loveseat, highlighting its design, center console, and overall appearance.

Introduction

This manual provides detailed instructions for the safe setup, operation, and maintenance of your Seatcraft Vienna Home Theater Loveseat with Center Storage Console. Please read this manual thoroughly before assembly and use to ensure proper functionality and longevity of your product. Retain this manual for future reference.

Safety Information

Important Safety Warnings:

- The product may be heavy and require assistance to assemble.
- Ensure proper tools are used during assembly.
- Keep children away from the assembly area to prevent injury.
- Regularly inspect the product for any loose parts or damage to maintain its safe use.
- Ensure all electrical connections are secure and routed safely to prevent tripping hazards or damage.
- Do not allow liquids to spill into electrical components or control panels.

Package Contents

Verify that all components are present before beginning assembly:

- 1 x Seatcraft Vienna Loveseat Base
- 2 x Detachable Backrests
- 2 x Tray Tables
- 1 x Power Cord
- 1 x User Manual (this document)

Setup and Assembly

The Seatcraft Vienna Loveseat arrives partially assembled. The backrests are detached for easier moving and installation. Assembly typically takes 30 minutes or less.

1. **Unpacking:** Carefully remove all components from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Positioning the Base:** Place the loveseat base in its desired location. Ensure there is at least 6.5 inches (16.5 cm) of clearance from the wall for the "wall hugger" recline feature.
3. **Attaching Backrests:** Align the metal brackets on the backrests with the corresponding receivers on the loveseat base. Slide the backrests down firmly until they click into place. Ensure both backrests are securely locked.
4. **Connecting Power:** Locate the power cord. Plug one end into the power port on the loveseat (usually at the back or underneath) and the other end into a standard electrical outlet. It is recommended to use a power strip with surge protection. The loveseat requires two outlets, one for each seating section.
5. **Initial Test:** Once assembled and powered, test the recline, headrest, and lumbar functions to ensure everything is working correctly.



Figure 1: Product Dimensions and Installation Clearance. This diagram illustrates the overall dimensions of the loveseat, including width, height, depth, and required wall clearance for recline. It also shows the minimum doorway width needed for installation.

Operating Instructions

Your Seatcraft Vienna Loveseat features multiple powered adjustments and convenient amenities.

Power Recline

Each seating position has independent power recline functionality. Locate the control panel, typically on the inner side of the armrest. Use the buttons to smoothly recline or return to the upright position. The loveseat offers a "wall hugger" recline, requiring minimal space behind it.

Powered Headrest

Adjust the angle of the headrest for optimal neck and head support. Use the dedicated buttons on the control panel to move the headrest up or down.



Figure 2: Powered Headrest Adjustment. This image highlights the adjustable powered headrest, demonstrating its range of motion for personalized comfort.

Powered Lumbar Support

Enhance lower back comfort with the powered lumbar support. Use the control panel buttons to increase or decrease the lumbar support to your preference.

USB Charging Ports

Each armrest is equipped with a USB charging port. Connect your compatible devices to charge them conveniently while seated.



Figure 3: USB Charging Functionality. This image shows a smartphone connected to the USB charging port located on the armrest, illustrating its convenient placement for device charging.

Center Storage Console and Cup Holders

The center console provides convenient storage space. Lift the lid to access the compartment. The console also features two integrated cup holders.



Figure 4: Center Storage Console. This image displays the open center console, highlighting the internal storage compartment and the two integrated cup holders.

Tray Tables

Two removable tray tables are included. These can be inserted into the accessory ports located on the armrests for a convenient surface for snacks or devices.

Maintenance

Proper care and maintenance will extend the life and appearance of your loveseat.

- **Cleaning:** For general cleaning, wipe the leather with a soft, damp cloth. For spills or stains, use a mild leather cleaner or follow the "Spot Clean" instructions provided by Seatcraft. Avoid harsh chemicals or abrasive cleaners.
- **Leather Care:** Periodically condition the leather to keep it supple and prevent drying or cracking. Use a leather conditioner specifically designed for top-grain leather.
- **Inspection:** Regularly check all connections, especially the backrest attachments and power cords, to ensure they are secure and undamaged.

- **Moving:** When moving the loveseat, lift it rather than dragging it to prevent damage to the frame and flooring. It is recommended to have at least two people assist with moving due to its weight.

Troubleshooting

If you encounter issues with your loveseat, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power to recline/headrest/lumbar/USB.	Power cord disconnected or not fully plugged in. Outlet not functioning.	Check that the power cord is securely plugged into both the loveseat and the wall outlet. Test the outlet with another device. Ensure both power cords (one for each seat) are connected.
Recline mechanism is stuck or not moving smoothly.	Obstruction under the loveseat. Mechanism requires lubrication.	Inspect for any objects obstructing the mechanism. Do not force the mechanism. Contact customer support if the issue persists after checking for obstructions.
Backrests feel loose.	Backrests not fully engaged in brackets.	Ensure backrests are pushed down firmly until they click into place.

If troubleshooting steps do not resolve the issue, please contact Seatcraft Customer Support.

Specifications

Feature	Detail
Brand	Seatcraft
Model	Vienna Loveseat with Center Storage Console
Product Dimensions (D x W x H)	41"D x 75"W x 43"H (104.1 cm D x 190.5 cm W x 109.2 cm H)
Fully Reclined Depth	70" (177.8 cm)
Wall Hugger Clearance	6.5" (16.5 cm)
Seat Height	43" (109.2 cm)
Seating Capacity	2
Material Type	Top-Grain Leather, Engineered Wood Frame, Foam Fill
Special Features	Power Recline, Adjustable Powered Headrest, Powered Lumbar Support, USB Charging, Center Storage Console, Cup Holders
Assembly Required	Yes
UPC	815876026913

Warranty Information

Your Seatcraft Vienna Loveseat is covered by a **1-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific details regarding coverage

and limitations, refer to the warranty card included with your product or contact Seatcraft Customer Support.

Customer Support

For assistance with assembly, operation, troubleshooting, or warranty claims, please contact Seatcraft Customer Support. Refer to the contact information provided on the Seatcraft website or your purchase documentation.
You can visit the official Seatcraft store for more information: Seatcraft Store on Amazon

© 2025 Seatcraft. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07F4V5F33

More documents and user manuals: **https://manuals.plus/**