

[Manuals.plus](#) /

› [YUHUI](#) /

› YUHUI Laptop Replacement Top LCD Cover Case for HP TPN-C125 TPN-C126 HQ-TRE RTL8723BE

YUHUI TPN-C125, TPN-C126, HQ-TRE, RTL8723BE

YUHUI Laptop Replacement Top LCD Cover Case for HP TPN-C125 TPN-C126 HQ-TRE RTL8723BE

Model: TPN-C125, TPN-C126, HQ-TRE, RTL8723BE | Brand: YUHUI

INTRODUCTION

This manual provides instructions for the installation, maintenance, and care of your YUHUI Laptop Replacement Top LCD Cover Case. This product is designed as a direct replacement for specific HP laptop models, ensuring compatibility and a refreshed appearance for your device.

SETUP: INSTALLATION GUIDE

Important Safety Notice:

Laptop repair requires technical knowledge and careful handling of electronic components. If you are not comfortable performing this installation, seek assistance from a qualified technician. Always disconnect the laptop from all power sources and remove the battery before proceeding with any internal work.

Required Tools

- Small Phillips head screwdriver
- Plastic pry tool (spudger)
- Anti-static wrist strap (recommended)

Step-by-Step Installation

1. Power off the laptop completely and disconnect the AC adapter. Remove the laptop battery if it is external.
2. Carefully remove any screws securing the old LCD cover. These are often located under rubber feet or small plastic covers around the display bezel.
3. Using a plastic pry tool, gently separate the old LCD cover from the display assembly. Work slowly around the edges to avoid damaging internal clips or cables.

4. Disconnect any cables (e.g., webcam, Wi-Fi antenna) that may be attached to the old cover. Note their routing for reassembly.
5. Position the new YUHUI Black Top LCD Cover Case. Ensure all cables are routed correctly and are not pinched.
6. Reconnect any cables that were detached in step 4, ensuring they are securely seated.
7. Carefully align the new cover and press it into place, ensuring all clips engage securely around the display.
8. Reinsert all screws removed in step 2. Do not overtighten.
9. Reinstall the battery (if removed) and reconnect the AC adapter. Power on the laptop to test functionality, including the display, webcam, and Wi-Fi.



Image: The YUHUI Black Top LCD Cover Case, designed for HP TPN-C125, TPN-C126, HQ-TRE, and RTL8723BE laptop models. This image shows the exterior of the replacement part.

OPERATING: CARE AND HANDLING

This replacement cover is designed for durability. To ensure its longevity and maintain the aesthetic of your laptop, follow these guidelines:

- Avoid placing heavy objects on the laptop when closed, as this can stress the cover and display assembly.
- Open and close the laptop gently, using both hands if possible, to distribute pressure evenly across the hinges and cover.
- Keep the cover free from excessive dust and debris to prevent scratches and maintain its appearance.

MAINTENANCE

Regular cleaning will help preserve the appearance of your laptop cover and prevent the buildup of grime.

Cleaning Instructions

- Ensure the laptop is powered off and disconnected from power before cleaning.
- Use a soft, lint-free microfiber cloth, slightly dampened with water or a mild, non-abrasive electronic cleaning solution.
- Gently wipe the surface of the cover. Avoid applying excessive pressure.
- Do not use harsh chemicals, abrasive cleaners, or solvents (such as alcohol, ammonia, or acetone), as these can damage the finish or material.

TROUBLESHOOTING

If you encounter issues after installing the new cover, consider the following common problems and solutions:

Cover Not Fitting Correctly

- **Issue:** The cover does not snap into place or has noticeable gaps.
- **Solution:** Recheck the alignment of the cover with the display assembly. Ensure no cables are obstructing the fit and that all internal components are properly seated and not interfering with the cover's closure.

Display or Peripheral Issues After Installation

- **Issue:** Screen flickering, no display, or webcam/Wi-Fi issues.
- **Solution:** These symptoms are often due to improperly connected internal cables. Power off the laptop, disconnect the battery, and carefully re-open the cover to check all cable connections (e.g., display cable, webcam cable, Wi-Fi antenna cables). Ensure they are securely seated in their respective ports.

Damaged Clips or Stripped Screws

- **Issue:** Clips on the cover or display assembly broke during installation, or screws are stripped.
- **Solution:** Handle components with care during installation to prevent damage. If clips are broken, the cover may not secure properly and might require replacement. If screws are stripped, they may need to be extracted and replaced with new ones of the correct size.

PRODUCT SPECIFICATIONS

Feature	Detail
Product Name	Laptop Cover

Feature	Detail
Brand	YUHUI
Compatible Model Numbers	HP TPN-C125, TPN-C126, HQ-TRE, RTL8723BE
Color	Black
ASIN	B07F596K76
Date First Available	June 29, 2018

WARRANTY AND SUPPORT

This product is a replacement part. For specific warranty information, please refer to the seller's policy at the time of purchase. Warranty terms may vary depending on the retailer.

For technical assistance, installation guidance, or further inquiries regarding this product, please contact your retailer or the manufacturer, YUHUI. The seller for this product is Kunshan Yu-huai Trading Company.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question