

[Manuals.plus](#) /

› [REVLON](#) /

› Revlon Light & Fast Hair Dryer User Manual

REVLON RVDR5253

Revlon Light & Fast Hair Dryer User Manual

Model: RVDR5253 | Brand: REVLON

1. IMPORTANT SAFETY INFORMATION

Please read all instructions before using this appliance. When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:
 - Always unplug this appliance immediately after using.
 - Do not use while bathing.
 - Do not place or store appliance where it can fall or be pulled into a tub or sink.
 - Do not place in or drop into water or other liquid.
 - If an appliance falls into water, unplug it immediately. Do not reach into the water.
- **WARNING:** To reduce the risk of burns, electrocution, fire, or injury to persons:
 - This appliance should never be left unattended when plugged in.
 - Close supervision is necessary when this appliance is used by, on, or near children or invalids.
 - Use this appliance only for its intended household use as described in this manual. Do not use attachments not recommended by the manufacturer.
 - Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a service center for examination and repair.
 - Keep the cord away from heated surfaces. Do not pull, twist, or wrap cord around the appliance.
 - Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
 - Never use while sleeping.
 - Never drop or insert any object into any opening.
 - Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
 - Do not use an extension cord with this appliance.
 - Do not direct hot air towards eyes or other heat-sensitive areas.
 - Attachments may be hot during use. Allow them to cool before handling.
 - Do not place appliance on any surface while it is operating.

2. PRODUCT OVERVIEW


The Revlon Light & Fast Hair Dryer (Model RVDR5253) is designed to provide stunning blowouts easily and comfortably. Its ultra-lightweight design makes it easy to handle, reducing fatigue during styling. The dryer incorporates advanced technologies to protect your hair and enhance its natural beauty.



Image: The Revlon Light & Fast Hair Dryer in copper finish, shown with its smoothing concentrator and volumizing diffuser attachments.

3. KEY FEATURES

- **IONIC TECHNOLOGY:** This technology helps to reduce frizz, leaving your hair looking shiny and healthy. It works by emitting negative ions that neutralize positive ions in the hair, which are responsible for frizz and static.



Advanced Ionic Technology®

gives you the power to create a salon-styled finish with less frizz.



©2020 Helen of Troy. All rights reserved.

Image: Detail showing the Advanced Ionic Technology feature, designed to reduce frizz and enhance shine.

- **CERAMIC COATING:** The dryer is coated with three layers of ceramic. This helps to distribute heat evenly, reducing the risk of heat damage from over-styling and making the drying process faster and easier.

TECHNOLOGY



Advanced Ionic Technology®

gives you the power to create a salon-styled finish. Less frizz for shiny, healthy-looking hair.



3X Ceramic Coating

helps reduce damage from over-styling with even heat distribution making styling fast and easy.



©2020 Helen of Troy. All rights reserved.

Image: Visual representation of key technologies including Ionic Technology and 3X Ceramic Coating.

- **LIGHTWEIGHT DESIGN:** Engineered with a featherweight design, this hair dryer ensures comfortable and easy handling, even during extended styling sessions.

REVLON

LIGHTWEIGHT, QUICK DRYING POWER

Light & Fast Hair Dryer

The REVLON® trademark is used under license from Revlon. ©2020 Revlon. All rights reserved.



Image: The lightweight design of the hair dryer contributes to quick and comfortable drying.

- **VERSATILE SETTINGS:** With 1875-Watt power, the dryer offers 2 heat and 2 speed settings for complete drying and styling flexibility. A dedicated Cold Shot button releases cool air to help set your hairstyle.



**2 Heat /
Speed Settings**
for complete drying
and styling flexibility

©2020 Helen of Troy. All rights reserved.

Image: The control panel with switches for heat (Hot, Warm, Cool) and speed (High, Low, Off) settings.

- **PRECISION ATTACHMENTS:** Includes a Smoothing Concentrator for precise airflow and a Volumizing Finger Diffuser for enhanced volume and defined curls.



©2020 Helen of Troy. All rights reserved.

Image: Labeled components of the hair dryer, including the concentrator and diffuser.

4. SETUP

1. **Unpack:** Carefully remove the hair dryer and all accessories from the packaging. Retain packaging for storage or future transport.
2. **Inspect:** Check the appliance for any signs of damage. Ensure the cord and plug are intact.
3. **Attach Accessories:**
 - To attach the Smoothing Concentrator or Volumizing Finger Diffuser, align the attachment with the nozzle of the dryer and push firmly until it clicks into place.
 - To remove, gently pull the attachment away from the nozzle. Ensure the dryer is cool before attaching or removing accessories.
4. **Plug In:** Insert the plug into a standard electrical outlet (120V AC). Ensure your hands are dry before plugging in or unplugging the appliance.

5. OPERATING INSTRUCTIONS

The Revlon Light & Fast Hair Dryer offers flexible settings to suit various hair types and styling needs.

Power and Heat Settings:

The dryer features two rocker switches on the handle for controlling speed and heat.

- **Speed Settings:**
 - **HIGH:** For fast drying and styling.
 - **LOW:** For gentle drying and precise styling.
 - **OFF:** Turns the dryer off.
- **Heat Settings:**
 - **HOT:** For quick drying of thick or coarse hair.
 - **WARM:** For normal drying of average hair.
 - **COOL:** For gentle drying or to set a style.
- **Cold Shot Button:** Press and hold the blue button on the handle to instantly switch to cool air. This helps to lock in your style for a longer-lasting finish.

Styling Tips:

- For best results, towel-dry hair to remove excess moisture before blow-drying.
- Use the HIGH speed and HOT heat setting for initial drying.
- Switch to LOW speed and WARM heat for styling.
- Finish with the Cold Shot to seal the hair cuticle and add shine.

6. ATTACHMENTS

Your Revlon Light & Fast Hair Dryer comes with two specialized attachments to help you achieve various hairstyles:

- **Smoothing Concentrator:** This narrow nozzle directs airflow to specific sections of your hair, ideal for creating sleek, smooth, and straight styles. Use with a round brush for best results.
- **Volumizing Finger Diffuser:** Designed to gently disperse air, this attachment is perfect for enhancing natural curls and waves, adding volume, and reducing frizz. Use by gently lifting hair at the roots with the diffuser fingers.



Image: The hair dryer's design features, highlighting the smoothing concentrator and volumizing diffuser.

7. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the life of your hair dryer.

1. **Always Unplug:** Before cleaning, always ensure the hair dryer is unplugged from the electrical outlet and has completely cooled down.
2. **Clean Air Intake Filter:** The rear filter cover is removable for easy cleaning. Gently twist or pull off the rear cap (refer to product diagram for exact method). Use a soft brush or vacuum cleaner to remove any accumulated lint, dust, or hair from the air intake filter. A clogged filter can lead to overheating and reduced performance. Replace the cap securely after cleaning.
3. **Wipe Exterior:** Wipe the exterior surfaces of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
4. **Storage:** When not in use, unplug the dryer. Allow it to cool and store it in a dry location. Do not wrap the cord around the dryer, as this can cause premature wear and breakage of the cord. Use the hanging ring for convenient storage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Dryer does not turn on.	No power to the outlet; tripped circuit breaker; faulty plug/cord.	Check the power outlet with another appliance. Reset circuit breaker if necessary. Inspect the cord and plug for damage. If damaged, do not use and seek professional repair.
Dryer overheats or shuts off.	Clogged air intake filter; prolonged use.	Unplug the dryer and allow it to cool down for at least 10-15 minutes. Clean the air intake filter as described in the Maintenance section. Ensure air vents are not blocked during use.
Weak airflow.	Clogged air intake filter.	Clean the air intake filter thoroughly.

Problem	Possible Cause	Solution
Hair is still frizzy.	Not utilizing Ionic Technology effectively; improper technique.	Ensure the dryer is set to an appropriate heat/speed. Use the Cold Shot button to seal the cuticle. Consider using anti-frizz hair products.

9. SPECIFICATIONS

Attribute	Detail
Model Number	RVDR5253
Power Source	Corded Electric
Wattage	1875 watts
Material	Ceramic
Color	Copper
Product Dimensions	3.9 x 8.9 x 10.6 inches
Item Weight	1.62 Pounds
Manufacturer	Helen of Troy
UPC	761318052531
Country of Origin	China

10. WARRANTY AND SUPPORT

This Revlon appliance is manufactured by Helen of Troy. For specific warranty information, including duration and terms, please refer to the warranty card included with your product packaging or visit the official Revlon or Helen of Troy website.

For further assistance, troubleshooting, or to inquire about replacement parts, please contact the manufacturer's customer support. Keep your purchase receipt as proof of purchase for warranty claims.

Additional resources:

- [User Guide \(PDF\)](#)
- [User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07F5QP2HK>

More documents and user manuals: **<https://manuals.plus/>**