Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Crelando 373472

Crelando Engraving Pen User Manual

Model: 373472

1. Introduction

Thank you for choosing the Crelando Engraving Pen. This versatile tool is designed for creating elegant lettering and individual patterns on a variety of hard materials. With its convenient, cordless operation and interchangeable tips, it's perfect for personalizing gifts and craft projects. Please read this manual carefully before first use to ensure safe and effective operation.

This package includes:

- Crelando Engraving Pen
- 2 Interchangeable Engraving Tips (Coarse/Fine)
- 2 Engraving Stencils
- 2 x 1.5V AA Batteries

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always wear appropriate safety glasses when operating the engraving pen to protect your eyes from debris.
- Wash your hands thoroughly after each use, especially after handling engraving tips or materials.
- This product is not suitable for children under 14 years of age.
- Children aged 14 and above should only use this item under direct adult supervision.
- Do not touch the engraving tip while the pen is operating or immediately after use, as it may be hot.
- Ensure the work area is well-ventilated to avoid inhaling dust or fumes from engraved materials.
- Do not use the pen on materials that are too soft or too hard, as this may damage the tip or the pen.
- Keep the pen and accessories out of reach of pets and small children.
- Do not immerse the pen in water or any other liquid.

3. Setup


3.1 Battery Installation

1. Twist the bottom cap of the engraving pen counter-clockwise to open the battery compartment.

2. Insert two (2) 1.5V AA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
3. Replace the bottom cap by twisting it clockwise until securely closed.

3.2 Attaching Engraving Tips

1. Ensure the pen is turned off.
2. Unscrew the tip holder at the front of the pen.
3. Select either the coarse or fine engraving tip based on your desired detail level.
4. Insert the chosen tip into the tip holder.
5. Screw the tip holder back onto the pen until it is finger-tight. Do not overtighten.



An image showing the Crelando Engraving Pen along with its accessories, including two interchangeable engraving tips (fine and coarse), two engraving stencils, and AA batteries.

4. Operating Instructions

4.1 Material Suitability

The Crelando Engraving Pen is suitable for engraving on hard materials such as:

- Glass
- Metal
- Leather
- Wood

Always test on an inconspicuous area of your material first to ensure desired results and prevent damage.

4.2 Engraving Process

1. Prepare your material: Ensure the surface is clean, dry, and free of oils or debris. Secure small items to prevent movement during engraving.
2. Select your tip: Choose the fine tip for intricate details and delicate lines, or the coarse tip for broader strokes and deeper engraving.
3. Use stencils (optional): If using the included stencils, place them firmly on your material.
4. Turn on the pen: Locate the power switch on the pen and slide it to the 'ON' position. The tip will begin to vibrate.
5. Begin engraving: Hold the pen like a pencil. Gently press the vibrating tip against the material and guide it along your desired pattern or lettering. Apply light, consistent pressure. Do not press too hard, as this can damage the tip or the material.
6. Work slowly and steadily for best results.
7. Turn off the pen: When finished, slide the power switch to the 'OFF' position.

5. Maintenance

5.1 Cleaning

- Always ensure the pen is turned off and cool before cleaning.
- Wipe the body of the pen with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Carefully remove any dust or debris from the engraving tip using a small brush or compressed air.

- If the tips become dull, they can be replaced with new ones.

5.2 Storage

- Store the engraving pen and its accessories in a dry, cool place, away from direct sunlight and moisture.
- If the pen will not be used for an extended period, remove the batteries to prevent leakage.
- Keep all components in their original packaging or a suitable storage case to prevent damage.

6. Troubleshooting

- **Pen not turning on:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with fresh ones.
  - Ensure the power switch is fully in the 'ON' position.
- **Engraving is too faint or inconsistent:**
  - Ensure the engraving tip is securely attached.
  - Try applying slightly more pressure, but do not force the pen.
  - The tip may be worn; consider replacing it with a new one.
  - Ensure the material surface is clean and suitable for engraving.
- **Pen vibrates but does not engrave:**
  - Check if the engraving tip is properly installed and not loose.
  - The tip might be completely worn out and needs replacement.

7. Specifications

Model Number	373472
Material	Plastic
Dimensions (W x L)	Approx. 2.9 mm x 17 cm
Weight	Approx. 107.2 g
Power Source	2 x 1.5V AA Batteries (included)
Package Dimensions	24 x 13 x 3.5 cm
Package Weight	150 g
First Available Date	November 25, 2022

8. Warranty and Support

For information regarding warranty, returns, or technical support, please refer to the retailer's policy where the product was purchased. Keep your proof of purchase for any warranty claims.

If you have further questions or require assistance, please contact the customer service department of your retailer.

© 2023 Crelando. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07F5QX4SF

More documents and user manuals: **https://manuals.plus/**