

[Manuals.plus](#) /

› [RASTAR](#) /

› RASTAR by Lamborghini Huracan STO RC Car User Manual

RASTAR 98800

RASTAR by Lamborghini Huracan STO RC Car User Manual

Model: 98800

INTRODUCTION

This user manual provides essential information for the safe and effective operation of your RASTAR by Lamborghini Huracan STO RC Car. Please read this manual thoroughly before use and retain it for future reference. This remote control vehicle is designed for both indoor and outdoor play, offering easy operation and responsive control.

WHAT'S IN THE BOX

- 1 x RASTAR by Lamborghini Huracan STO RC Car
- 1 x Remote Controller
- Instruction Manual (this document)



Image: The RASTAR Lamborghini Huracan STO RC Car in blue and orange, accompanied by its black remote controller, as packaged.

SAFETY INFORMATION

- Not suitable for children under 3 years due to small parts.
- Adult supervision is recommended during operation.
- Do not operate the vehicle near people, pets, or obstacles to prevent injury or damage.
- Avoid operating in wet conditions or on public roads.
- Always remove batteries from the car and remote when not in use for extended periods.
- Do not mix old and new batteries, or different types of batteries.

SETUP

1. Battery Installation (Car)

1. Locate the battery compartment on the underside of the car.
2. Use a screwdriver to open the battery compartment cover.
3. Insert 3 x AA 1.5V batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

2. Battery Installation (Remote Controller)

1. Locate the battery compartment on the back of the remote controller.
2. Use a screwdriver to open the battery compartment cover.
3. Insert 2 x AA 1.5V batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.



Image: The underside of the RASTAR Lamborghini Huracan STO RC Car, highlighting the battery compartment for 3 AA batteries and the direction adjustment knob.




Image: The remote controller and the RC car, with text indicating that 3 AA batteries are needed for the car and 2 AA for the remote.

3. Pairing and First Use

The car and remote are typically pre-paired. Turn on the car using the power switch on its underside. Then, turn on the remote controller. The car should respond to the remote's commands. If not, turn both off and on again.

4. Direction Adjustment

If the car does not drive straight, use the direction adjustment knob located on the underside of the car, near the front wheels, to fine-tune its alignment.

OPERATING INSTRUCTIONS

Your RASTAR Lamborghini Huracan STO RC Car offers full-function control for an engaging driving experience.

Remote Controller Functions:

- **Forward:** Push the left joystick forward.
- **Backward:** Pull the left joystick backward.
- **Turn Left:** Push the right joystick left.
- **Turn Right:** Push the right joystick right.



Image: A person holding the remote controller with the RASTAR Lamborghini Huracan STO RC Car in the background, illustrating its remote-controlled nature.

Driving Tips:

- The car operates on a single-frequency 2.4GHz system, minimizing interference.
- Maintain a control distance of up to 80 feet for optimal performance.
- The car is suitable for both indoor and outdoor use on smooth, dry surfaces.
- Working headlights and taillights enhance the driving experience.

MAINTENANCE

- **Cleaning:** Wipe the car and remote with a soft, dry cloth. Do not use chemical cleaners or water.
- **Storage:** Store the vehicle in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Always remove batteries from both the car and the remote controller if they will not be used for an extended period to prevent leakage and damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Car does not move or respond.	Batteries are low or incorrectly installed. Car or remote power switch is off. Car and remote are not paired.	Replace batteries in both car and remote, ensuring correct polarity. Turn on both the car and remote. Turn both off and on again to re-establish connection.
Poor control range or interference.	Low batteries. Operating too far from the car. Environmental interference.	Replace batteries. Operate within the 80-foot range. Move to an area with less electronic interference.
Car does not drive straight.	Wheel alignment issue.	Adjust the direction adjustment knob on the underside of the car.

SPECIFICATIONS

Feature	Detail
Brand	RASTAR
Model	Lamborghini Huracan STO (Model No. 98800)
Scale	1:24
Product Dimensions	7.44 x 3.66 x 2.05 inches
Item Weight	1.1 pounds
Car Battery Requirement	3 x AA 1.5V batteries (not included)
Remote Battery Requirement	2 x AA 1.5V batteries (not included)
Control Frequency	2.4GHz
Control Distance	Up to 80 feet
Recommended Age	14 years and up (Manufacturer recommended age: 14-14 years)
Features	Full Function (Forward, Backward, Left, Right), Working Head and Tail Lights, Custom Lamborghini Stamped Rims, Rubber Grip Tires, Authentic Body Styling



Image: Diagram showing the dimensions of the RASTAR Lamborghini Huracan STO RC Car, including length, width, and height.

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. Please refer to the product packaging or contact RASTAR customer service for details regarding warranty coverage and support.

For further assistance or inquiries, please visit the official RASTAR website or contact their customer support channels.