

[Manuals.plus](#) /

> [Hamilton](#) /

> Hamilton Ventura Elvis80 Automatic Asymmetric Men's Watch H24555331 User Manual

Hamilton H24555331

Hamilton Ventura Elvis80 Automatic Asymmetric Men's Watch H24555331 User Manual

PRODUCT OVERVIEW

The Hamilton Ventura Elvis80 Automatic Asymmetric Men's Watch, model H24555331, is a distinctive timepiece featuring a black dial, silver-tone stainless steel case, and a black rubber band. It is powered by an automatic movement and offers 50 meters (165 feet) of water resistance. This manual provides essential information for the proper use and care of your watch.



Figure 1: Hamilton Ventura Elvis80 Automatic Asymmetric Men's Watch H24555331

SETUP INSTRUCTIONS

Your Hamilton Ventura Elvis80 watch features an automatic movement, meaning it is powered by the natural motion of your wrist. To initiate operation or if the watch has stopped due to inactivity, follow these steps:

1. **Initial Winding:** Gently unscrew the crown (if applicable) and then turn it clockwise approximately 30-40 times. This provides an initial power reserve.
2. **Setting the Time:** Pull the crown out to the second position. Rotate the crown to set the hour and minute hands to the correct time.
3. **Setting the Date:** If your watch includes a date function, pull the crown out to the first position (if applicable) and rotate it to adjust the date. Avoid setting the date between 9 PM and 3 AM to prevent damage to the movement.
4. **Starting the Watch:** Push the crown back into its original position and screw it down firmly (if applicable) to ensure water resistance. The watch will begin running.

Regular wear will keep the watch wound. If worn daily, manual winding should not be necessary.

OPERATING THE WATCH

The Hamilton Ventura Elvis80 is designed for reliable timekeeping with its automatic movement. The watch is water resistant to 50 meters (165 feet), making it suitable for short periods of recreational swimming or showering. However, it is not designed for diving or high-impact water sports.

- **Water Resistance:** Ensure the crown is always pushed in and screwed down (if applicable) to maintain the specified water resistance. Do not operate the crown or any pushers while the watch is wet or submerged in water.
- **Automatic Movement:** The watch gains power from the natural motion of your wrist. Consistent wear ensures continuous operation. If the watch is not worn for an extended period, it may stop and require manual winding as described in the Setup Instructions.

CARE AND MAINTENANCE

Proper care will ensure the longevity and performance of your Hamilton Ventura Elvis80 watch.

- **Cleaning:** Regularly clean the watch case and rubber strap with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by thorough drying. Avoid using harsh chemicals or abrasive materials.
- **Temperature:** Avoid exposing your watch to extreme temperatures (above 60°C / 140°F or below 0°C / 32°F) or sudden temperature changes, as this can affect the movement and seals.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, certain electronic devices) as magnetism can affect the accuracy of the mechanical movement.
- **Impact:** Protect your watch from shocks and impacts. While robust, severe impacts can damage the internal components.
- **Servicing:** For optimal performance and to maintain water resistance, it is recommended to have your watch serviced by an authorized Hamilton service center every 3-5 years.

TROUBLESHOOTING

If you encounter any issues with your Hamilton Ventura Elvis80 watch, please consider the following common solutions:

- **Watch Not Running:** If the watch has stopped, ensure it has sufficient power reserve. Wear it consistently for several hours or manually wind the crown as described in the Setup Instructions.
- **Inaccurate Time:** Minor deviations in timekeeping are normal for mechanical watches. However, if the watch is consistently gaining or losing significant time, it may require adjustment. Ensure it has not been exposed to strong magnetic fields.
- **Water Intrusion:** If you notice condensation under the crystal or suspect water has entered the watch, immediately take it to an authorized service center. Do not attempt to dry it yourself.

For issues not resolved by these steps, or for any complex repairs, please contact an authorized Hamilton service center.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	H24555331
Case Material	Stainless Steel
Case Diameter	42.5 Millimeters
Case Thickness	11.38 Millimeters
Band Material	Rubber
Band Width	20 Millimeters
Dial Color	Black
Crystal Type	Sapphire Crystal
Movement Type	Automatic (Mechanical Movement)
Water Resistance	50 Meters / 165 Feet
Clasp Type	Tang Buckle

WARRANTY AND SUPPORT

Your Hamilton Ventura Elvis80 Automatic Asymmetric Men's Watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage.

For warranty service, repairs, or any technical support, please contact an authorized Hamilton service center. Unauthorized repairs may void your warranty.

You can find contact information for authorized service centers on the official Hamilton website or through your retailer.