

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Genie](#) /

› [Genie G3T-R 3-Button Garage Door Opener Remote Instruction Manual](#)

Genie G3T-R

Genie G3T-R 3-Button Garage Door Opener Remote Instruction Manual

Brand: Genie | Model: G3T-R

INTRODUCTION

The Genie G3T-R 3-Button Remote is designed to provide secure and convenient access to your garage. Featuring Intellicode Security technology, the access code changes with each door activation to prevent unauthorized entry. The remote also incorporates Auto-Seek Dual Frequency technology, which automatically selects between 315 or 390 MHz to minimize interference and enhance performance. This manual provides detailed instructions for setting up, operating, and maintaining your remote.

SETUP

1. Unpacking and Components

Your Genie G3T-R remote package includes the following items:

- Two (2) 3-button remotes
- Two (2) CR2032 batteries (pre-installed with pull tabs)
- Two (2) visor clips
- Programming instructions

INCLUDES:
2 VISOR CLIPS
2 CR2032 BATTERIES
1 SET OF INSTRUCTIONS



Figure 1: Included components of the Genie G3T-R remote package.

2. Battery Activation

The CR2032 batteries are pre-installed in your remotes. To activate them, locate and pull out the small plastic tab extending from the battery compartment. This tab prevents battery drain during storage and shipping.

3. Attaching the Visor Clip

To attach the visor clip:

1. Locate the slot on the back of the remote.
2. Slide the metal visor clip into the slot until it clicks securely into place.



Figure 2: Genie G3T-R remote with the visor clip attached.

4. Programming the Remote

The Genie G3T-R remote is easily programmable for use with Genie garage door openers. The programming method depends on the age of your opener:

- **For Genie Intellicode Garage Door Openers (1997-Present):** The remote can operate up to 3 openers. Refer to your garage door opener's manual for specific programming steps, which typically involve pressing the 'Learn' button on the opener unit and then a button on the remote.
- **For Genie Operators (1995-1997):** The remote will operate with up to 2 doors using only the top two buttons. Consult your specific opener's manual for programming instructions.

General programming steps often involve:

1. Locate the 'Learn Code' button on your garage door opener's power head.
2. Press and release the 'Learn Code' button. The LED indicator on the opener will begin to flash.
3. Within 30 seconds, press and release the desired button on your G3T-R remote.
4. The opener's LED will stop flashing and illuminate steadily, indicating successful programming.
5. Test the remote by pressing the programmed button. The garage door should activate.



Figure 3: Illustrative image of holding the remote for programming.

OPERATING

Using Your Genie G3T-R Remote

Once programmed, simply press the corresponding button on your remote to activate your garage door opener. The remote's three buttons allow you to control up to three different Genie garage door openers.



Figure 4: Operating the Genie G3T-R remote to open a garage door.

Intellicode Security Technology: This feature automatically changes the access code each time the door is activated, enhancing security by preventing code duplication.

Auto-Seek Dual Frequency Technology: The remote automatically switches between 315 MHz and 390

MHz frequencies to find the strongest signal, reducing interference from other devices and improving reliability.

HomeLink and Car2U Compatibility: The Genie G3T-R remote can be used to train built-in car wireless control systems like HomeLink and Car2U, allowing for integrated garage door operation from your vehicle.

MAINTENANCE

Battery Replacement

The Genie G3T-R remote uses a CR2032 coin cell battery. When the remote's range decreases or it stops responding, it may be time to replace the battery.

1. To open the remote casing, use a small coin or the visor clip as a lever in the small notch on the side of the remote.
2. Carefully pry open the two halves of the remote.
3. Remove the old CR2032 battery.
4. Insert a new CR2032 battery with the positive (+) side facing up.
5. Snap the two halves of the remote back together securely.

General Care

To ensure the longevity of your remote:

- Keep the remote dry and away from extreme temperatures.
- Avoid dropping the remote or subjecting it to strong impacts.
- Clean the remote periodically with a soft, dry cloth.

TROUBLESHOOTING

Common Issues and Solutions

- **Remote Not Working:** Check if the battery tab has been removed. Ensure the battery is correctly installed and has sufficient charge.
- **Reduced Range:** Replace the battery. Ensure there are no obstructions between the remote and the garage door opener.
- **Programming Failure:** Double-check the programming steps in this manual and your garage door opener's manual. Ensure you are within range of the opener during programming.
- **Interference:** The Auto-Seek Dual Frequency technology is designed to minimize interference. If issues persist, ensure no other electronic devices are operating on similar frequencies nearby.

If you continue to experience issues after attempting these troubleshooting steps, please refer to the support section for further assistance.

SPECIFICATIONS

Product Specifications

Manufacturer	The Genie Company
Part Number	39904R
Item Weight	2.72 ounces

Product Dimensions	10.75 x 7.75 x 2.75 inches
Item Model Number	Model G3T-R
Batteries	2 CR2032 batteries required (included)
Battery Cell Type	Lithium Manganese Dioxide
Color	Black
Max Number of Supported Devices	3
Compatible Devices	Genie Intellicode garage door openers (1995-present)

WARRANTY

The Genie G3T-R 3-Button Garage Door Opener Remote comes with a 1-year manufacturer's warranty. Please retain your proof of purchase for warranty claims.

SUPPORT

For additional support, detailed product information, or to purchase genuine Genie accessories and parts, please visit the official Genie Company website or contact their customer service. Using genuine parts ensures optimal performance and compatibility.

Video 1: Official video showcasing Genie Garage Door Opener Genuine Accessories. This video highlights various accessories and parts available from Genie, emphasizing quality and compatibility.