

Piscifun Piscifun-TL020

Piscifun Fish Gripper with Digital Scale (60LB Capacity) Instruction Manual

Model: Piscifun-TL020

INTRODUCTION

Thank you for choosing the Piscifun Fish Gripper with Digital Scale. This device is designed to provide a secure grip on fish and accurate weight measurements, enhancing your fishing experience. Crafted from high-grade stainless steel, it offers durability and reliable performance in various fishing conditions.

PRODUCT FEATURES

- **Unmatched Durability:** Constructed from high-grade stainless steel, designed for tough freshwater and saltwater conditions.
- **High Capacity:** Capable of weighing fish up to 60lb (27kg).
- **All-Weather Performance:** Water-resistant construction ensures functionality in various weather conditions.
- **Easy-to-Read Display:** Features a built-in LCD light and a large, clear display for accurate measurements, even in low light.
- **360° Rotating Handle:** Provides complete control over measurements.
- **Memory Function:** Saves up to 10 weight measurements.
- **Dual Mode:** Easily switch between Kilograms (KG) and Pounds (LBS).
- **Power-Saving Features:** Includes auto-shutoff and a low battery indicator.

SETUP

Battery Installation

The digital scale and LCD display require two AAA batteries for operation. Ensure correct polarity when inserting the batteries.

1. Locate the battery compartment on the back of the scale unit.
2. Open the battery compartment cover.

3. Insert two AAA batteries, observing the positive (+) and negative (-) indicators.
4. Securely close the battery compartment cover.

Sealed Design

- No Intrusion Within 1-Minute Immersion Test



Water-resistant Display



Sealed with Rubber Gaskets



Image: The Piscifun Fish Gripper with Digital Scale, highlighting the water-resistant display and the battery compartment for two AAA batteries.

OPERATING INSTRUCTIONS

Powering On/Off

- To power on, press the **POWER** button. The display will show "0.00".
- To power off, press and hold the **POWER** button for a few seconds until the display turns off. The device also features an auto-shutoff function to conserve battery life.

Selecting Units (KG/LBS)

To switch between Kilograms (KG) and Pounds (LBS):

- With the device powered on, press the **UNIT** button to toggle between the available measurement units.

Gripping a Fish

The fish gripper features a robust stainless steel clip for secure handling of fish.

1. Press the trigger to open the gripper jaws.
2. Carefully place the jaws around the fish's lower jaw.
3. Release the trigger to securely close the jaws on the fish.



Adjustable Wrist-Strap

- To prevent loss in case.

Rotatable & Non-Slip Handle

- More Convenient to weigh your fish.

Image: Close-up of the Piscifun Fish Gripper's anti-corrosion 304 stainless steel jaws, measuring 4cm/1.57 inches wide.

Weighing a Fish

For accurate weight measurement, keep the fish as still as possible during weighing.

1. Securely grip the fish using the gripper.
2. Hold the gripper vertically, allowing the fish to hang freely.

3. The weight will be displayed on the LCD screen. The 360° rotating handle allows for easy viewing from any angle.
4. To reset the scale for a new measurement, briefly press the **POWER** button to clear the previous reading to "0.00".




Image: The Piscifun Fish Gripper with Digital Scale, illustrating how to hold the gripper straight for precise weighing and a table detailing weight deviation ranges.

How to get precise weight

Keep the gripper straight when weighing your fish. Or the deviation will increase.

Deviation	
Weight	Deviation
0-5.5lb	±0.22lb
5.6-17.64lb	±0.22lb
17.65-24.25lb	±0.44lb
24.26-55.12lb	±0.88lb

Tips :

In order to keep your gripper working properly. Do not soak it in water though each gripper has passed one minute immersion test keep it functioning well in all weather condition even when drops into water.



Image: A person using the Piscifun Fish Gripper with Digital Scale to weigh a fish, demonstrating proper technique.

Memory Function

The scale can store up to 10 weight measurements.

- After a stable weight is displayed, press the **MEMORY** button to save the current reading.
- To recall saved measurements, repeatedly press the **MEMORY** button.

Adjustable Wrist Strap

The integrated adjustable wrist strap helps prevent accidental loss of the gripper, especially when handling active fish or in wet conditions.

Sealed Design

- No Intrusion Within 1-Minute Immersion Test



Water-resistant Display



Sealed with Rubber Gaskets



Image: The Piscifun Fish Gripper with Digital Scale, highlighting the adjustable wrist strap for security and the rotatable, non-slip handle for comfortable use.

Water Resistance

The Piscifun Fish Gripper is designed with water-resistant construction, including sealed components and rubber gaskets, to ensure functionality even when exposed to water. It has passed a one-minute immersion test.

Your browser does not support the video tag.

Video: Official Piscifun video demonstrating the water-resistant capabilities of the Fish Gripper with Digital Scale by submerging it in water.

MAINTENANCE

- After each use, especially in saltwater, rinse the gripper with fresh water to remove salt and debris.
- Ensure the gripper is dry before storing.
- Periodically check the battery compartment for any signs of corrosion and replace batteries as needed.

TROUBLESHOOTING

Inaccurate Weight Readings

- Ensure the fish is held still and the gripper is vertical during weighing. Movement can cause deviations.
- Verify that the scale is zeroed before each measurement. Press the**POWER** button briefly to reset to "0.00".
- Check battery levels. Low batteries can affect accuracy.

Display Not Turning On

- Check if the batteries are correctly installed and fully charged. Replace if necessary.
- Ensure the **POWER** button is pressed firmly.

SPECIFICATIONS

Feature	Detail
Brand	Piscifun
Model	Piscifun-TL020
Weight Capacity Maximum	60 pounds (27 kg)
Material Type	Stainless Steel
Display Type	LED
Power Source	2 x AAA Batteries
Special Features	Dual Display Mode, Large Display, Memory Function, Water-Resistant
Item Weight	0.26 kg

WARRANTY AND SUPPORT

Piscifun products are designed for quality and durability. For any questions, technical assistance, or warranty claims, please contact Piscifun customer support through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question