

[Manuals.plus](#) /

› [Aigostar](#) /

› Aigostar 1L Portable Electric Kettle (Model 300104LDS) Instruction Manual

Aigostar 300104LDS

Aigostar 1L Portable Electric Kettle Instruction Manual

Model: 300104LDS

1. INTRODUCTION

Thank you for purchasing the Aigostar 1L Portable Electric Kettle. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your new appliance. Please read these instructions thoroughly before first use and retain them for future reference.



Figure 1: Aigostar 1L Portable Electric Kettle

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions carefully.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact customer support for examination, repair, or adjustment.

- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The kettle features an **Automatic Shut-Off** function and **Boil Dry Protection** for enhanced safety.
- The kettle is constructed with **BPA-Free** and food-grade plastic materials.
- The handle is designed to be **Cool-Touch**, providing a safe grip even when the water is hot.



Figure 2: Key Safety Features

3. PRODUCT OVERVIEW

Components

- Kettle Body with Lid
- 360° Rotational Power Base with Integrated Cord Wrap
- Removable Filter (located in the spout)

Features

- **Capacity:** 1.0 Liter, suitable for 1-3 persons.
- **Power:** 1100W for rapid boiling.
- **Automatic Shut-Off:** Automatically turns off when water boils.
- **Boil Dry Protection:** Prevents the kettle from operating without water.
- **BPA-Free:** Constructed with food-grade, BPA-free plastic.
- **Cordless Design:** Kettle lifts off the 360° rotational base for easy pouring.
- **Integrated Cord Wrap:** For compact storage of the power cord.
- **Wide Opening Lid:** 120° broad opening for easy filling and cleaning.
- **Dual Water Windows:** Allows easy monitoring of water level from both sides.
- **Removable Filter:** Helps to combat limescale buildup.

PORTABLE DESIGN

- Cordless body
- 360° rotary base
- Built-in cord storage




Figure 3: Portable Design and Cordless Operation



Figure 4: Internal Features and Design

4. SETUP

4.1 Unpacking

Carefully remove the kettle and all accessories from the packaging. Ensure all components are present and undamaged. Dispose of packaging materials responsibly.

4.2 First Use Cleaning

Before initial use, fill the kettle with water to the MAX line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues. For a more thorough cleaning, especially to remove any potential deposits or odors, mix 3 tablespoons of vinegar or lemon juice with water, boil, and let it sit for 5-8 hours or overnight before rinsing thoroughly.

4.3 Placing the Kettle

Place the power base on a stable, flat, heat-resistant surface. Ensure the power cord is fully unwound from the integrated cord wrap and plugged into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Filling the Kettle

Press the lid release button to open the 120° broad opening lid. Fill the kettle with the desired amount of water, ensuring it is between the MIN and MAX (1.0L) marks on the water level indicator. Do not overfill or underfill. Close the lid securely.



Figure 5: Filling the Kettle

5.2 Boiling Water

Place the kettle firmly on its power base. Press the ON/OFF switch down. The red indicator light will illuminate, indicating that the kettle is heating. The kettle will begin to boil water rapidly. Once the water reaches a rolling boil, the kettle will automatically shut off, and the indicator light will extinguish.

5.3 Pouring Water

Carefully lift the kettle from its power base. The cordless design allows for easy pouring. Pour the hot water slowly and steadily to avoid splashing. The cool-touch handle ensures safe handling.



Figure 6: Pouring Hot Water

5.4 Suggested Uses

The Aigostar electric kettle is ideal for preparing various hot beverages and instant meals:

- Tea
- Coffee (pour-over, French press)
- Instant Oatmeal
- Instant Soups
- Noodles
- Hot Chocolate



Figure 7: Versatile Uses of the Kettle

Video 1: Aigostar Small Electric Kettle Overview. This video demonstrates the kettle's compact size, automatic operation, and quick boiling capabilities, highlighting its ease of use for various hot beverages.

Video 2: Travel Hot Water Boiler in Use. This video showcases the kettle's portability and its application for making coffee, emphasizing its BPA-free construction and convenience for travel.

6. CLEANING AND MAINTENANCE

Regular cleaning and maintenance will prolong the life of your kettle and ensure optimal performance.

6.1 Exterior Cleaning

Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Ensure the kettle is unplugged and completely cool before cleaning.

6.2 Interior Descaling

Mineral deposits (limescale) can build up inside the kettle over time, especially in areas with hard water. To descale:

1. Mix 3 tablespoons of vinegar or lemon juice with water.
2. Fill the kettle with this solution to the MAX line.
3. Boil the solution.
4. Allow the solution to soak in the kettle for 5-8 hours, or overnight.
5. Discard the solution and rinse the interior thoroughly with fresh water.
6. If necessary, gently wipe the inner pot with a soft cloth after soaking.
7. Repeat the process if significant scale remains.

6.3 Removable Filter

The filter in the spout can be removed for cleaning. Rinse it under running water to remove any trapped particles or limescale. Ensure it is properly reinserted before using the kettle.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	No power to the base; Kettle not properly seated on base; Boil-dry protection activated.	Check power outlet; Ensure kettle is correctly placed on base; Allow kettle to cool down, then refill with water and restart.
Water does not boil.	Kettle not switched on; Insufficient water.	Press the ON/OFF switch; Ensure water level is above MIN mark.
Kettle shuts off before boiling.	Boil-dry protection activated (if kettle was empty or near empty).	Allow kettle to cool down, then refill with water and restart.
White deposits inside kettle.	Limescale buildup from hard water.	Perform descaling procedure as described in Section 6.2.

8. SPECIFICATIONS

- **Brand:** Aigostar
- **Model Name:** 300104LDS
- **Capacity:** 1.0 Liter
- **Power:** 1100W (110V ~60Hz)
- **Material:** BPA-Free, Food Grade Plastic
- **Special Features:** Automatic Shut-Off, Boil Dry Protection, Heat Resistant Handle, Lightweight, Rapid Boil
- **Product Dimensions:** 7.4"L x 6"W x 8.14"H
- **Item Weight:** 1 Pound
- **Included Components:** Mini Electric Tea Kettle, 360° Base, User Manual
- **Product Care Instructions:** Hand Wash
- **Country/Region of Origin:** China
- **UPC:** 718356204774

9. WARRANTY AND SUPPORT

For any questions regarding your Aigostar 1L Portable Electric Kettle, please contact Aigostar customer support. We are committed to providing assistance and ensuring your satisfaction with our products. Please refer to the product packaging or the official Aigostar website for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question