

[Manuals.plus](#) /

› [Dell](#) /

› Dell P Series 21.5" FHD 1080p LED-Lit Monitor (P2219H) User Manual

Dell P2219H

Dell P Series 21.5" FHD 1080p LED-Lit Monitor (P2219H) User Manual

Brand: Dell | Model: P2219H

INTRODUCTION

This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your Dell P Series 21.5" FHD 1080p LED-Lit Monitor (P2219H). The monitor features an ultrathin bezel design and a compact footprint, optimizing desk space. It offers a Full HD 1920 x 1080 resolution, a 1000:1 contrast ratio, 250 cd/m² brightness, and a fast 5 ms response time in fast mode, supporting up to 16.7 million colors. Connectivity options include HDMI, DisplayPort, VGA, and USB ports for peripherals. The monitor's ergonomic stand allows for tilt, swivel, pivot, and height adjustments, and its IPS (In-Plane Switching) panel provides wide 178° horizontal and vertical viewing angles for consistent color and clarity.

1. SETUP INSTRUCTIONS

1.1 What's in the Box

- Monitor panel
- Stand riser and base
- 1x Power cable
- 1x Power adapter
- 1x HDMI 1.4 cable
- Quick setup guide
- Safety, Environmental, and Regulatory Information

1.2 Monitor Assembly

Carefully remove all components from the packaging. Attach the stand riser to the monitor panel, ensuring it clicks securely into place. Then, attach the base to the stand riser and tighten any screws if necessary. Place the assembled monitor on a stable, flat surface.



Front view of the Dell P2219H monitor with its stand assembled, ready for use.

1.3 Connecting Your Monitor

Connect the power cable to the monitor and a power outlet. Use the provided HDMI 1.4 cable to connect your computer's HDMI output to the monitor's HDMI input. Alternatively, you can use a DisplayPort or VGA cable if your computer supports those connections. For USB peripheral connectivity, connect the upstream USB cable from your computer to the monitor's upstream USB port, then connect your USB devices to the downstream USB ports on the monitor.



Rear view of the Dell P2219H monitor displaying the various input and output ports, including power, HDMI, DisplayPort, VGA, and USB ports.

2. OPERATING YOUR MONITOR

2.1 Power On/Off

Press the power button located on the bottom right side of the monitor bezel to turn the monitor on or off. The power LED indicator will illuminate when the monitor is on.

2.2 On-Screen Display (OSD) Menu

Use the buttons next to the power button to navigate the On-Screen Display (OSD) menu. This menu allows you to adjust various settings such as brightness, contrast, input source, color settings, and more. Refer to the quick setup guide for detailed OSD navigation instructions.

2.3 Adjusting the Monitor Position

The Dell P2219H monitor offers extensive ergonomic adjustments:

- **Height Adjustment:** Raise or lower the monitor to your preferred viewing height.
- **Tilt:** Tilt the screen forward or backward to find the optimal viewing angle.

- **Swivel:** Rotate the monitor left or right on its base.
- **Pivot:** Rotate the screen 90 degrees to switch between landscape and portrait orientation.



Diagram illustrating the adjustable dimensions and movement capabilities of the Dell P2219H monitor, including height, tilt, swivel, and pivot.



Side view of the Dell P2219H monitor, demonstrating its ability to pivot the screen vertically.

3. MAINTENANCE AND CARE

3.1 Cleaning the Monitor

To clean your monitor, ensure it is powered off and unplugged. Use a soft, lint-free cloth lightly dampened with water or a non-abrasive screen cleaner. Avoid using harsh chemicals, abrasive cleaners, or spraying liquid directly onto the screen.

3.2 General Care

Avoid exposing the monitor to direct sunlight, extreme temperatures, or high humidity. Do not block the ventilation openings on the monitor. Handle the monitor with care to prevent physical damage.

4. TROUBLESHOOTING COMMON ISSUES

4.1 No Display or Blank Screen

- Ensure the power cable is securely connected to both the monitor and the power outlet.
- Verify that the video cable (HDMI, DisplayPort, or VGA) is firmly connected to both the monitor and your computer.
- Check if the correct input source is selected on the monitor using the OSD menu.
- Restart your computer.

4.2 Image Quality Issues (Blurry, Distorted, Incorrect Colors)

- Ensure your computer's display resolution is set to the native resolution of the monitor (1920 x 1080).
- Adjust brightness, contrast, and color settings through the monitor's OSD menu.
- Check for any bent pins on the video cable connectors.

4.3 Monitor Not Responding

- Perform a power cycle: Turn off the monitor, unplug it from the power outlet, wait for 30 seconds, then plug it back in and turn it on.
- If the issue persists, try connecting the monitor to a different computer or using a different video cable to isolate the problem.

5. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Dell
Model Number	P2219H
Screen Size	21.5 Inches
Resolution	FHD 1080p (1920 x 1080 Pixels)
Aspect Ratio	16:9
Display Type	LED IPS
Refresh Rate	60 Hz
Response Time	8 Milliseconds (5 ms in fast mode)
Brightness	250 cd/m²
Contrast Ratio	1,000:1
Viewing Angle	178 Degrees (Horizontal/Vertical)
Connectivity Technology	HDMI, USB, VGA
Total Number of HDMI Ports	1
Total USB Ports	3 (USB 3.0)
Additional Features	Anti Glare Screen, Height Adjustment, Pivot Adjustment, Swivel Adjustment, Tilt Adjustment, Comfort View

Feature	Specification
Item Dimensions (D x W x H)	6.54"D x 19.19"W x 18.58"H
Item Weight	6.1 Pounds
Power Consumption	12 Watts
VESA Mount	Yes (100 x 100mm)

For more detailed environmental and regulatory information, please refer to the [EPREL database](#).

6. WARRANTY INFORMATION

This Dell P2219H monitor is covered by a **1-Year Manufacturer Warranty**. For specific terms and conditions, please refer to the warranty documentation included with your product or visit the official Dell support website.

7. CUSTOMER SUPPORT

For further assistance, technical support, or to access drivers and manuals, please visit the official Dell support website:

[Dell Support](#)
[Visit the Dell Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07F8Z2WFL>

More documents and user manuals: <https://manuals.plus/>