

[manuals.plus](#) /

› [Sunnydaze](#) /

› [Sunnydaze Outdoor Double Chaise Rocking Lounge Chair with Canopy and Headrest Pillows - Instruction Manual](#)

Sunnydaze PL-625

Sunnydaze Outdoor Double Chaise Rocking Lounge Chair with Canopy and Headrest Pillows

Model: PL-625

Brand: Sunnydaze

PRODUCT OVERVIEW

The Sunnydaze Outdoor Double Chaise Rocking Lounge Chair is designed for comfortable outdoor relaxation for two. It features a durable powder-coated steel frame, a weather-resistant sling fabric seat, and an adjustable canopy for shade. Headrest pillows are included for enhanced comfort. The chair is designed to gently rock, providing a soothing experience, and includes wheels for easy repositioning.



Image: The Sunnydaze Outdoor Double Chaise Rocking Lounge Chair, showcasing its black and white design with canopy and headrest pillows, set on a patio overlooking a pond.

SAFETY INFORMATION

Important Warnings

WARNING: This product can expose you to chemicals including Lead, which is known to the state of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

Always ensure the lounge chair is placed on a stable, level surface before use. Do not exceed the maximum weight capacity of 440 lbs. Keep children and pets away from the chair during assembly and ensure all parts are securely fastened before allowing anyone to use it. Avoid using the chair in strong winds or severe weather conditions; store indoors or cover when not in use to prolong product life.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.



Image: All components of the Sunnydaze Outdoor Double Chaise Rocking Lounge Chair laid out, including the frame pieces, fabric seat, canopy, headrest pillows, and hardware.

- Main Frame Sections (Rocking Base, Seat Support)
- Fabric Seat with Velcro Straps
- Canopy Frame Poles
- Canopy Fabric
- Headrest Pillows (2)
- Assembly Hardware (Bolts, Washers, Allen Wrench)
- End Caps and Wheels

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

Video: Detailed assembly guide for the Sunnydaze Double Chaise Rocking Lounge Chair with Canopy and Pillows. This video demonstrates each step of the assembly process, from connecting frame pieces to attaching the fabric and canopy.

1. **Assemble the Base Frame:** Connect the main rocking base sections using the provided hardware. Ensure all bolts are finger-tightened initially. Pay attention to the orientation of the curved sections; the side labeled 'B' (back) is longer than side 'A' (front).
2. **Attach the Seat Support Frame:** Secure the rectangular seat support frame to the rocking base. Again, only finger-tighten bolts at this stage.
3. **Install the Fabric Seat:** Slide the fabric seat onto the assembled frame. Ensure the velcro strips on the fabric face the back side of the chair and are not visible from the front when set up. Secure the fabric to the frame using the designated attachment points and hardware.
4. **Assemble Canopy Poles:** Connect the curved canopy poles. Ensure they are securely joined.
5. **Attach Canopy Fabric:** Slide the canopy fabric onto the assembled canopy poles.
6. **Mount Canopy to Chair:** Attach the canopy poles to the designated points on the main chair frame. These points are typically located near the top of the curved backrest.
7. **Final Tightening:** Once all components are in place and correctly aligned, fully tighten all bolts using the provided Allen wrench. Do not overtighten.
8. **Attach Headrest Pillows:** Secure the headrest pillows to the fabric seat using their integrated straps or attachment mechanisms.

- 1 Lounger gently rocks back and forth
- 2 Two detachable pillows for comfortable head support
- 3 Move anywhere with two back wheels



Image: A close-up view highlighting the rocking mechanism and built-in wheels for easy mobility, along with the comfortable headrest pillows.

OPERATING INSTRUCTIONS

The Sunnydaze Double Chaise Rocking Lounge Chair is designed for ease of use and comfort.

Video: A brief overview of the Double Chaise Rocking Lounge Chair, demonstrating its rocking motion and overall design in an outdoor setting.

- **Rocking Motion:** Gently push off with your feet to initiate the rocking motion. The chair is designed for a smooth, comfortable sway.
- **Canopy Adjustment:** The canopy provides shade from direct sunlight. It is fixed in position to offer consistent overhead protection.
- **Mobility:** To move the lounge chair, lift the front end slightly and use the built-in wheels at the back to roll it to

your desired location.

- **Comfort:** Adjust the headrest pillows for optimal neck and head support.



Image: A couple comfortably relaxing together on the double chaise rocking lounge chair, enjoying the outdoor environment.

MAINTENANCE

Proper care will extend the life and appearance of your lounge chair.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Rust Prevention:** The powder-coated steel frame is designed to resist rust, but prolonged exposure to moisture can cause issues. Regularly inspect the frame for any signs of rust, especially at joints or where paint may be chipped. Touch up any affected areas with rust-inhibiting paint.
- **Storage:** During off-seasons or periods of non-use, store the lounge chair in a dry, protected area. If outdoor storage is necessary, use a weather-resistant cover.

- **Fabric Care:** The vinyon fiber and polyethylene fabric is weather-resistant. Allow it to air dry completely after cleaning or rain to prevent mildew.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Chair does not rock smoothly or feels unstable.	Incorrect assembly of the rocking base or loose bolts.	Review assembly instructions, particularly Step 1 regarding the 'A' and 'B' sides of the rocking base. Ensure all bolts are securely tightened.
Discomfort from a bar in the back.	Fabric seat installed incorrectly or facing the wrong direction.	Ensure the fabric seat is oriented correctly, with the velcro strips facing the back side of the chair. Re-install if necessary.
Rust spots appearing on the frame or patio.	Prolonged exposure to moisture or damaged powder coating.	Regularly wipe down the frame, especially after rain. If rust appears, clean the area and apply rust-inhibiting paint. Consider using a protective cover when not in use.
Chair blows over easily in wind.	Lightweight design combined with wind exposure.	Secure the chair during windy conditions or move it to a more sheltered location. Consider using sandbags or other weights on the base if necessary, ensuring they do not interfere with rocking.

SPECIFICATIONS

Feature	Detail
Brand	Sunnydaze
Model Name	PL-625
Color	Black and White
Overall Dimensions	55" W x 70" D x 72" H
Seat Dimensions	49" W x 77" D x 19" H
Arm Dimensions	2" W x 28" D x 26" H
Item Weight	56 lbs
Maximum Weight Recommendation	440 Pounds
Frame Material	Powder-Coated Steel

Feature	Detail
Seat Material	Vinyon Fiber and Polyethylene with Polypropylene Fiber Filling
Special Features	Arm Rest, Head Support, Rocking Motion, Wheels, Canopy
Product Care Instructions	Wipe Clean
UPC	819271025625



Image: A diagram showing the key dimensions of the Sunnydaze Outdoor Double Chaise Rocking Lounge Chair, including width, depth, and height.

WARRANTY AND SUPPORT

Sunnydaze Decor stands behind its products.

- **Manufacturer's Warranty:** This product is backed by a 1-year manufacturer's warranty.
- **Customer Support:** For assistance with assembly, missing parts, or any other inquiries, please contact Sunnydaze Decor customer support.
- **Online Resources:** Visit the official Sunnydaze Store for additional product information and support: [Sunnydaze Store on Amazon](#).