

[Manuals.plus](#) /

› [LITTLE BALANCE](#) /

› LITTLE BALANCE 8231 Bamboo Kitchen Scale User Manual

LITTLE BALANCE 8231

LITTLE BALANCE Bamboo Kitchen Scale

MODEL: 8231

Introduction

Thank you for choosing the LITTLE BALANCE Bamboo Kitchen Scale. This manual provides essential information for the safe and efficient use of your new kitchen scale. Please read these instructions carefully before use and retain them for future reference. This digital kitchen scale features a natural bamboo platform, a retractable display, and a convenient USB rechargeable battery, designed for precise measurements up to 10 kg.

Safety Information

- Do not immerse the scale in water or any other liquid.
- Clean the scale with a damp cloth only. Do not use abrasive cleaners.
- Place the scale on a hard, flat, and stable surface to ensure accurate readings.
- Avoid exposing the scale to extreme temperatures, direct sunlight, or high humidity.
- Do not overload the scale beyond its maximum capacity of 10 kg.
- Keep the scale out of reach of children.
- Handle the retractable display gently to prevent damage.

Package Contents

Please check the package for the following items:

- LITTLE BALANCE Bamboo Kitchen Scale (Model 8231)
- USB Charging Cable
- User Manual



Image: Product packaging illustrating the scale and its components.

Setup

1. **Unpack the Scale:** Carefully remove the scale and all accessories from the packaging.
2. **Initial Charge:** Before first use, it is recommended to fully charge the scale using the provided USB cable. Connect the USB cable to the scale's charging port and a suitable USB power source (e.g., computer, USB wall adapter). The display will indicate charging status.
3. **Placement:** Place the scale on a firm, flat, and level surface to ensure accurate measurements. Avoid soft or uneven surfaces.
4. **Extend Display:** Gently slide out the display panel from the side of the scale until it is fully extended and visible.



Image: The scale with its display retracted and extended.

Operating Instructions

1. **Power On:** Press the power button (often integrated with the TARE button) to turn on the scale. The display will show '0' or '0.0'.

2. **Select Unit:** Press the 'UNIT' button to cycle through available measurement units (e.g., grams (g), ounces (oz), pounds (lb), milliliters (ml)). Select your desired unit before weighing.
3. **Tare Function:** To weigh ingredients in a container, first place the empty container on the scale. Press the 'TARE' button. The display will reset to '0'. You can now add ingredients to the container, and the scale will display only the weight of the ingredients.
4. **Weighing:** Place the item(s) to be weighed directly onto the bamboo platform or into a tared container. Read the weight displayed on the screen.
5. **Power Off:** Press and hold the power button for a few seconds to turn off the scale. The scale may also have an auto-off function to conserve battery.



Image: The scale in use, demonstrating weighing various kitchen ingredients.

Maintenance and Care

- **Cleaning:** Wipe the bamboo platform and display with a soft, slightly damp cloth. Do not use harsh chemicals or abrasive materials. Ensure the scale is completely dry before storage or next use.
- **Storage:** Store the scale in a dry place at room temperature. Retract the display panel when not in use to protect it from damage.
- **Battery Care:** Recharge the scale when the battery indicator shows low power. Avoid completely draining the battery frequently to prolong its lifespan.



Image: Side profile of the scale, highlighting its compact design for easy storage.

Troubleshooting

- **Scale does not turn on:** Ensure the scale is fully charged. Connect it to a USB power source and allow it to charge for a period.
- **Inaccurate readings:**
 - Ensure the scale is on a hard, flat, and stable surface.
 - Make sure no objects are touching the scale or interfering with its movement.
 - Re-tare the scale before weighing, especially if using a container.
 - Avoid placing items off-center on the weighing platform.
- **Display shows 'Err' or other error messages:** This may indicate an overload. Remove items from the scale immediately. If the error persists, try turning the scale off and on again.

Specifications

Model	8231
Material	Bamboo
Maximum Weight Capacity	10 Kilograms (10 kg)
Graduation	1 gram (1 g)
Dimensions (L x W x H)	240 mm x 180 mm x 20 mm
Power Source	USB Rechargeable
Item Weight	0.58 Kilograms



Image: The scale with its length and width dimensions indicated.



Image: Detail of the genuine bamboo weighing platform.

Warranty

This LITTLE BALANCE Kitchen Scale comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty information provided with your product packaging.



GARANTIE

Image: Warranty graphic. Please refer to the text above for the applicable warranty period.

Support

If you encounter any issues or have questions not covered in this manual, please contact LITTLE BALANCE customer

support. Refer to the product packaging or the official LITTLE BALANCE website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07F9VP433>

More documents and user manuals: <https://manuals.plus/>